

**ENGINE SECTION 3**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

**FUEL INJECTION (FUEL SYSTEMS) FU(H4DOSTC)**

**EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES) EC(H4DOSTC)**

**INTAKE (INDUCTION) IN(H4DOSTC)**

**MECHANICAL ME(H4DOSTC)**

**EXHAUST EX(H4DOSTC)**

**COOLING CO(H4DOSTC)**

**LUBRICATION LU(H4DOSTC)**

**SPEED CONTROL SYSTEMS SP(H4DOSTC)**

**IGNITION IG(H4DOSTC)**

**STARTING/CHARGING SYSTEMS SC(H4DOSTC)**

**ENGINE (DIAGNOSTICS) EN(H4DOSTC)**



# ENGINE (DIAGNOSTICS)

# *EN(H4DOSTC)*

---

	<b>Page</b>
1. Basic Diagnostic Procedure .....	2
2. Check List for Interview .....	4
3. General Description .....	6
4. Electrical Components Location.....	9
5. Engine Control Module (ECM) I/O Signal .....	20
6. Engine Condition Data .....	23
7. Transmission Control Module (TCM) I/O Signal .....	24
8. Data Link Connector .....	25
9. Subaru Select Monitor.....	26
10. Read Diagnostic Trouble Code .....	32
11. Inspection Mode.....	33
12. Clear Memory Mode.....	35
13. Compulsory Valve Operation Check Mode .....	36
14. Engine Malfunction Indicator Lamp (MI) .....	38
15. Diagnostics for Engine Starting Failure .....	51
16. List of Diagnostic Trouble Code (DTC) .....	62
17. Diagnostic Procedure with Diagnostic Trouble Code (DTC) .....	66
18. General Diagnostic Table.....	246



# BASIC DIAGNOSTIC PROCEDURE

ENGINE (DIAGNOSTICS)

## 1. Basic Diagnostic Procedure

### A: PROCEDURE

#### 1. ENGINE

Step	Value	Yes	No
<b>1 CHECK ENGINE START FAILURE.</b> 1) Ask the customer when and how the trouble occurred using the interview check list. <Ref. to EN(H4DOSTC)-4, CHECK, Check List for Interview.> 2) Start the engine. Does the engine start?	Engine starts.	Go to step 2.	Inspection using "Diagnostics for Engine Start Failure". <Ref. to EN(H4DOSTC)-66, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
<b>2 CHECK ILLUMINATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI).</b> Does the CHECK ENGINE malfunction indicator lamp illuminate?	Indicator lamp illuminates.	Go to step 3.	Inspection using "General Diagnostics Table". <Ref. to EN(H4DOSTC)-246, General Diagnostic Table.>
<b>3 CHECK INDICATION OF DTC ON DISPLAY.</b> 1) Turn the ignition switch to OFF. 2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector. 3) Turn the ignition switch to ON and the Subaru Select Monitor or OBD-II general scan tool switch to ON. 4) Read the DTC on the Subaru Select Monitor. Does the Subaru Select Monitor indicate DTC?	DTC is indicated.	Record the DTC. Repair the trouble cause. <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).> Go to step 4.	Repair the related parts.  NOTE: If DTC is not shown on display although the MI illuminates, perform diagnostics of MI (CHECK ENGINE malfunction indicator lamp) circuit or combination meter. <Ref. to EN(H4DOSTC)-38, Engine Malfunction Indicator Lamp (MI).>
<b>4 PERFORM THE DIAGNOSIS.</b> 1) Perform the clear memory mode. <Ref. to EN(H4DOSTC)-35, Clear Memory Mode.> 2) Perform the inspection mode. <Ref. to EN(H4DOSTC)-33, Inspection Mode.> Does the Subaru Select Monitor indicate DTC?	DTC is indicated.	Inspect using "Diagnostics Procedure with Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOSTC)-66, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Complete the diagnosis.

## 2. AUTOMATIC TRANSMISSION

When trouble code about automatic transmission is shown on display, carry out the following basic check. After that, carry out the replacement or repair work.

- 1) ATF level check <Ref. to AT-30, Automatic Transmission Fluid.>
- 2) Differential gear oil level check <Ref. to AT-31, Differential Gear Oil.>
- 3) ATF leak check <Ref. to AT-30, Automatic Transmission Fluid.>
- 4) Differential gear oil leak check <Ref. to AT-31, Differential Gear Oil.>
- 5) Stall test <Ref. to AT-33, Stall Test.>
- 6) Line pressure test <Ref. to AT-36, Line Pressure Test.>
- 7) Transfer clutch pressure test <Ref. to AT-38, Transfer Clutch Pressure Test.>
- 8) Time lag test <Ref. to AT-35, Time Lag Test.>
- 9) Road test <Ref. to AT-32, Road Test.>
- 10) Shift characteristics <Ref. to AT-38, Transfer Clutch Pressure Test.>

# CHECK LIST FOR INTERVIEW

ENGINE (DIAGNOSTICS)

## 2. Check List for Interview

### A: CHECK

#### 1. CHECK LIST NO. 1

Check the following items when problem has occurred.

NOTE:

Use copies of this page for interviewing customers.

Customer's name		Engine no.	
Date of sale		Fuel brand	
Date of repair		Odometer reading	km
Vin no.			miles
Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Various/Others:		
Outdoor temperature	°C (°F)		
	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold		
Place	<input type="checkbox"/> Highway <input type="checkbox"/> Suburbs <input type="checkbox"/> Inner city <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Others:		
Engine temperature	<input type="checkbox"/> Cold <input type="checkbox"/> Warming-up <input type="checkbox"/> After warming-up <input type="checkbox"/> Any temperature <input type="checkbox"/> Others:		
Engine speed	rpm		
Vehicle speed	MPH		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH)		
Headlight	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Rear defogger	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Blower	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Radio	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
A/C compressor	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	CD/Cassette	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Cooling fan	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Car phone	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Front wiper	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	CB	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Rear wiper	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF		

# CHECK LIST FOR INTERVIEW

ENGINE (DIAGNOSTICS)

## 2. CHECK LIST NO. 2

Check the following items about the vehicle's state when MI turns on.

NOTE:

Use copies of this page for interviewing customers.

a) Other warning lights or indicators turn on. <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<input type="checkbox"/> Low fuel warning light <input type="checkbox"/> Charge indicator light <input type="checkbox"/> AT diagnostics indicator light <input type="checkbox"/> ABS warning light <input type="checkbox"/> Engine oil pressure warning light
b) Fuel level
<ul style="list-style-type: none"><li>• Lack of gasoline: <input type="checkbox"/> Yes/<input type="checkbox"/> No</li><li>• Indicator position of fuel gauge:</li></ul>
c) Intentional connecting or disconnecting of harness connectors or spark plug cords: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li></ul>
d) Intentional connecting or disconnecting of hoses: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li></ul>
e) Installing of parts other than genuine parts: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li><li>• Where:</li></ul>
f) Occurrence of noise: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>
g) Occurrence of smell: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>
h) Intrusion of water into engine compartment or passenger compartment: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
i) Troubles occurred
<input type="checkbox"/> Engine does not start. <input type="checkbox"/> Engine stalls during idling. <input type="checkbox"/> Engine stalls while driving. <input type="checkbox"/> Engine speed decreases. <input type="checkbox"/> Engine speed does not decrease. <input type="checkbox"/> Rough idling <input type="checkbox"/> Poor acceleration <input type="checkbox"/> Back fire <input type="checkbox"/> After fire <input type="checkbox"/> No shift <input type="checkbox"/> Excessive shift shock

# GENERAL DESCRIPTION

## ENGINE (DIAGNOSTICS)

### 3. General Description

#### A: CAUTION

1) Airbag system wiring harness is routed near the engine control module (ECM), main relay and fuel pump relay.

#### CAUTION:

- All Airbag system wiring harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.
- Be careful not to damage the Airbag system wiring harness when servicing the engine control module (ECM), transmission control module (TCM), main relay and fuel pump relay.

2) Never connect the battery in reverse polarity.

- The ECM will be destroyed instantly.
- The fuel injector and other part will be damaged in just a few minutes more.

3) Do not disconnect the battery cables while the engine is running.

- A large counter electromotive force will be generated in the alternator, and this voltage may damage electronic parts such as ECM, etc.

4) Before disconnecting the connectors of each sensor and ECM, be sure to turn OFF the ignition switch.

5) Poor contact has been identified as a primary cause of this problem. To measure the voltage and/or resistance of individual sensors or all electrical control modules at the harness side connector, use a tapered pin with a diameter of less than 0.64 mm (0.025 in). Do not insert the pin more than 5 mm (0.20 in) into the part.

6) Before removing ECM from the located position, disconnect two cables on the battery.



- Otherwise, the ECM may be damaged.

#### CAUTION:

**When replacing ECM, be careful not to use the wrong spec. ECM to avoid any damage on fuel injection system.**


7) The connectors to each sensor in the engine compartment and the harness connectors on the engine side and body side are all designed to be waterproof. However, it is still necessary to take care not to allow water to get into the connectors when washing the vehicle, or when servicing the vehicle on a rainy day.

8) Use ECM or TCM mounting stud bolts at the body head grounding point when measuring the voltage and resistance inside the passenger compartment.



(A) Stud bolt

9) Use engine grounding terminal or engine proper as grounding point to the body when measuring the voltage and resistance in the engine compartment.



10) Every MFI-related part is a precision part. Do not drop them.



11) Observe the following cautions when installing a radio in MFI equipped models.

### CAUTION:

- The antenna must be kept as far apart as possible from the control unit.  
(The ECM is located under the steering column, inside of the instrument panel lower trim panel.)
- The antenna feeder must be placed as far apart as possible from the ECM and MFI harness.
- Carefully adjust the antenna for correct matching.
- When mounting a large power type radio, pay special attention to the three items above mentioned.
- Incorrect installation of the radio may affect the operation of ECM.

12) Before disconnecting the fuel hose, disconnect the fuel pump connector and crank the engine for more than five seconds to release pressure in the fuel system. If engine starts during this operation, run it until it stops.

13) Problems in the electronic-controlled automatic transmission may be caused by failure of the engine, the electronic control system, the transmission proper, or by a combination of these. These three causes must be distinguished clearly when performing diagnostics.

14) Diagnostics should be conducted by rotating with simple, easy operations and proceeding to complicated, difficult operations. The most important thing in diagnostics is to understand the customer's complaint, and distinguish between the three causes.

15) On ABS vehicle, when performing a driving test in jacked-up or lifted-up position, sometimes the warning light may be lit, but this is not a malfunction of the system. The reason for this is the speed difference between the front and rear wheels. After diagnosis of engine control system, perform the ABS memory clearance procedure of self-diagnosis system.

## B: INSPECTION

Before performing diagnostics, check the following items which might affect engine problems:

### 1. BATTERY

1) Measure the battery voltage and specific gravity of electrolyte.


**Standard voltage: 12 V**

**Specific gravity: Above 1.260**

2) Check the condition of the main and other fuses, and harnesses and connectors. Also check for proper grounding.

## 2. ENGINE GROUNDING

Make sure the engine grounding terminal is properly connected to the engine.



## C: NOTE

### 1. DESCRIPTION

- The on-board diagnostics (OBD) system detects and indicates a fault in various inputs and outputs of the complex electronic control. CHECK ENGINE malfunction indicator lamp (MI) in the combination meter indicates occurrence of a fault or trouble.
- Further, against such a failure or sensors as may disable the drive, the fail-safe function is provided to ensure the minimal driveability.

### 2. ENGINE AND EMISSION CONTROL SYSTEM

- The Multipoint Fuel Injection (MFI) system is a system that supplies the optimum air-fuel mixture to the engine for all the various operating conditions through the use of the latest electronic technology.

With this system fuel, which is pressurized at a constant pressure, is injected into the intake air passage of the cylinder head. The injection quantity of fuel is controlled by an intermittent injection system where the electro-magnetic injection valve (fuel injector) opens only for a short period of time, depending on the quantity of air required for one cycle of operation. In actual operation, the injection quantity is determined by the duration of an electric pulse applied to the fuel injector and this permits simple, yet highly precise metering of fuel.

- Further, all the operating conditions of the engine are converted into electric signals, and this results in additional features of the system, such as large improved adaptability, easier addition of compensating element, etc.

The MFI system also has the following features:

- Reduced emission of harmful exhaust gases.
- Reduced in fuel consumption.
- Increased engine output.
- Superior acceleration and deceleration.

## GENERAL DESCRIPTION

### ENGINE (DIAGNOSTICS)



- Superior startability and warm-up performance in cold weather since compensation is made for coolant and intake air temperature.

### 3. AUTOMATIC TRANSMISSION AND ELECTRONIC-HYDRAULIC CONTROL SYSTEM

The electronic-hydraulic control system consists of various sensors and switches, a transmission control module (TCM) and the hydraulic controller including solenoid valves. The system controls the

transmission proper including shift control, lock-up control, overrunning clutch control, line pressure control and shift timing control. It also controls the AWD transfer clutch. In other words, the system detects various operating conditions from various input signals and sends output signals to shift solenoids 1, 2 and low clutch timing solenoid and 2-4 brake timing solenoid, line pressure duty solenoid, lock-up duty solenoid, transfer duty solenoid and 2-4 brake duty solenoid (a total of eight solenoids).

### D: PREPARATION TOOL


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST24082AA210</p>	24082AA210 (Newly adopted tool)	CARTRIDGE	Troubleshooting for electrical systems.
 <p style="text-align: center;">ST22771AA030</p>	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems. <ul style="list-style-type: none"> <li>• English: 22771AA030 (Without printer)</li> <li>• German: 22771AA070 (Without printer)</li> <li>• French: 22771AA080 (Without printer)</li> <li>• Spanish: 22771AA090 (Without printer)</li> </ul>

## 4. Electrical Components Location





### A: LOCATION

#### 1. ENGINE

##### • MODULE




- (1) Engine control module (ECM)
- (2) CHECK ENGINE malfunction indicator lamp (MI)
- (3) Read memory connector
- (4) Test mode connector
- (5) Data link connector



# ELECTRICAL COMPONENTS LOCATION

## ENGINE (DIAGNOSTICS)









### • SENSOR



- |                                       |                                |   |
|---------------------------------------|--------------------------------|---|
| (1) Pressure sensor                   | (4) Knock sensor               | (7) Mass air flow and intake air temperature sensor |
| (2) Engine coolant temperature sensor | (5) Camshaft position sensor   | (8) Differential pressure sensor                    |
| (3) Throttle position sensor          | (6) Crankshaft position sensor |   |


# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)




# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)




EN-00967


- (1) Front oxygen (A/F) sensor
- (2) Front catalytic converter
- (3) Rear oxygen sensor
- (4) Rear catalytic converter




EN-00968



EN-00970



EN-00969




EN-00971

# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)

## • SOLENOID VALVE, ACTUATOR, EMISSION CONTROL SYSTEM PARTS AND IGNITION SYSTEM PARTS



EN-00972

(1) Solenoid box ASSY

(3) Purge control solenoid valve


(5) Fuel injector

(2) Idle air control solenoid valve

(4) Ignition coil

# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)



EN-00973

- (A) Relief valve control solenoid valve 2
- (B) Filter
- (C) Exhaust valve control duty solenoid valve





- (D) Relief valve control solenoid valve 1
- (E) Exhaust valve control solenoid valve (For negative pressure)
- (F) Intake air valve control solenoid valve

- (G) Exhaust valve control solenoid valve (For positive pressure)




# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)









# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)




- |                |                          |                                      |
|----------------|--------------------------|--------------------------------------|
| (1) Fuel pump  | (3) Fuel pump relay      | (5) Starter                          |
| (2) Main relay | (4) Fuel pump controller | (6) Wastegate control solenoid valve |



## 2. TRANSMISSION


### • MODULE




EN-00985

(1) Transmission Control Module (TCM) (for AT vehicles)

(2) AT diagnostic indicator light (for AT vehicles)



EN-00879




AT-00765

# ELECTRICAL COMPONENTS LOCATION

## ENGINE (DIAGNOSTICS)

### • SENSOR




- (1) Rear vehicle speed sensor (for AT vehicles)
- (2) Front vehicle speed sensor (for MT vehicles)
- (3) Front vehicle speed sensor (for AT vehicles)
- (4) Torque converter turbine speed sensor
- (5) ATF temperature sensor (for AT vehicles)
- (6) Brake light switch

# ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)

## • SOLENOID VALVE AND SWITCH (AT VEHICLES)



- (1) Dropping resistor
- (2) Inhibitor switch
- (3) Shift solenoid valve 1
- (4) Shift solenoid valve 2
- (5) Line pressure duty solenoid
- (6) Lock-up duty solenoid
- (7) Transfer duty solenoid
- (8) 2-4 brake duty solenoid
- (9) Low clutch timing solenoid valve
- (10) 2-4 brake timing solenoid valve

## • SOLENOID VALVE AND SWITCH (MT VEHICLES)




- (1) Neutral position switch

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

## 5. Engine Control Module (ECM) I/O Signal

### A: ELECTRICAL SPECIFICATION



EN-00997

Content		Con- nector No.	Termi- nal No.	Signal (V)		Note
				Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Crank- shaft position sensor	Signal (+)	B135	2	0	-7 — +7	Sensor output waveform
	Signal (-)	B135	11	0	0	—
	Shield	B135	21	0	0	—
Camshaft position sensor	Signal (+)	B135	1	0	-7 — +7	Sensor output waveform
	Signal (-)	B135	10	0	0	—
	Shield	B135	21	0	0	—
Throttle position sensor	Signal	B135	7	Fully closed: 0.2 — 1.0 Fully opened: 4.2 — 4.7		—
	Power supply	B135	9	5	5	—
	GND (sen- sor)	B135	19	0	0	—
Rear oxy- gen sen- sor	Signal	B135	17	0	0 — 0.9	—
	Shield	B135	26	0	0	—
	GND (sen- sor)	B135	19	0	0	—
Front oxy- gen (A/F) sensor heater	Signal 1	B137	4	0 — 1.0	0 — 1.0	—
	Signal 2	B137	5	0 — 1.0	0 — 1.0	—
Rear oxygen sensor heater signal		B136	13	0 — 1.0	0 — 1.0	—
Engine coolant tempera- ture sen- sor	Signal	B135	18	1.0 — 1.4	1.0 — 1.4	After warm-up the engine.
	GND (sen- sor)	B135	19	0	0	After warm-up the engine.
Vehicle speed signal		B134	1	0 or 5	0 or 5	"5" and "0" are repeatedly dis- played when the vehicle is driven.

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

Content		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Mass air flow sensor	Signal	B84	13	—	0.3 — 4.5	—
	Shield	B84	8	0	0	—
	GND	B84	7	0	0	—
Intake air temperature sensor signal		B135	27	—	—	—
Wastegate control solenoid valve		B137	24	10 — 13	13 — 14	—
Starter switch		B134	16	0	0	Cranking: 8 — 14
A/C switch		B134	6	ON: 10 — 13 OFF: 0	ON: 13 — 14 OFF: 0	—
Ignition switch		B134	14	10 — 13	13 — 14	—
Neutral position switch (MT)		B134	8	ON: 12±0.5 OFF: 0		Switch is ON when gear is in neutral position.
Neutral position switch (AT)		B134	8	ON: 0 OFF: 12±0.5		Switch is ON when shift is in "N" or "P" position.
Test mode connector		B134	5	5	5	When connected: 0
Knock sensor	Signal	B135	4	2.8	2.8	—
	Shield	B135	22	0	0	—
Back-up power supply		B137	10	10 — 13	13 — 14	Ignition switch "OFF": 10 — 13
Control unit power supply	B137	2	10 — 13	13 — 14	—	
	B137	3	10 — 13	13 — 14	—	
Sensor power supply		B135	9	5	5	—
Line end check		B134	10	0	0	—
Ignition control	#1	B136	24	0	13 — 14	Waveform
	#2	B136	23	0	13 — 14	Waveform
	#3	B136	22	0	13 — 14	Waveform
	#4	B136	21	0	13 — 14	Waveform
Fuel injector	#1	B137	1	10 — 13	1 — 14	Waveform
	#2	B136	6	10 — 13	1 — 14	Waveform
	#3	B136	5	10 — 13	1 — 14	Waveform
	#4	B136	4	10 — 13	1 — 14	Waveform
Idle air control solenoid valve	Signal	B136	10	0 or 13 — 14	0 or 13 — 14	Waveform
Fuel pump controller	Signal 1	B134	13	—	—	—
	Signal 2	B136	16	—	—	—
A/C relay control		B137	27	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—
Radiator fan relay 1 control		B137	17	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—
Radiator fan relay 2 control		B137	28	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	With A/C vehicles only
Malfunction indicator lamp		B137	15	—	—	Light "ON": 1, or less Light "OFF": 10 — 14
Engine speed output		B136	9	—	0 — 13, or more	Waveform
Torque control signal 1		B134	19	5	5	—
Torque control signal 2		B134	18	5	5	—
Torque control cut signal		B136	14	8	8	—
Purge control solenoid valve		B137	16	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

## ENGINE (DIAGNOSTICS)

Content		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Pressure sensor	Signal	B135	8	1.7 — 2.4	1.1 — 1.6	—
	Power supply	B135	9	5	5	
	GND (sensor)	B135	19	0	0	
Small light switch		B134	17	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Blower fan switch		B134	9	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Rear defogger switch		B134	3	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Power steering oil pressure switch		B135	24	10 — 13	ON: 0 OFF: 13 — 14	—
Front oxygen (A/F) sensor signal (+)		B137	19	2.8 — 3.2	2.8 — 3.2	—
Front oxygen (A/F) sensor signal (-)		B137	29	2.4 — 2.7	2.4 — 2.7	—
Front oxygen (A/F) sensor shield		B137	18	0	0	—
SSM/GST communication line		B134	21	Less than 1 ↔ More than 4	Less than 1 ↔ More than 4	—
GND (sensors)		B135	19	0	0	—
GND (injectors)		B136	8	0	0	—
GND (ignition system)		B136	18	0	0	—
GND (power supply)		B136	17	0	0	—
		B134	22	0	0	—
GND (control systems)		B134	7	0	0	—
		B134	15	0	0	—
GND (oxygen sensor heater 1)		B137	9	0	0	—
GND (oxygen sensor heater 2)		B137	8	0	0	—
Differential pressure sensor signal		B135	15	2	2	—
Relief valve control solenoid valve 2 signal		B136	11	10 — 13	13 — 14	—
Relief valve control solenoid valve 1 signal		B136	12	10 — 13	13 — 14	—
Exhaust valve control solenoid valve (negative pressure) signal		B136	3	10 — 13	13 — 14	—
Exhaust valve control solenoid valve (positive pressure) signal		B136	1	10 — 13	13 — 14	—
Intake air valve control solenoid valve signal		B137	12	10 — 13	13 — 14	—
Exhaust valve control duty solenoid valve		B137	11	10 — 13	13 — 14	—



## 6. Engine Condition Data

### A: ELECTRICAL SPECIFICATION

Content	Specified data
Engine load	1.6 — 2.9 (%): Idling
	6.4 — 12.8 (%): 2,500 rpm racing

Measuring condition:

- After engine is warmed-up.
- Gear position is in neutral position.
- A/C is turned OFF.
- All accessory switches are turned OFF.

# TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

---

## 7. Transmission Control Module (TCM) I/O Signal

### A: ELECTRICAL SPECIFICATION

<Ref. to AT-14, Transmission Control Module (TCM) I/O Signal.>


## 8. Data Link Connector

### A: NOTE

- 1) This connector is used both for OBD-II general scan tools and the Subaru Select Monitor.
- 2) Terminal No. 4 to No. 6 of the data link connector is used for the Subaru Select Monitor signal.

### CAUTION:

**Do not connect any scan tools other than the OBD-II general scan tools and Subaru Select Monitor, because the circuit for the Subaru Select Monitor may be damaged.**



Terminal No.	Contents	Terminal No.	Contents
1	Power supply	9	Blank
2	Blank	10	K line of ISO 9141 CARB
3	Blank	11	Blank
4	Blank	12	Ground
5	Blank	13	Ground
6	Flash write	14	Blank
7	Blank	15	Blank
8	Blank	16	Blank

# SUBARU SELECT MONITOR


ENGINE (DIAGNOSTICS)

## 9. Subaru Select Monitor

### A: OPERATION


#### 1. HOW TO USE SUBARU SELECT MONITOR

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4DOSTC)-8, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.

3) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(H4DOSTC)-8, PREPARATION TOOL, General Description.>



4) Connect the Subaru Select Monitor to data link connector.

(1) Data link connector located in the lower portion of the instrument panel (on the driver's side).




(2) Connect the diagnosis cable to data link connector.

#### CAUTION:

**Do not connect scan tools except for the Subaru Select Monitor and OBD-II general scan tool.**

5) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

6) Using the Subaru Select Monitor, call up the diagnostic trouble code(s) and various data, then record them.

#### 2. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE. (NORMAL MODE)

Refer to Read Diagnostic Trouble Code for information about how to indicate DTC. <Ref. to EN(H4DOSTC)-32, Read Diagnostic Trouble Code.>

#### 3. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE. (OBD MODE)

Refer to Read Diagnostic Trouble Code for information about how to indicate DTC. <Ref. to EN(H4DOSTC)-32, Read Diagnostic Trouble Code.>

## 4. READ CURRENT DATA FOR ENGINE. (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display & Save} and press [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data Display} and press [YES] key.
  - 6) Using the scroll key, move the display screen up or down until desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Battery voltage	Battery Voltage	V
Vehicle speed signal	Vehicle Speed	km/h or MPH
Engine speed signal	Engine Speed	rpm
Engine coolant temperature signal	Coolant Temp.	°C or °F
Ignition timing signal	Ignition Timing	deg
Throttle position signal	Throttle Opening Angle	%
Throttle position signal	Throttle Sensor Voltage	V
Injection pulse width	Fuel Injection #1 Pulse	ms
Idle air control signal	ISC Valve Duty Ratio	%
Alternator duty control signal	ALT Duty	%
Fuel pump duty control signal	Fuel Pump Duty	%
A/F sensor resistance	A/F Sensor #1 Resistance	Ω
Front oxygen (A/F) sensor output signal	A/F Sensor Output Lamda 1	—
Rear oxygen sensor output signal	Rear O2 Sensor	V
Short term fuel trim	A/F Correction #1	%
Knock sensor signal	Knocking Signal	deg
Atmospheric absolute pressure signal	Atmosphere Pressure	mmHg or kPa or inHg or psig
Intake manifold relative pressure signal	Mani. Relative Pressure	mmHg or kPa or inHg or psig
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg or kPa or inHg or psig
A/F correction (short term fuel trim) by rear oxygen sensor	A/F Correction #3	%
Long term whole fuel trim	A/F Learning #1	%
Front oxygen (A/F) sensor heater current	A/F Heater Current 1	A
Rear oxygen sensor heater voltage	Rear O2 Heater Voltage	V
Canister purge control solenoid valve duty ratio	CPC Valve Duty Ratio	%
Primary supercharged pressure control signal	Primary Control	%
Secondary supercharged pressure control signal	Secondary control	%
Differential pressure sensor signal	Diff. Press. Sen. Vol.	V
Differential pressure sensor signal	Pressure Diff. Sensor	mmHg or kPa or inHg or psig
Intake air temperature signal	Intake Air Temp.	°C or °F
Mass air flow sensor signal	Mass Air Flow	g/s
Mass air flow sensor signal	Air Flow Sensor Voltage	V
Ignition switch signal	Ignition Switch	ON or OFF
Test mode connector signal	Test Mode Signal	ON or OFF
Neutral position switch signal	Neutral Position Switch	ON or OFF
Air conditioning switch signal	A/C Switch	ON or OFF
Air conditioning signal	A/C Compressor Signal	ON or OFF
Radiator main fan relay signal	Radiator Fan Relay #1	ON or OFF
Knocking signal	Knocking Signal	ON or OFF
Radiator sub fan relay signal	Radiator Fan Relay #2	ON or OFF

# SUBARU SELECT MONITOR

## ENGINE (DIAGNOSTICS)

Contents	Display	Unit of measure
Power steering switch signal	P/S Switch	ON or OFF
Rear oxygen sensor rich signal	Rear O2 Rich Signal	ON or OFF
Starter switch signal	Starter Switch	ON or OFF
Idle switch signal	Idle Switch Signal	ON or OFF
Crankshaft position sensor signal	Crankshaft Position Sig.	ON or OFF
Camshaft position sensor signal	Camshaft Position Sig.	ON or OFF
Rear defogger switch signal	Rear Defogger SW	ON or OFF
Blower fan switch signal	Blower Fan SW	ON or OFF
Small light switch signal	Light Switch	ON or OFF
Supercharged pressure relief valve solenoid 1 signal	Relief Valve Solenoid 1	ON or OFF
Supercharged pressure relief valve solenoid 2 signal	Relief Valve Solenoid 2	ON or OFF
Exhaust gas positive pressure signal	Ex. Gas Pos. Pressure	ON or OFF
Exhaust gas negative pressure signal	Ex. Gas Neg. Pressure	ON or OFF
Read memory connector signal	Read Memory Signal	ON or OFF
MT/AT identification signal	AT Vehicle ID Signal	ON or OFF
TCS relief valve solenoid signal	TCS Relief Valve Sol.	ON or OFF
Engine torque control signal #1	Torque Control Signal #1	ON or OFF
Engine torque control signal #2	Torque Control Signal #2	ON or OFF
Engine torque control permission signal	Torque Permission Signal	ON or OFF

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

### 5. READ CURRENT DATA FOR ENGINE. (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press [YES] key.
  - 5) On the «OBD Menu» display screen, select the {Current Data Display & Save} and press [YES] key.
  - 6) On the «Data Display Menu» display screen, select the {Data Display} and press [YES] key.
  - 7) Using the scroll key, move the display screen up or down until desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Number of diagnosis code	Number of Diagnosis Code	—
Malfunction indicator lamp status	MI (MI)	Complete or incomplete
Monitoring test of misfire	Misfire monitoring	No support
Monitoring test of fuel system	Fuel system monitoring	Complete or incomplete
Monitoring test of comprehensive component	Component monitoring	Complete or incomplete
Test of catalyst	Catalyst Diagnosis	No support
Test of heated catalyst	Heated catalyst	No support
Test of evaporative emission purge control system	Evaporative purge system	No support
Test of secondary air system	Secondary air system	No support
Test of air conditioning system refrigerant	A/C system refrigerant	No support
Test of oxygen sensor	Oxygen sensor	Complete or incomplete
Test of oxygen sensor heater	O2 Heater Diagnosis	Complete or incomplete
Test of EGR system	EGR system	No support

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

## 6. READ FREEZE FRAME DATA FOR ENGINE. (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press [YES] key.
  - 5) On the «OBD Menu» display screen, select the {Freeze Frame Data} and press [YES] key.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Diagnostic trouble code (DTC) for freeze frame data	Freeze frame data	DTC
Air fuel ratio control system for bank 1	Fuel system for Bank1	ON or OFF
Engine load data	Engine Load	%
Engine coolant temperature signal	Coolant Temp.	°C or °F
Short term fuel trim by front oxygen (A/F) sensor	Short term fuel trim B1	%
Long term fuel trim by front oxygen (A/F) sensor	Long term fuel trim B1	%
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg or kPa or inHg or psig
Engine speed signal	Engine Speed	rpm
Vehicle speed signal	Vehicle Speed	km/h or MPH

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

## 7. LED OPERATION MODE FOR ENGINE

- 1) On the «Main Menu» display screen, select the {Each System Check} and press [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display & Save} and press [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data & LED Display} and press [YES] key.
  - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Message	LED "ON" requirements
Ignition switch signal	Ignition Switch	ON or OFF	When ignition switch is turned ON.
Test mode connector signal	Test Mode Signal	ON or OFF	When test mode connector is connected.
Neutral position switch signal	Neutral SW	ON or OFF	When neutral position signal is entered.
Air conditioning switch signal	A/C SW	ON or OFF	When air conditioning switch is turned ON.
Air conditioning relay signal	A/C Relay	ON or OFF	When air conditioning relay is in function.
Radiator main fan relay signal	Radiator Fan Relay #1	ON or OFF	When radiator main fan relay is in function.
Knocking signal	Knocking Signal	ON or OFF	When knocking signal is entered.
Radiator sub fan relay signal	Radiator Fan Relay #2	ON or OFF	When radiator sub fan relay is in function.
Engine torque control signal #1	Torque Control Signal #1	ON or OFF	When engine torque control signal 1 is entered.
Engine torque control signal #2	Torque Control Signal #2	ON or OFF	When engine torque control signal 2 is entered.
Engine torque control permission signal	Torque Control Permit	ON or OFF	When engine torque control permission signal is entered.
Rear oxygen sensor rich signal	Rear O2 Rich Signal	ON or OFF	When rear oxygen sensor mixture ratio is rich.
Starter switch signal	Starter Switch Signal	ON or OFF	When starter switch signal is entered.
Idle switch signal	Idle Switch Signal	ON or OFF	When idle switch signal is entered.
Crankshaft position sensor signal	Crankshaft Position Sig.	ON or OFF	When crankshaft position sensor signal is entered.

# SUBARU SELECT MONITOR

## ENGINE (DIAGNOSTICS)

Contents	Display	Message	LED "ON" requirements
Camshaft position sensor signal	Camshaft Position Sig.	ON or OFF	When camshaft position sensor signal is entered.
Power steering switch signal	P/S SW	ON or OFF	When power steering switch is entered.
Rear defogger switch signal	Rear Defogger SW	ON or OFF	When rear defogger switch is turned ON.
Blower fan switch signal	Blower Fan SW	ON or OFF	When blower fan switch is turned ON.
Light switch signal	Light SW	ON or OFF	When small light switch is turned ON.

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

### 8. READ CURRENT DATA FOR AT.

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Transmission Control System} and press the [YES] key.
  - 3) Press the [YES] key after displayed the information of transmission type.
  - 4) On the «Transmission Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
  - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Battery voltage	Battery Voltage	V
Rear vehicle speed sensor signal	Vehicle Speed #1	km/h or MPH
Front vehicle speed sensor signal	Vehicle Speed #2	km/h or MPH
Engine speed signal	Engine Speed	rpm
Automatic transmission fluid temperature signal	ATF Temp.	°C or °F
Throttle position signal	Throttle Sensor Voltage	V
Gear position	Gear Position	—
Line pressure control duty ratio	Line Pressure Duty Ratio	%
Lock up clutch control duty ratio	Lock Up Duty Ratio	%
Transfer clutch control duty ratio	Transfer Duty Ratio	%
Power supply for throttle position sensor	Throttle Sensor Power	V
Torque converter turbine speed signal	AT Turbine Speed	rpm
2-4 brake timing pressure control duty ratio	2-4B Duty Ratio	%
Intake manifold pressure sensor voltage	Mani. Pressure Voltage	V
2 wheel drive switch signal	2WD Switch	ON or OFF
Stop lamp switch signal	Stop Lamp Switch	ON or OFF
Anti lock brake system signal	ABS Signal	ON or OFF
Cruise control system signal	Cruise Control Signal	ON or OFF
Neutral/Parking range signal	N/P Range Signal	ON or OFF
Reverse range signal	R Range Signal	ON or OFF
Drive range signal	D Range Signal	ON or OFF
3rd range signal	3rd Range Signal	ON or OFF
2nd range signal	2nd Range Signal	ON or OFF
1st range signal	1st Range Signal	ON or OFF
Shift control solenoid A	Shift Solenoid #1	ON or OFF
Shift control solenoid B	Shift Solenoid #2	ON or OFF
Torque control output signal #1	Torque Control Signal #1	ON or OFF
Torque control output signal #2	Torque Control Signal #2	ON or OFF
Torque control cut signal	Torque Control Cut Sig.	ON or OFF
2-4 brake timing control solenoid valve	2-4 Brake Timing Sol.	ON or OFF
Low clutch timing control solenoid valve	Low Clutch Timing Sol.	ON or OFF



# SUBARU SELECT MONITOR

ENGINE (DIAGNOSTICS)

Contents	Display	Unit of measure
Automatic transmission diagnosis indicator lamp	AT Diagnosis Lamp	ON or OFF

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

For select monitor display details, refer to the following.

### 10. Read Diagnostic Trouble Code

#### A: OPERATION

##### 1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {Diagnostic Code(s) Display} and press [YES] key.
- 5) On the «Diagnostic Code(s) Display» display screen, select the {Current Diagnostic Code(s)} or {History Diagnostic Code(s)} and press [YES] key.

##### NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>

##### 2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press [YES] key.
- 5) On the «OBD Menu» display screen, select the {Diagnosis Code(s) Display} and press [YES] key.
- 6) Make sure that a diagnostic trouble code (DTC) is shown on the display screen.

##### NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>

## 11. Inspection Mode


### A: OPERATION

#### 1. PREPARATION FOR THE INSPECTION MODE

Raise the vehicle using a garage jack and place on safety stands or drive the vehicle onto free rollers.

**WARNING:**

- Before raising the vehicle, ensure parking brakes are applied.
- Do not use a pantograph jack in place of a safety stand.
- Secure a rope or wire to the front and rear towing or tie-down hooks to prevent the lateral runout of front wheels.
- Do not abruptly depress/release clutch pedal or accelerator pedal during works even when engine is operating at low speeds since this may cause vehicle to jump off free rollers.
- In order to prevent the vehicle from slipping due to vibration, do not place any wooden blocks or similar items between the safety stands and the vehicle.
- Since the rear wheels will also rotate, do not place anything near them. Also, make sure that nobody goes in front of the vehicle.




- (A) Safety stand
- (B) Free rollers


#### 2. SUBARU SELECT MONITOR

After performing diagnostics and clearing the memory, check for any remaining unresolved trouble data.


- 1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4DOSTC)-8, PREPARATION TOOL, General Description.>



- 2) Connect the diagnosis cable to Subaru Select Monitor.
- 3) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(H4DOSTC)-8, PREPARATION TOOL, General Description.>



- 4) Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of center console box.




# INSPECTION MODE

## ENGINE (DIAGNOSTICS)

5) Connect the Subaru Select Monitor to data link connector.

(1) Connect the Subaru Select Monitor to data link connector located in the lower portion of instrument panel (on the driver's side).




(2) Connect the diagnosis cable to data link connector.

### CAUTION:

**Do not connect scan tools except for the Subaru Select Monitor and OBD-II general scan tool.**

6) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

7) On the «Main Menu» display screen, select the {2. Each System Check} and press [YES] key.

8) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.

9) Press the [YES] key after displayed the information of engine type.

10) On the «Engine Diagnosis» display screen, select the {Dealer Check Mode Procedure} and press [YES] key.

11) When the "Perform Inspection (Dealer Check) Mode?" is shown on the display screen, press [YES] key.

12) Perform subsequent procedures as instructed on the display screen.

• If trouble still remains in the memory, the corresponding diagnostic trouble code (DTC) appears on the display screen.

### NOTE:

• For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

• For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>

• Release the parking brake.

• The speed difference between front and rear wheels may light either the ABS warning light, but this indicates no malfunctions. When engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

## 12. Clear Memory Mode

### A: OPERATION

#### 1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {Clear Memory} and press [YES] key.
- 5) When the 'Done' and 'Turn Ignition Switch OFF' are shown on the display screen, turn the Subaru Select Monitor and ignition switch to OFF.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

#### 2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press [YES] key.
- 5) On the «OBD Menu» display screen, select the {4. Diagnosis Code(s) Cleared} and press [YES] key.
- 6) When the 'Clear Diagnostic Code?' is shown on the display screen, press [YES] key.
- 7) Turn the Subaru Select Monitor and ignition switch to OFF.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.


# COMPULSORY VALVE OPERATION CHECK MODE

ENGINE (DIAGNOSTICS)

## 13. Compulsory Valve Operation Check Mode


### A: OPERATION

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4DOSTC)-8, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.

3) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(H4DOSTC)-8, PREPARATION TOOL, General Description.>




4) Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of center console box.



5) Connect the Subaru Select Monitor to data link connector.

(1) Connect the Subaru Select Monitor to data link connector located in the lower portion of the instrument panel (on the driver's side).




(2) Connect the diagnosis cable to data link connector.

### CAUTION:

**Do not connect scan tools except for the Subaru Select Monitor and OBD-II general scan tool.**

6) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

7) On the «Main Menu» display screen, select the {2. Each System Check} and press [YES] key.

8) On the «System Selection Menu» display screen, select the {Engine Control System} and press [YES] key.

9) Press the [YES] key after displayed the information of engine type.

10) On the «Engine Diagnosis» display screen, select the {System Operation Check Mode} and press [YES] key.

11) On the «System Operation Check Mode» display screen, select the {Actuator ON/OFF Operation} and press [YES] key.

12) Select the desired compulsory actuator on the «Actuator ON/OFF Operation» display screen and press [YES] key.

# COMPULSORY VALVE OPERATION CHECK MODE

ENGINE (DIAGNOSTICS)

13) Pressing the [NO] key completes the compulsory operation check mode. The display will then return to the «Actuator ON/OFF Operation» screen.

- A list of the support data is shown in the following table.

Contents	Display
Compulsory fuel pump relay operation check	Fuel Pump Relay
Compulsory radiator fan relay operation check	Radiator Fan Relay
Compulsory air conditioning relay operation check	A/C Compressor Relay
Compulsory purge control solenoid valve operation check	CPC Solenoid Valve
Compulsory relief valve control solenoid valve operation check	—
Compulsory exhaust valve control solenoid valve operation check	—
Compulsory intake air control solenoid valve operation check	—

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

## 14.Engine Malfunction Indicator Lamp (MI)

### A: PROCEDURE

1. Activation of check engine malfunction indicator lamp (MI). <Ref. to EN(H4DOSTC)-39, ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI), Engine Malfunction Indicator Lamp (MI).>
↓
2. Check that engine malfunction indicator lamp (MI) does not come on. <Ref. to EN(H4DOSTC)-40, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MI).>
↓
3. Check that engine malfunction indicator lamp (MI) does not go off. <Ref. to EN(H4DOSTC)-44, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT GO OFF., Engine Malfunction Indicator Lamp (MI).>
↓
4. Check that engine malfunction indicator lamp (MI) does not blink at a cycle of 3 Hz. <Ref. to EN(H4DOSTC)-46, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT BLINK AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MI).>
↓
5. Check that engine malfunction indicator lamp (MI) remains blinking at a cycle of 3 Hz. <Ref. to EN(H4DOSTC)-48, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) REMAINS BLINKING AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MI).>



# ENGINE MALFUNCTION INDICATOR LAMP (MI)


ENGINE (DIAGNOSTICS)

## B: ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI)


1) When the ignition switch is turned to ON (engine OFF), the CHECK ENGINE malfunction indicator lamp (MI) in the combination meter illuminates.

### NOTE:


If the MI does not illuminate, perform diagnostics of the CHECK ENGINE light circuit or the combination meter circuit. <Ref. to EN(H4DOSTC)-40, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MI).>




2) After starting the engine, the MI goes out. If it does not, either the engine or emission control system is malfunctioning.



3) If the diagnosis system senses a misfire which could damage the catalyzer, the MI will blink at a cycle of 1 Hz.



4) When the ignition switch is turned to ON (engine OFF) or to "START" with the test mode connector connected, the MI blinks at a cycle of 3 Hz.




# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

## C: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT COME ON.

- **DIAGNOSIS:**
  - The CHECK ENGINE malfunction indicator lamp (MI) circuit is open or shorted.
- **TROUBLE SYMPTOM:**
  - When the ignition switch is turned ON (engine OFF), the MI does not come on.
- **WIRING DIAGRAM:**



EN-00928

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 15 (+) — Chassis ground (-):</b> Is the measured value less than the specified value?	1 V	Go to step 4.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b> Does the MI come on when shaking or pulling ECM connector and harness?	MI illuminates.	Repair the poor contact in ECM connector.	Go to step 3.
<b>3 CHECK ECM CONNECTOR.</b> Is the ECM connector correctly connected?	Connected.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Repair the connection of ECM connector.
<b>4 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Remove the combination meter. <Ref. to IDI-15, Combination Meter Assembly.> 3) Disconnect the connector from ECM and combination meter. 4) Measure the resistance of harness between ECM and combination meter connector. <b>Connector &amp; terminal</b> <b>(B137) No. 15 — (i11) No. 10:</b> Is the measured value less than the specified value?	1 $\Omega$	Go to step 5.	Repair the harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and combination meter connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>5 CHECK POOR CONTACT.</b> Check poor contact in combination meter connector. Is there poor contact in combination meter connector?	There is poor contact.	Repair the poor contact in combination meter connector.	Go to step 6.

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>6</b>      <b>CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON. 2) Measure the voltage between combination meter connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <i>(i10) No. 8 (+) — Chassis ground (-):</i> <i>(i11) No. 5 (+) — Chassis ground (-):</i></p> <p>Does the measured value exceed the specified value?</p>	10 V	Go to step 7.	<p>Check the following and repair if necessary.</p> <p><b>NOTE:</b></p> <ul style="list-style-type: none"> <li>• Broken down ignition relay.</li> <li>• Blown out fuse (No. 5).</li> <li>• If replaced fuse (No. 5) blows easily, check the harness for short circuit of harness between fuse (No. 5) and ignition relay connector.</li> <li>• Open or short circuit in harness between fuse (No. 5) and battery terminal</li> <li>• Open circuit in harness between fuse (No. 5) and ignition relay connector</li> <li>• Poor contact in ignition relay connector</li> <li>• Poor contact in ignition switch connector</li> </ul>
<p><b>7</b>      <b>CHECK LAMP BULB.</b></p> <p>Remove the engine malfunction indicator lamp bulb.</p> <p>Is the lamp bulb condition OK?</p>	OK	Repair the combination meter connector.	Replace the lamp bulb.

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

---

**MEMO:**

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

## ENGINE (DIAGNOSTICS)

### D: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT GO OFF.


**DIAGNOSIS:**

- The CHECK ENGINE malfunction indicator lamp (MI) circuit is shorted.

**TROUBLE SYMPTOM:**

- Although MI comes on when the engine runs, trouble code is not shown on the Subaru select monitor or OBD-II general scan tool display.

**WIRING DIAGRAM:**



EN-00928

Step	Value	Yes	No
<b>1 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Turn the ignition switch to ON. Does the MI come on?	MI illuminates.	Repair the short circuit in harness between combination meter and ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

---

MEMO:

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

## E: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT BLINK AT A CYCLE OF 3 HZ.



### • DIAGNOSIS:

- The CHECK ENGINE malfunction indicator lamp (MI) circuit is open or shorted.
- Test mode connector circuit is in open.

### • TROUBLE SYMPTOM:

- When in inspection mode, the MI does not blink at a cycle of 3 Hz.

### • WIRING DIAGRAM:



EN-00929



# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)



Step	Value	Yes	No
<b>1 CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI).</b> 1) Turn the ignition switch to OFF. 2) Disconnect the test mode connector. 3) Turn the ignition switch to ON. (engine OFF) Does the MI come on?	MI illuminates.	Go to step 2.	Repair the MI circuit. <Ref. to EN(H4DOSTC)-40, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MI).>
<b>2 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Turn the ignition switch to ON. Does the MI come on?	MI illuminates.	Repair the ground short circuit in harness between combination meter and ECM connector.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN TEST MODE CONNECTOR AND CHASSIS GROUND.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between test mode connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B76) No. 1 — Chassis ground:</b> Is the measured value less than the specified value?	1 Ω	Go to step 4.	Repair the harness and connector.  <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between test mode connector and chassis ground
<b>4 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Go to step 5.
<b>5 CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR.</b> 1) Connect the test mode connector. 2) Measure the resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 5 — Chassis ground:</b> Is the measured value less than the specified value?	1 Ω	Go to step 6.	Repair the open circuit in harness between ECM and test mode connector.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

## F: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) REMAINS BLINKING AT A CYCLE OF 3 HZ.

- **DIAGNOSIS:**
  - Test mode connector circuit is shorted.
- **TROUBLE SYMPTOM:**
  - MI blinks at a cycle of 3 Hz when the ignition switch is turned to ON.
- **WIRING DIAGRAM:**



EN-00929

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1</b> <b>CHECK TEST MODE CONNECTOR.</b> 1) Disconnect the test mode connector. 2) Turn the ignition switch to ON. Does the MI flash on and off?	MI flashes.	Go to step 2.	System is in good order. <b>NOTE:</b> MI blinks at a cycle of 3 Hz when test mode connector is connected.
<b>2</b> <b>CHECK HARNESS BETWEEN ECM CONNECTOR AND ENGINE GROUNDING TERMINAL.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 5 — Chassis ground:</b> Does the measured value exceed the specified value?	1 M $\Omega$	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Repair the short circuit in harness between ECM and test mode connector.

# ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

---

**MEMO:**

## 15. Diagnostics for Engine Starting Failure

### A: PROCEDURE

1. Inspection of starter motor circuit. <Ref. to EN(H4DOSTC)-52, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
2. Inspection of ECM power supply and ground line. <Ref. to EN(H4DOSTC)-56, CONTROL MODULE POWER SUPPLY AND GROUND LINE, Diagnostics for Engine Starting Failure.>
↓
3. Inspection of fuel pump circuit. <Ref. to EN(H4DOSTC)-60, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

## B: STARTER MOTOR CIRCUIT

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H4DOSTC)-35, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• WIRING DIAGRAM:



EN-00930

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK OPERATION OF STARTER MOTOR.</b> Does the starter motor operate when the switch starts?	Operates.	Go to step 2.	Go to step 3.
<b>2 CHECK DTC.</b> Is DTC displayed?	DTC is indicated.	Check DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>	Repair poor contact in ECM connector.
<b>3 CHECK INPUT SIGNAL FOR STARTER MOTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from starter motor. 3) Turn the ignition switch to ST. 4) Measure the power supply voltage between starter motor connector terminal and engine ground.  <b>Connector &amp; terminal</b> <b>(B14) No. 1 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?  NOTE: On AT vehicles, place the selector lever in the "P" or "N" position.	10 V	Go to step 4.	Go to step 5.
<b>4 CHECK GROUND CIRCUIT OF STARTER MOTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the terminal from starter motor. 3) Measure the resistance of ground cable between ground cable terminal and engine ground. Is the measured value less than the specified value?	5 Ω	Check the starter motor. <Ref. to SC(H4DOSTC)-6, Starter.>	Repair the open circuit of ground cable.
<b>5 CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ignition switch. 3) Measure the power supply voltage between ignition switch connector and chassis ground.  <b>Connector &amp; terminal</b> <b>(B72) No. 1 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 6.	Repair the open circuit in harness between ignition switch and battery, and check fuse SBF No. 4 and SBF No. 1.
<b>6 CHECK IGNITION SWITCH.</b> 1) Disconnect the connector from ignition switch. 2) Measure the resistance between ignition switch terminals while turning ignition switch to the "ST" position.  <b>Terminals</b> <b>No. 1 — No. 3:</b> Is the measured value less than specified value?	5 Ω	Go to step 7.	Replace the ignition switch.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>7</b> <b>CHECK TRANSMISSION TYPE.</b> Is the target AT vehicle?	Target is AT vehicle.	Go to step <b>8</b> .	Repair open or ground short circuit in harness between starter motor and ignition switch.
<b>8</b> <b>CHECK INPUT VOLTAGE OF INHIBITOR SWITCH.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from inhibitor switch. 3) Connect the connector to ignition switch. 4) Measure the input voltage between inhibitor switch connector terminal and engine ground while turning ignition switch to ST. <b>Connector &amp; terminal</b> <b>(B12) No. 12 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step <b>9</b> .	Repair open or ground short circuit in harness between inhibitor switch and ignition switch.
<b>9</b> <b>CHECK INHIBITOR SWITCH.</b> 1) Place the selector lever in the “P” or “N” position. 2) Measure the resistance between inhibitor switch terminals. <b>Connector &amp; terminal</b> <b>(T3) No. 11 — No. 12:</b> Is the measured value less than specified value?	1 $\Omega$	Repair open or ground short circuit in harness between inhibitor switch and starter motor.	Replace the inhibitor switch. <Ref. to AT-50, REMOVAL, Inhibitor Switch.>



# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

---

MEMO:

# DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

## C: CONTROL MODULE POWER SUPPLY AND GROUND LINE

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H4DOSTC)-35, Clear Memory Mode.> and INSPECTION MODE. <Ref. to EN(H4DOSTC)-33, Inspection Mode.>

### • WIRING DIAGRAM:



EN-00931

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CHECK MAIN RELAY.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Remove the main relay.                      3) Connect the battery to main relay terminals No. 1 and No. 2.                      4) Measure the resistance between main relay terminals.</p> <p><b>Terminals</b>  <b>No. 3 — No. 5:</b>  <b>No. 4 — No. 6:</b></p> <p>Is the measured value less than the specified value?</p>	10 Ω	Go to step 2.	Replace the main relay.
<p><b>2 CHECK GROUND CIRCUIT OF ECM.</b></p> <p>1) Disconnect the connector from ECM.                      2) Measure the resistance of harness between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B134) No. 7 — Chassis ground:</b>  <b>(B134) No. 12 — Chassis ground:</b>  <b>(B134) No. 15 — Chassis ground:</b>  <b>(B134) No. 22 — Chassis ground:</b>  <b>(B136) No. 8 — Chassis ground:</b>  <b>(B136) No. 17 — Chassis ground:</b>  <b>(B136) No. 18 — Chassis ground:</b>  <b>(B137) No. 8 — Chassis ground:</b>  <b>(B137) No. 9 — Chassis ground:</b>  <b>(B84) No. 1 — Chassis ground:</b></p> <p>Is the measured value less than the specified value?</p>	5 Ω	Go to step 3.	Repair the open circuit in harness between ECM connector and engine grounding terminal.
<p><b>3 CHECK INPUT VOLTAGE OF ECM.</b></p> <p>Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 10 (+) — Chassis ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	Go to step 4.	Repair the open or ground short circuit of power supply circuit.
<p><b>4 CHECK INPUT VOLTAGE OF ECM.</b></p> <p>1) Turn the ignition switch to ON.                      2) Measure the resistance between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B134) No. 14 (+) — Chassis ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	Go to step 5.	Repair the open or ground short circuit of power supply circuit.
<p><b>5 CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Measure resistance between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B134) No. 2 — Chassis ground:</b></p> <p>Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 6.	Repair ground short circuit in harness between ECM connector and main relay connector.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6 CHECK OUTPUT VOLTAGE FROM ECM.</b> 1) Connect the connector to ECM. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 2 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 7.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<b>7 CHECK INPUT VOLTAGE OF MAIN RELAY.</b> Check the voltage between main relay connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B47) No. 2 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 8.	Repair the open circuit in harness between ECM connector and main relay connector.
<b>8 CHECK GROUND CIRCUIT OF MAIN RELAY.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between main relay connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B47) No. 1 — Chassis ground:</b> Is the measured value less than the specified value?	5 Ω	Go to step 9.	Repair the open circuit between main relay and chassis ground.
<b>9 CHECK INPUT VOLTAGE OF MAIN RELAY.</b> Measure the voltage between main relay connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B47) No. 5 (+) — Chassis ground (-):</b> <b>(B47) No. 6 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 10.	Repair the open or ground short circuit in harness of power supply circuit.
<b>10 CHECK INPUT VOLTAGE OF ECM.</b> 1) Connect the main relay connector. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 2 (+) — Chassis ground (-):</b> <b>(B137) No. 3 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Check the fuel pump circuit. <Ref. to EN(H4DOSTC)-60, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>	Repair the open or ground short circuit in harness between ECM connector and main relay connector.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

---

MEMO:

# DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

## D: FUEL PUMP CIRCUIT

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H4DOSTC)-35, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00932

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>     <b>CHECK OPERATING SOUND OF FUEL PUMP.</b> Make sure that the fuel pump is in operation for 2 seconds when turning ignition switch to ON. Does the fuel pump produce operating sound?  NOTE: Fuel pump operation can also be executed using the Subaru Select Monitor (Function mode: FD01). For the procedure, refer to "Compulsory Valve Operation Check Mode". &lt;Ref. to EN(H4DOSTC)-36, Compulsory Valve Operation Check Mode.&gt;</p>	Operating sound produced.	Go to step 2.	Record the DTC. Repair the trouble case. <Ref. to EN(H4DOSTC)-66, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
<p><b>2</b>     <b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Are there poor contact in ECM connectors?</p>	There is poor contact.	Repair poor contact in ECM connectors.	Inspection using "General Diagnostic Table" <Ref. to EN(H4DOSTC)-246, INSPECTION, General Diagnostic Table.>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## 16. List of Diagnostic Trouble Code (DTC)

### A: LIST

DTC No.	Item	Index
P0031	HO2S Heater Control Circuit Low (Bank 1 Sensor 1)	<Ref. to EN(H4DOSTC)-66, DTC P0031 — HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0032	HO2S Heater Control Circuit High (Bank 1 Sensor 1)	<Ref. to EN(H4DOSTC)-70, DTC P0032 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0037	HO2S Heater Control Circuit Low (Bank 1 Sensor 2)	<Ref. to EN(H4DOSTC)-72, DTC P0037 — HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0038	HO2S Heater Control Circuit High (Bank 1 Sensor 2)	<Ref. to EN(H4DOSTC)-76, DTC P0038 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0102	Mass or Volume Air Flow Circuit Low Input	<Ref. to EN(H4DOSTC)-78, DTC P0102 — MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0103	Mass or Volume Air Flow Circuit High Input	<Ref. to EN(H4DOSTC)-82, DTC P0103 — MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0107	Manifold Absolute Pressure/Barometric Pressure Circuit Low Input	<Ref. to EN(H4DOSTC)-84, DTC P0107 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0108	Manifold Absolute Pressure/Barometric Pressure Circuit High Input	<Ref. to EN(H4DOSTC)-88, DTC P0108 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0112	Intake Air Temperature Circuit Low Input	<Ref. to EN(H4DOSTC)-92, DTC P0112 — INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0113	Intake Air Temperature Circuit High Input	<Ref. to EN(H4DOSTC)-94, DTC P0113 — INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0117	Engine Coolant Temperature Circuit Low Input	<Ref. to EN(H4DOSTC)-98, DTC P0117 — ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0118	Engine Coolant Temperature Circuit High Input	<Ref. to EN(H4DOSTC)-100, DTC P0118 — ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0122	Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input	<Ref. to EN(H4DOSTC)-104, DTC P0122 — THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0123	Throttle/Pedal Position Sensor/Switch "A" Circuit High Input	<Ref. to EN(H4DOSTC)-108, DTC P0123 — THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0136	O2 Sensor Circuit (Bank 1 Sensor 2)	<Ref. to EN(H4DOSTC)-110, DTC P0136 — O2 SENSOR CIRCUIT (BANK 1 SENSOR 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0171	System too Lean (Bank 1)	<Ref. to EN(H4DOSTC)-112, DTC P0171 — SYSTEM TOO LEAN (BANK 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0172	System too Rich (Bank 1)	<Ref. to EN(H4DOSTC)-114, DTC P0172 — SYSTEM TOO RICH (BANK 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0245	Turbo/Super ChargerWastegateSolenoid "A" Low	<Ref. to EN(H4DOSTC)-118, DTC P0245 — TURBO/SUPER CHARGER-WASTEGATESOLENOID "A" LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>



# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0246	Turbo/Super ChargerWastegateSolenoid "A" High	<Ref. to EN(H4DOSTC)-122, DTC P0246 — TURBO/SUPER CHARGER-WASTEGATESOLENOID "A" HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0249	Turbo/Super ChargerWastegateSolenoid "B" Low	<Ref. to EN(H4DOSTC)-124, DTC P0249 — TURBO/SUPER CHARGER-WASTEGATESOLENOID "B" LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0250	Turbo/Super ChargerWastegateSolenoid "B" High	<Ref. to EN(H4DOSTC)-128, DTC P0250 — TURBO/SUPER CHARGER-WASTEGATESOLENOID "B" HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0261	Cylinder 1 Injector Circuit Low	<Ref. to EN(H4DOSTC)-130, DTC P0261 — CYLINDER 1 INJECTOR CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0264	Cylinder 2 Injector Circuit Low	<Ref. to EN(H4DOSTC)-130, DTC P0264 — CYLINDER 2 INJECTOR CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0267	Cylinder 3 Injector Circuit Low	<Ref. to EN(H4DOSTC)-130, DTC P0267 — CYLINDER 3 INJECTOR CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0270	Cylinder 4 Injector Circuit Low	<Ref. to EN(H4DOSTC)-132, DTC P0270 — CYLINDER 4 INJECTOR CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0327	Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)	<Ref. to EN(H4DOSTC)-136, DTC P0327 — KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0328	Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)	<Ref. to EN(H4DOSTC)-138, DTC P0328 — KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0335	Crankshaft Position Sensor "A" Circuit	<Ref. to EN(H4DOSTC)-140, DTC P0335 — CRANKSHAFT POSITION SENSOR "A" CIRCUIT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0340	Camshaft Position Sensor "A" Circuit (Bank 1 or Single Sensor)	<Ref. to EN(H4DOSTC)-142, DTC P0340 — CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR)N —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0350	Ignition Coil Primary/Secondary Circuit	<Ref. to EN(H4DOSTC)-144, DTC P0350 — IGNITION COIL PRIMARY/SECONDARY CIRCUIT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0444	Evaporative Emission Control System Purge Control Valve Circuit Open	<Ref. to EN(H4DOSTC)-148, DTC P0444 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT OPEN —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0445	Evaporative Emission Control System Purge Control Valve Circuit Shorted	<Ref. to EN(H4DOSTC)-152, DTC P0445 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT SHORTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0500	Vehicle Speed Sensor	<Ref. to EN(H4DOSTC)-156, DTC P0500 — VEHICLE SPEED SENSOR —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0508	Idle Control System Circuit Low	<Ref. to EN(H4DOSTC)-158, DTC P0508 — IDLE CONTROL SYSTEM CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0509	Idle Control System Circuit High	<Ref. to EN(H4DOSTC)-162, DTC P0509 — IDLE CONTROL SYSTEM CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0512	Starter Request Circuit	<Ref. to EN(H4DOSTC)-164, DTC P0512 — STARTER REQUEST CIRCUIT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0513	Incorrect Immobilizer Key	<Ref. to IM-20, DTC P0153 — INCORRECT IMMOBILIZER KEY (USE OF UNREGISTERED KEY) —, Diagnostics Chart with Trouble Code.>
P0562	System Voltage Low	<Ref. to EN(H4DOSTC)-166, DTC P0562 — SYSTEM VOLTAGE LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0563	System Voltage High	<Ref. to EN(H4DOSTC)-168, DTC P0563 — SYSTEM VOLTAGE HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0851	Neutral switch input circuit low	<Ref. to EN(H4DOSTC)-170, DTC P0851 — NEUTRAL SWITCH INPUT CIRCUIT LOW (AT MODEL) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> and <Ref. to EN(H4DOSTC)-172, DTC P0851 — NEUTRAL SWITCH INPUT CIRCUIT LOW (MT MODEL) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0852	Neutral switch input circuit high	<Ref. to EN(H4DOSTC)-174, DTC P0852 — NEUTRAL SWITCH INPUT CIRCUIT HIGH (AT MODEL) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> and <Ref. to EN(H4DOSTC)-178, DTC P0852 — NEUTRAL SWITCH INPUT CIRCUIT HIGH (MT MODEL) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1110	Atmospheric Pressure Sensor Circuit Malfunction (Low Input)	<Ref. to EN(H4DOSTC)-181, DTC P1110 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1111	Atmospheric Pressure Sensor Circuit Malfunction (High Input)	<Ref. to EN(H4DOSTC)-182, DTC P1111 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1130	O2 Sensor Circuit (Open) (Bank1 Sensor1)	<Ref. to EN(H4DOSTC)-184, DTC P1130 — O2 SENSOR CIRCUIT (OPEN) (BANK1 SENSOR1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1131	O2 Sensor Circuit (Short) (Bank1 Sensor1)	<Ref. to EN(H4DOSTC)-186, DTC P1131 — O2 SENSOR CIRCUIT (SHORT) (BANK1 SENSOR1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1134	A/F Sensor micro-computer Problem	<Ref. to EN(H4DOSTC)-190, DTC P1134 — A/F SENSOR MICRO-COMPUTER PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1199	Differential Pressure Sensor	<Ref. to EN(H4DOSTC)-192, DTC P1199 — DIFFERENTIAL PRESSURE SENSOR —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1230	Fuel Pump Controller	<Ref. to EN(H4DOSTC)-194, DTC P1230 — FUEL PUMP CONTROLLER —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1235	Intake Control Solenoid Valve Circuit Low	<Ref. to EN(H4DOSTC)-198, DTC P1235 — INTAKE CONTROL SOLENOID VALVE CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1236	Intake Control Solenoid Valve Circuit High	<Ref. to EN(H4DOSTC)-202, DTC P1236 — INTAKE CONTROL SOLENOID VALVE CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1237	Exhaust Control Valve Solenoid Circuit Low (Positive Pressure)	<Ref. to EN(H4DOSTC)-204, DTC P1237 — EXHAUST CONTROL VALVE SOLENOID CIRCUIT LOW (POSITIVE PRESSURE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1238	Exhaust Control Valve Solenoid Circuit High (Positive Pressure)	<Ref. to EN(H4DOSTC)-208, DTC P1238 — EXHAUST CONTROL VALVE SOLENOID CIRCUIT HIGH (POSITIVE PRESSURE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1239	Exhaust Control Valve Solenoid Circuit Low (Negative Pressure)	<Ref. to EN(H4DOSTC)-210, DTC P1239 — EXHAUST CONTROL VALVE SOLENOID CIRCUIT LOW (NEGATIVE PRESSURE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1240	Exhaust Control Valve Solenoid Circuit High (Negative Pressure)	<Ref. to EN(H4DOSTC)-214, DTC P1240 — EXHAUST CONTROL VALVE SOLENOID CIRCUIT HIGH (NEGATIVE PRESSURE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1241	2Stage Twin TURBO System (Single)	<Ref. to EN(H4DOSTC)-216, DTC P1241 — 2STAGE TWIN TURBO SYSTEM (SINGLE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1242	2Stage Twin TURBO System (Twin)	<Ref. to EN(H4DOSTC)-218, DTC P1242 — 2STAGE TWIN TURBO SYSTEM (TWIN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1247	Relief Valve Control Solenoid Valve 1 Circuit Low	<Ref. to EN(H4DOSTC)-220, DTC P1247 — RELIEF VALVE CONTROL SOLENOID VALVE 1 CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P1248	Relief Valve Control Solenoid Valve 1 Circuit High	<Ref. to EN(H4DOSTC)-224, DTC P1248 — RELIEF VALVE CONTROL SOLENOID VALVE 1 CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1249	Relief Valve Control Solenoid Valve 2 Circuit Low	<Ref. to EN(H4DOSTC)-226, DTC P1249 — RELIEF VALVE CONTROL SOLENOID VALVE 2 CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1250	Relief Valve Control Solenoid Valve 2 Circuit High	<Ref. to EN(H4DOSTC)-230, DTC P1250 — RELIEF VALVE CONTROL SOLENOID VALVE 2 CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1507	Idle Control System Malfunction (Fail-safe)	<Ref. to EN(H4DOSTC)-232, DTC P1507 — IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1518	Starter Switch Circuit Low input	<Ref. to EN(H4DOSTC)-234, DTC P1518 — STARTER SWITCH CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1560	Back-up Voltage Circuit Malfunction	<Ref. to EN(H4DOSTC)-236, DTC P1560 — BACK-UP VOLTAGE CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1570	Antenna	<Ref. to IM-21, DTC P1570 — Antenna —, Diagnostics Chart with Trouble Code.>
P1571	Reference Code Incompatibility	<Ref. to IM-17, DTC P1571 REFERENCE CODE INCOMPATIBILITY, Diagnostic Procedure with Trouble Code (DTC).>
P1572	IMM Circuit Failure (Except Antenna Circuit)	<Ref. to IM-18, DTC P1572 IMM CIRCUIT FAILURE (EXCEPT ANTENNA CIRCUIT), Diagnostic Procedure with Trouble Code (DTC).>
P1574	Key Communication Failure	<Ref. to IM-23, DTC P1574 KEY COMMUNICATION FAILURE, Diagnostic Procedure with Trouble Code (DTC).>
P1576	EGI Control Module EEPROM	<Ref. to IM-25, DTC P1576 EGI CONTROL MODULE EEPROM, Diagnostic Procedure with Trouble Code (DTC).>
P1577	IMM Control Module EEPROM	<Ref. to IM-25, DTC P1577 IMM CONTROL MODULE EEPROM, Diagnostic Procedure with Trouble Code (DTC).>
P1698	Engine Torque Control Cut Signal Circuit Malfunction (Low Input)	<Ref. to EN(H4DOSTC)-238, DTC P1698 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1699	Engine Torque Control Cut Signal Circuit Malfunction (High Input)	<Ref. to EN(H4DOSTC)-240, DTC P1699 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1711	Engine Torque Control Signal #1 Circuit Malfunction	<Ref. to EN(H4DOSTC)-242, DTC P1711 — ENGINE TORQUE CONTROL SIGNAL #1 CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1712	Engine Torque Control Signal #2 Circuit Malfunction	<Ref. to EN(H4DOSTC)-244, DTC P1712 — ENGINE TORQUE CONTROL SIGNAL #2 CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b> Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0031 and P0037 at the same time?	Indicated.	Go to step 2.	Go to step 5.
<b>2</b> <b>CHECK POWER SUPPLY TO FRONT OXYGEN (A/F) SENSOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from front oxygen (A/F) sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between front oxygen (A/F) sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(B18) No. 2 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 3.	Repair the power supply line. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and front oxygen (A/F) sensor connector</li> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in main relay connector</li> </ul>
<b>3</b> <b>CHECK GROUND CIRCUIT OF ECM.</b> Measure the resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 8 — Chassis ground:</b> <b>(B137) No. 9 — Chassis ground:</b> Is the measured value less than the specified value?	5 Ω	Go to step 4.	Repair the harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine ground cable</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>4</b> <b>CHECK CURRENT DATA.</b> 1) Start the engine 2) Read the data of front oxygen (A/F) sensor heater current using Subaru Select Monitor. Is the measured value less than the specified value? <b>NOTE:</b> For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.>	0.2 A	Repair the poor contact in connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>	Go to step 5.
<b>5</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Start and idle the engine. 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 4 (+) — Chassis ground (-):</b> <b>(B137) No. 5 (+) — Chassis ground (-):</b> Is the measured value less than the specified value?	1.0 V	Go to step 7.	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>6 CHECK OUTPUT SIGNAL FROM ECM.</b>                      Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B137) No. 4 (+) — Chassis ground (-):</b>  <b>(B137) No. 5 (+) — Chassis ground (-):</b>                      Is the measured value less than the specified value shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	1.0 V	Repair the poor contact in ECM connector.	Go to step 7.
<p><b>7 CHECK FRONT OXYGEN (A/F) SENSOR.</b>                      1) Turn the ignition switch to OFF.                      2) Measure the resistance between front oxygen (A/F) sensor connector terminals.  <b>Terminals</b>  <b>No. 2 — No. 1:</b>                      Is the measured value less than the specified value?</p>	10 Ω	Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open or ground short circuit in harness between front oxygen (A/F) sensor and ECM connector</li> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>	Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOSTC)-38, Front Oxygen (A/F) Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## B: DTC P0032 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1) —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00933



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>     <b>CHECK OUTPUT SIGNAL FROM ECM.</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B137) No. 4 (+) — Chassis ground (-):</b>  <b>(B137) No. 5 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value?</p>	8 V	Go to step 3.	Go to step 2.
<p><b>2</b>     <b>CHECK FRONT OXYGEN (A/F) SENSOR HEATER CURRENT.</b>            1) Turn the ignition switch to OFF.            2) Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.            3) Turn the ignition switch to ON.            4) Read the data of front oxygen (A/F) sensor heater current using Subaru Select Monitor.            Does the measured value exceed the specified value?             NOTE:            For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	2.3 A	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	END
<p><b>3</b>     <b>CHECK OUTPUT SIGNAL FROM ECM.</b>            Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B137) No. 4 (+) — Chassis ground (-):</b>  <b>(B137) No. 5 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value by shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	8.0 V	Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.	END


# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## C: DTC P0037 — HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2)

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00934

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CHECK GROUND CIRCUIT OF ECM.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ECM.                      3) Measure the resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 8 — Chassis ground:</b>  <b>(B137) No. 9 — Chassis ground:</b></p> <p>Is the measured value less than the specified value?</p>	5 Ω	Go to step 3.	Go to step 2.
<p><b>2 CHECK CURRENT DATA.</b>                      1) Start the engine.                      2) Read the data of rear oxygen sensor heater current using Subaru Select Monitor.                      Does the measured value exceed the specified value?</p> <p>NOTE:                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	0.2 A	Repair the connector.  NOTE: In this case, repair the following: • Poor contact in rear oxygen sensor connector • Poor contact in rear oxygen sensor connecting harness connector • Poor contact in ECM connector	Go to step 3.
<p><b>3 CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Start and idle the engine.                      2) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p> <p>Is the measured value less than the specified value?</p>	1.0 V	Go to step 6.	Go to step 4.
<p><b>4 CHECK OUTPUT SIGNAL FROM ECM.</b>                      Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p> <p>Is the measured value less than the specified value by shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	1.0 V	Repair the poor contact in ECM connector.	Go to step 5.
<p><b>5 CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Disconnect the connector from rear oxygen sensor.                      2) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p> <p>Is the measured value less than the specified value?</p>	1.0 V	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Repair the battery short circuit in harness between ECM and rear oxygen sensor connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>6</b>      <b>CHECK POWER SUPPLY TO REAR OXYGEN SENSOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from rear oxygen sensor.                      3) Turn the ignition switch to ON.                      4) Measure the voltage between rear oxygen sensor connector and engine ground or chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(T6) No. 2 (+) — Chassis ground (-):</b>                      Does the measured value exceed the specified value?</p>	10 V	Go to step 7.	Repair the power supply line. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and rear oxygen sensor connector</li> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>7</b>      <b>CHECK REAR OXYGEN SENSOR.</b>                      1) Turn the ignition switch to OFF.                      2) Measure the resistance between rear oxygen sensor connector terminals.</p> <p><b>Terminals</b>  <b>No. 1 — No. 2:</b>                      Is the measured value less than the specified value?</p>	30 Ω	Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between rear oxygen sensor and ECM connector</li> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Replace the rear oxygen sensor. <Ref. to FU(H4DOSTC)-39, Rear Oxygen Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## D: DTC P0038 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2) —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00934

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 13 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	8 V	Go to step 2.	Go to step 3.
<b>2 CHECK CURRENT DATA.</b> 1) Turn the ignition switch to OFF. 2) Repair the battery short circuit in harness between ECM and rear oxygen sensor connector. 3) Turn the ignition switch to ON. 4) Read the data of rear oxygen sensor heater current using Subaru Select Monitor. Does the measured value exceed the specified value?  NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.>	7 A	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	END
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	END

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## E: DTC P0102 — MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT —

### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

### • WIRING DIAGRAM:



EN-00951



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector.                  3) Turn the ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.                  4) Start the engine and run it at idle.                  5) Read the data of mass air flow sensor signal using Subaru Select Monitor.                  Is the measured value within the specified value?</p> <p><b>NOTE:</b>                  For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	<p>1.3 g/sec (0.172 lb/min) — 240 g/sec (32 lb/min) or 0.3 — 4.58 V</p>	<p>Even if MI lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the mass air flow sensor.</p> <p><b>NOTE:</b>                  In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open or ground short circuit in harness between mass air flow sensor and ECM connector</li> <li>• Poor contact in mass air flow sensor or ECM connector</li> </ul>	<p>Go to step 2.</p>
<p><b>2 CHECK INPUT SIGNAL FOR ECM.</b>                  Measure the voltage between ECM connector and chassis ground while engine is idling.  <b>Connector &amp; terminal</b>  <b>(B84) No. 13 (+) — Chassis ground (-):</b>                  Is the measured value less than the specified value?</p>	<p>0.2 V</p>	<p>Go to step 4.</p>	<p>Go to step 3.</p>
<p><b>3 CHECK INPUT SIGNAL FOR ECM (USING SUBARU SELECT MONITOR).</b>                  Measure the voltage between ECM connector and chassis ground while engine is idling.                  Does the measured value change by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?</p>	<p>The value changes.</p>	<p>Repair the poor contact in ECM connector.</p>	<p>Contact SUBARU distributor service.  <b>NOTE:</b>                  Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>
<p><b>4 CHECK POWER SUPPLY TO MASS AIR FLOW SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from mass air flow sensor.                  3) Turn the ignition switch to ON.                  4) Measure the voltage between mass air flow sensor connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B3) No. 1 (+) — Chassis ground (-):</b>                  Does the measured value exceed the specified value?</p>	<p>10V</p>	<p>Go to step 5.</p>	<p>Repair the open circuit between mass air flow sensor and main relay</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>5 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ECM.                      3) Measure the resistance of harness between ECM and mass air flow sensor connector.</p> <p><b>Connector &amp; terminal</b>                      (B84) No. 13 — (B3) No. 3:                      (B135) No. 27 — (B3) No. 4:                      (B135) No. 19 — (B3) No. 5:</p> <p>Is the measured value less than the specified value?</p>	1Ω	Go to step 6.	Repair the open circuit between ECM and mass air flow sensor connector.
<p><b>6 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR</b></p> <p>Measure the resistance of harness between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>                      (B84) No. 13 — Chassis ground:                      (B135) No. 27 — Chassis ground:                      (B135) No. 19 — Chassis ground:</p> <p>Does the measured value exceed the specified value?</p>	1MΩ	Go to step 7.	Repair the ground short circuit between ECM and mass air flow sensor connector.
<p><b>7 CHECK POOR CONTACT</b></p> <p>Check poor contact in mass air flow sensor connector.</p> <p>Is there poor contact in mass air flow sensor connector?</p>	There is poor contact.	Repair the poor contact in mass air flow sensor connector.	Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOSTC)-33, Mass Air Flow and Intake Air Temperature Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## F: DTC P0103 — MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT —


### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CONNECT SUBARU SELECT MONITOR, AND READ DATA.</b></p> <ol style="list-style-type: none"> <li>1) Turn the ignition switch to OFF.</li> <li>2) Connect the Subaru Select Monitor to data link connector.</li> <li>3) Turn the ignition switch to ON and Subaru Select Monitor switch to ON.</li> <li>4) Start the engine.</li> <li>5) Read the data of mass air flow sensor signal using Subaru Select Monitor.</li> </ol> <p>Is the measured value within the specified value?</p> <p>NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	<p>1.3 g/sec (0.172 lb/min) — 240 g/sec (32 lb/min) or 0.3 — 4.58 V</p>	<p>Even if MI lights up, the circuit has returned to a normal condition at this time.</p>	<p>Go to step 2.</p>
<p><b>2 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.</b></p> <ol style="list-style-type: none"> <li>1) Turn the ignition switch to OFF and Subaru Select Monitor switch to OFF.</li> <li>2) Disconnect the connector from mass air flow sensor.</li> <li>3) Turn the ignition switch to ON and Subaru Select Monitor switch to ON.</li> <li>4) Read the data of mass air flow sensor signal using Subaru Select Monitor.</li> </ol> <p>Does the measured value exceed the specified value?</p> <p>NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	<p>240 g/sec (32 lb/min) or 4.58 V</p>	<p>Repair the battery short circuit in harness between mass air flow sensor and ECM connector. After repair, replace the ECM.</p>	<p>Replace the mass air flow sensor.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## G: DTC P0107 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00935

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK CURRENT DATA.</b> 1) Start the engine. 2) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor. Is the measured value less than the specified value?  NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.>	-7.2 kPa (-54 mmHg, -2.1 inHg)	Go to step 3.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b> Check the poor contact in ECM and pressure sensor connector. Is there poor contact in ECM or pressure sensor connector?	There is poor contact.	Repair the poor contact in ECM or pressure sensor connector.	Even if MI lights up, the circuit has returned to a normal condition at this time.
<b>3 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	4.5 V	Go to step 5.	Go to step 4.
<b>4 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b> Does the measured value change by shaking harness and connector of ECM while monitoring the value with voltage meter?	The value changes.	Repair the poor contact in ECM connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>5 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 8 (+) — Chassis ground (-):</b> Is the measured value less than the specified value?	0.7 V	Go to step 6.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>6 CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from pressure sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between pressure sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E21) No. 3 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?	4.5 V	Go to step 7.	Repair the open circuit in harness between ECM and intake manifold pressure sensor connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>7</b>     <b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connector from ECM.            3) Measure the resistance of harness between ECM and intake manifold pressure sensor connector.  <b>Connector &amp; terminal</b>  <b>(B135) No. 19 — (E21) No. 2:</b>            Is the measured value less than the specified value?</p>	1 Ω	Go to step <b>8</b> .	Repair the open circuit in harness between ECM and intake manifold pressure sensor connector.
<p><b>8</b>     <b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b>            Measure the resistance of harness between intake manifold pressure sensor connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E21) No. 1 — Engine ground:</b>            Does the measured value exceed the specified value?</p>	1 MΩ	Go to step <b>9</b> .	Repair the ground short circuit in harness between ECM and intake manifold pressure sensor connector.
<p><b>9</b>     <b>CHECK POOR CONTACT.</b>            Check poor contact in pressure sensor connector.            Is there poor contact in pressure sensor connector?</p>	There is poor contact.	Repair the poor contact in pressure sensor connector.	Replace the pressure sensor. <Ref. to FU(H4DOSTC)-34, Pressure Sensor.>



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)





ENGINE (DIAGNOSTICS)

## H: DTC P0108 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00935

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK CURRENT DATA.</b> 1) Start the engine. 2) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor. Does the measured value exceed the specified value?  <b>NOTE:</b> For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.>	282 kPa (2121 mmHg, 83.50 inHg)	Go to step 7.	Go to step 2.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	4.5 V	Go to step 4.	Go to step 3.
<b>3 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b> Does the measured value change by shaking harness and connector of ECM while monitoring the value with voltage meter?	The value changes.	Repair the poor contact in ECM connector.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>4 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 8 (+) — Chassis ground (-):</b> Is the measured value less than the specified value?	4.5 V	Go to step 5.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>5 CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from pressure sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between pressure sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E21) No. 3 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?	4.5 V	Go to step 6.	Repair the open circuit in harness between ECM and pressure sensor connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>6</b>    <b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and pressure sensor connector. <b>Connector &amp; terminal</b> <b>(B135) No. 8 — (E21) No. 1:</b> <b>(B135) No. 19 — (E21) No. 2:</b> Is the measured value less than the specified value?</p>	1 Ω	Go to step 7.	Repair the open circuit in harness between ECM and pressure sensor connector.
<p><b>7</b>    <b>CHECK POOR CONTACT.</b> Check poor contact in pressure sensor connector. Is there poor contact in pressure sensor connector?</p>	There is poor contact.	Repair the poor contact in pressure sensor connector.	Replace the pressure sensor. <Ref. to FU(H4DOSTC)-34, Pressure Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### I: DTC P0112 — INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT —


#### • TROUBLE SYMPTOM:

- Erroneous idling
- Poor driving performance

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

#### • WIRING DIAGRAM:



EN-00951

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of intake air temperature sensor signal using Subaru Select Monitor. Does the measured value exceed the specified value?</p> <p>NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	55°C (131°F)	Go to step 2.	<p>Repair the poor contact.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from mass air flow and intake air temperature sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Read the data of intake air temperature sensor signal using Subaru Select Monitor. Is the measured value less than the specified value?</p> <p>NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	-36°C (-97°F)	Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOSTC)-33, Mass Air Flow and Intake Air Temperature Sensor.>	Repair the ground short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## J: DTC P0113 — INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT —


### • TROUBLE SYMPTOM:

- Erroneous idling
- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00951



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of intake air temperature sensor signal using Subaru Select Monitor. Is the measured value less than the specified value?</p> <p>NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	-36°C (-97°F)	Go to step 2.	<p>Repair the poor contact.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from mass air flow and intake air temperature sensor.</p> <p>3) Measure the voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B3) No. 2 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.	Go to step 3.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B3) No. 2 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.	Go to step 4.
<p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>Measure the voltage between mass air flow and intake air temperature sensor and pressure sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B3) No. 2 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?</p>	4 V	Go to step 5.	<p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between mass air flow and intake air temperature sensor and ECM connector</li> <li>• Poor contact in mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between mass air flow and intake air temperature sensor and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B3) No. 5 — Engine ground:</b>                      Is the measured value less than the specified value?</p>	<p>5 Ω</p>	<p>Replace the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DOSTC)-33, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>	<p>Repair the harness and connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between mass air flow and intake air temperature sensor and ECM connector</li> <li>• Poor contact in mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### K: DTC P0117 — ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT —


#### • TROUBLE SYMPTOM:

- Hard to start
- Erroneous idling
- Poor driving performance

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

#### • WIRING DIAGRAM:



EN-00936

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor.</p> <p>Does the measured value exceed the specified value?</p> <p>NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	120°C (248°F)	Go to step 2.	<p>Repair the poor contact.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in engine coolant temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from engine coolant temperature sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor.</p> <p>Is the measured value less than the specified value?</p> <p>NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	-40°C (-40°F)	Replace the engine coolant temperature sensor. <Ref. to FU(H4DOSTC)-28, Engine Coolant Temperature Sensor.>	Repair the ground short circuit in harness between engine coolant temperature sensor and ECM connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## L: DTC P0118 — ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT —


### • TROUBLE SYMPTOM:

- Hard to start
- Erroneous idling
- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00936

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor.</p> <p>Is the measured value less than the specified value?</p> <p><b>NOTE:</b> For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	-40°C (-40°F)	Go to step 2.	<p>Repair the poor contact.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in engine coolant temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from engine coolant temperature sensor.</p> <p>3) Measure the voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E8) No. 2 (+) — Engine ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between ECM and engine coolant temperature sensor connector.	Go to step 3.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E8) No. 2 (+) — Engine ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between ECM and engine coolant temperature sensor connector.	Go to step 4.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>Measure the voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E8) No. 2 (+) — Engine ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	4 V	Go to step 5.	<p>Repair the harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine coolant temperature sensor connector</li> <li>• Poor contact in engine coolant temperature sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E8) No. 1 — Engine ground:</b></p> <p>Is the measured value less than the specified value?</p>	5 Ω	Replace the engine coolant temperature sensor. <Ref. to FU(H4DOSTC)-28, Engine Coolant Temperature Sensor.>	<p>Repair the harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine coolant temperature sensor connector</li> <li>• Poor contact in engine coolant temperature sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
**ENGINE (DIAGNOSTICS)**

**M: DTC P0122 — THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT LOW INPUT —**


**• TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**



EN-00937

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CHECK CURRENT DATA.</b>                      1) Start the engine.                      2) Read the data of throttle position sensor signal using Subaru Select Monitor.                      Is the measured value less than the specified value?</p> <p>NOTE:                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	0.1 V	Go to step 2.	Even if MI lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>2 CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground while throttle valve is fully closed.  <b>Connector &amp; terminal</b>  <b>(B135) No. 9 (+) — Chassis ground (-):</b>                      Does the measured value exceed the specified value?</p>	4.5 V	Go to step 4.	Go to step 3.
<p><b>3 CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 9 (+) — Chassis ground (-):</b>                      Does the measured value change by shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	The voltage changes.	Repair the poor contact in ECM connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<p><b>4 CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 7 (+) — Chassis ground (-):</b>                      Is the measured value less than the specified value?</p>	0.1 V	Go to step 6.	Go to step 5.
<p><b>5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b>                      Measure the voltage between ECM connector and chassis ground.                      Does the measured value change by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?</p>	The value changes.	Repair the poor contact in ECM connector.	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>6 CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Disconnect the connectors from throttle position sensor.                      3) Turn the ignition switch to ON.                      4) Measure the voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E13) No. 1 (+) — Engine ground (-):</b>                      Does the measured value exceed the specified value?</p>	4.5 V	Go to step 7.	Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between throttle position sensor and ECM connector</li> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>7 CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Measure the resistance of harness between ECM connector and throttle position sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 7 — (E13) No. 3:</b>                      Is the measured value less than the specified value?</p>	1 Ω	Go to step 8.	Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between throttle position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>8 CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E13) No. 3 — Engine ground:</b>                      Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 9.	Repair the ground short circuit in harness between throttle position sensor and ECM connector.
<p><b>9 CHECK POOR CONTACT.</b></p> <p>Check the poor contact in throttle position sensor connector.                      Is there poor contact in throttle position sensor connector?</p>	There is poor contact.	Repair the poor contact in throttle position sensor connector.	Replace the throttle position sensor. <Ref. to FU(H4DOSTC)-32, Throttle Position Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## N: DTC P0123 — THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT HIGH INPUT —


### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00937

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of throttle position sensor signal using Subaru Select Monitor. Does the measured value exceed the specified value?</p> <p><b>NOTE:</b> For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	4.7 V	Go to step 2.	<p>Even if MI lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from throttle position sensor.</p> <p>3) Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E13) No. 2 — Engine ground:</b></p> <p>Is the measured value less than the specified value?</p>	5 Ω	Go to step 3.	<p>Repair the harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between throttle position sensor and ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E13) No. 3 (+) — Engine ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	4.7 V	Repair the battery short circuit in harness between throttle position sensor and ECM connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	<p>Replace the throttle position sensor. &lt;Ref. to FU(H4DOSTC)-32, Throttle Position Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## O: DTC P0136 — O2 SENSOR CIRCUIT (BANK 1 SENSOR 2) —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00934



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CHECK REAR OXYGEN SENSOR DATA.</b>                      1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for two minutes.                      2) Read the data of rear oxygen sensor signal using Subaru Select Monitor.                      Does the value fluctuate?</p> <p>NOTE:                      For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	The value fluctuates.	Go to step 5.	Go to step 2.
<p><b>2 CHECK REAR OXYGEN SENSOR DATA.</b>                      Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II General Scan Tool.                      Is the measured value within the specified value?</p>	0.2 — 0.4 V	Go to step 3.	Replace the rear oxygen sensor. <Ref. to FU(H4DOSTC)-39, Rear Oxygen Sensor.>
<p><b>3 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connectors from ECM and rear oxygen sensor.                      3) Measure the resistance of harness between ECM and rear oxygen sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 26 — (T6) No. 4:</b>                      Does the measured value exceed the specified value?</p>	3 Ω	Repair the open circuit in harness between ECM and rear oxygen sensor connector.	Go to step 4.
<p><b>4 CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from rear oxygen sensor.                      3) Turn the ignition switch to ON.                      4) Measure the voltage between rear oxygen sensor harness connector and engine ground or chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(T6) No. 4 (+) — Engine ground (-):</b>                      Does the measured value exceed the specified value?</p>	0.2 V	Replace the rear oxygen sensor. <Ref. to FU(H4DOSTC)-39, Rear Oxygen Sensor.>	Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between rear oxygen sensor and ECM connector</li> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>
<p><b>5 CHECK EXHAUST SYSTEM.</b>                      Check the exhaust system parts.                      Is there a fault in exhaust system?</p> <p>NOTE:                      Check the following items.</p> <ul style="list-style-type: none"> <li>• Loose installation of portions</li> <li>• Damage (crack, hole etc.) of parts</li> <li>• Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor</li> </ul>	There is a fault.	Repair or replace the faulty parts.	Replace the rear oxygen sensor. <Ref. to FU(H4DOSTC)-39, Rear Oxygen Sensor.>

## **DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**

ENGINE (DIAGNOSTICS)

---

### **P: DTC P0171 — SYSTEM TOO LEAN (BANK 1) —**

NOTE:

For the diagnostic procedure, refer to DTC P0172. <Ref. to EN(H4DOSTC)-114, DTC P0172 — SYSTEM TOO RICH (BANK 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### Q: DTC P0172 — SYSTEM TOO RICH (BANK 1) —

#### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

Step	Value	Yes	No
<b>1 CHECK EXHAUST SYSTEM.</b> Are there holes or loose bolts on exhaust system?	There is no problem.	Go to step 2.	Repair the exhaust system.
<b>2 CHECK AIR INTAKE SYSTEM.</b> Are there holes, loose bolts or disconnection of hose on air intake system?	There is no problem.	Go to step 3.	Repair the air intake system.
<b>3 CHECK PCV VALVE.</b> Is PCV valve clogged?	PCV valve is not clogged.	Go to step 4.	Replace PCV valve.
<b>4 CHECK FUEL PRESSURE.</b> <b>Warning:</b> •Place "NO FIRE" signs near the working area. •Be careful not to spill fuel on the floor. 1) Release the fuel pressure. (1) Disconnect the connector from fuel pump relay. (2) Start the engine and run it until it stalls. (3) After the engine stalls, crank it for 5 more seconds. (4) Turn the ignition switch to OFF. 2) Connect the connector to fuel pump relay. 3) Disconnect the fuel delivery hose from fuel filter, and connect fuel pressure gauge. 4) Install the fuel filler cap. 5) Start the engine and idle while gear position is neutral. 6) Measure the fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold. Is the measured value within the specified value?  <b>Warning:</b> Before removing the fuel pressure gauge, release fuel pressure.  <b>NOTE:</b> If the fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.	284 — 314 kPa (2.9 — 3.2 kg/cm <sup>2</sup> , 41 — 46 psi)	Go to step 5.	Repair the following items. <b>Fuel pressure too high</b> • Clogged fuel return line or bent hose <b>Fuel pressure too low</b> • Improper fuel pump discharge • Clogged fuel supply line

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>5 CHECK FUEL PRESSURE.</b> After connecting pressure regulator vacuum hose, measure fuel pressure. Is the measured value within the specified value?</p> <p><b>Warning:</b> <b>Before removing the fuel pressure gauge, release fuel pressure.</b></p> <p><b>NOTE:</b> •If the fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. •If out of specification as measured at this step, check or replace the pressure regulator and pressure regulator vacuum hose.</p>	206 — 235 kPa (2.1 — 2.4 kg/cm <sup>2</sup> , 30 — 34 psi)	Go to step 6.	<p>Repair the following items.</p> <p><b>Fuel pressure too high</b></p> <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Clogged fuel return line or bent hose</li> </ul> <p><b>Fuel pressure too low</b></p> <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Improper fuel pump discharge</li> <li>• Clogged fuel supply line</li> </ul>
<p><b>6 CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b> 1) Start the engine and warm-up completely. 2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor. Does the measured value exceed the specified value?</p> <p><b>NOTE:</b> For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	60°C (140°F)	Go to step 7.	Replace the engine coolant temperature sensor. <Ref. to FU(H4DOSTC)-28, Engine Coolant Temperature Sensor.>
<p><b>7 CHECK INTAKE MANIFOLD PRESSURE SENSOR.</b> 1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2) Place the shift lever in neutral position. 3) Turn the A/C switch to OFF. 4) Turn all accessory switches to OFF. 5) Read the data of intake manifold pressure sensor signal using Subaru Select Monitor.</p> <p><b>NOTE:</b> For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt; Is the measured value within the specified value?</p>	Ignition ON 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg) Idling 24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 12.20 inHg)	Go to step 8.	Replace the mass air flow and intake manifold pressure sensor. <Ref. to FU(H4DOSTC)-33, Mass Air Flow and Intake Air Temperature Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Value	Yes	No
8	<p><b>CHECK INTAKE AIR TEMPERATURE SENSOR.</b></p> <ol style="list-style-type: none"><li>1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).</li><li>2) Place the shift lever in neutral position.</li><li>3) Turn the A/C switch to OFF.</li><li>4) Turn all accessory switches to OFF.</li><li>5) Open the front hood.</li><li>6) Measure the ambient temperature.</li><li>7) Read the data of intake manifold pressure sensor signal using Subaru Select Monitor. Is the value obtained when ambient temperature is subtracted from intake air temperature within the specified range?</li></ol> <p>NOTE: For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(H4DOSTC)-26, Subaru Select Monitor.&gt;</p>	-10°C (14°F) — 50°C (122°F)	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Check the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOSTC)-33, Mass Air Flow and Intake Air Temperature Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## R: DTC P0245 — TURBO/SUPER CHARGER WASTEGATE SOLENOID “A” LOW


**• TROUBLE SYMPTOM:**

- Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 24 (+) — Chassis ground (-):</b>                      Does the measured value exceed the specified value?</p>	10 V	Even if MI lights up, the circuit has returned to a normal condition at this time. Contact with your Subaru distributor.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connectors from wastegate control solenoid valve and ECM.                      3) Measure the resistance of harness between wastegate control solenoid valve connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(F81) No. 1 — Engine ground:</b>                      Does the measured value exceed the specified value?</p>	1 M $\Omega$	Go to step 3.	Repair the ground short circuit in harness between ECM and wastegate control solenoid valve connector.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      Measure the resistance of harness between ECM and wastegate control solenoid valve of harness connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 24 — (F81) No. 1:</b>                      Is the measured value less than the specified value?</p>	1 $\Omega$	Go to step 4.	Repair the open circuit in harness between ECM and wastegate control solenoid valve connector.  NOTE: In this case, repair the following: • Open circuit in harness between ECM and wastegate control solenoid valve connector
<p><b>4</b></p> <p><b>CHECK WASTEGATE CONTROL SOLENOID VALVE.</b>                      1) Remove the wastegate control solenoid valve.                      2) Measure the resistance between wastegate control solenoid valve terminals.</p> <p><b>Terminals</b>  <b>No. 1 — No. 2:</b>                      Is the measured value within the specified value?</p>	30 — 34 $\Omega$	Go to step 5.	Replace the wastegate control solenoid valve. <Ref. to IN(H4DOSTC)-21, Wastegate Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>5</b>    <b>CHECK POWER SUPPLY TO WASTEGATE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between wastegate control solenoid valve and engine ground. <b>Connector &amp; terminal</b> <b>(F81) No. 2 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Repair the open circuit in harness between main relay and wastegate control solenoid valve connector.
<p><b>6</b>    <b>CHECK POOR CONTACT.</b> Check poor contact in wastegate control solenoid valve connector. Is there poor contact in wastegate control solenoid valve connector?</p>	There is poor contact.	Repair the poor contact in wastegate control solenoid valve connector.	Contact with your Subaru distributor. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## S: DTC P0246 — TURBO/SUPER CHARGERWASTEGATESOLENOID “A” HIGH


**• TROUBLE SYMPTOM:**

- Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**



EN-00938

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 24 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 3.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<b>3 CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from wastegate control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 24 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair the battery short circuit in harness between ECM and wastegate control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 4.
<b>4 CHECK WASTEGATE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between wastegate control solenoid valve terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b> Is the measured value less than the specified value?	1 Ω	Replace the wastegate control solenoid valve <Ref. to IN(H4DOSTC)-21, Wastegate Control Solenoid Valve.> and ECM <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 5.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### T: DTC P0249 — TURBO/SUPER CHARGER WASTEGATE SOLENOID “B” LOW


• **TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK INPUT SIGNAL TO ECM.</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 11 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Even if MI lights up, the circuit has returned to a normal condition at this time. Contact SUBARU distributor service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL DUTY SOLENOID VALVE AND ECM CONNECTOR.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connectors from exhaust valve control duty solenoid valve and ECM.            3) Measure the resistance of harness between exhaust valve control duty solenoid valve connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B220) No. 12 — Engine ground:</b>            Does the measured value exceed the specified value?</p>	1 M $\Omega$	Go to step 3.	Repair the ground short circuit in harness between ECM and exhaust valve control duty solenoid valve connector.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL DUTY SOLENOID VALVE AND ECM CONNECTOR.</b>            Measure the resistance of harness between ECM and exhaust valve control duty solenoid valve of harness connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 11 — (B220) No. 12:</b>            Is the measured value less than the specified value?</p>	1 $\Omega$	Go to step 4.	Repair the open circuit in harness between ECM and exhaust valve control duty solenoid valve connector.
<p><b>4</b></p> <p><b>CHECK EXHAUST VALVE CONTROL DUTY SOLENOID VALVE.</b>            Measure the resistance between purge control solenoid valve terminals.</p> <p><b>Terminals</b>  <b>No. 11 — No. 12:</b>            Is the measured value within the specified value?</p>	17 — 21 $\Omega$	Go to step 5.	Replace the exhaust valve control duty solenoid valve. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
<p><b>5</b></p> <p><b>CHECK POWER SUPPLY TO EXHAUST VALVE CONTROL DUTY SOLENOID VALVE.</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between exhaust valve control duty solenoid valve and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B220) No. 11 (+) — Engine ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Repair the open circuit in harness between main relay and exhaust valve control duty solenoid valve connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in exhaust valve control duty solenoid valve and ECM connectors. Is there poor contact in exhaust valve control duty solenoid valve and ECM connectors?	There is poor contact.	Repair the poor contact in exhaust valve control duty solenoid valve and ECM connectors.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### U: DTC P0250 — TURBO/SUPER CHARGER WASTEGATESOLENOID “B” HIGH


**• TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**



EN-00939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL TO ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 11 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 3.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<b>3 CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL DUTY SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from exhaust valve control duty solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 11 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair the battery short circuit in harness between ECM and exhaust valve control duty solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 4.
<b>4 CHECK EXHAUST VALVE CONTROL DUTY SOLENOID VALVE.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between exhaust valve control duty solenoid valve terminals. <b>Terminals</b> <b>No. 11 — No. 12:</b> Is the measured value less than the specified value?	1 $\Omega$	Replace the exhaust valve control duty solenoid valve <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.> and ECM <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 5.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in ECM and exhaust valve control duty solenoid valve connectors. Is there poor contact in ECM exhaust valve control duty solenoid valve connectors?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

---

## **V: DTC P0261 — CYLINDER 1 INJECTOR CIRCUIT LOW —**

NOTE:

For the diagnostic procedure, refer to DTC P0270. <Ref. to EN(H4DOSTC)-132, DTC P0270 — CYLINDER 4 INJECTOR CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **W: DTC P0264 — CYLINDER 2 INJECTOR CIRCUIT LOW —**

NOTE:

For the diagnostic procedure, refer to DTC P0270. <Ref. to EN(H4DOSTC)-132, DTC P0270 — CYLINDER 4 INJECTOR CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **X: DTC P0267 — CYLINDER 3 INJECTOR CIRCUIT LOW —**

NOTE:

For the diagnostic procedure, refer to DTC P0270. <Ref. to EN(H4DOSTC)-132, DTC P0270 — CYLINDER 4 INJECTOR CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### Y: DTC P0270 — CYLINDER 4 INJECTOR CIRCUIT LOW —


**• TROUBLE SYMPTOM:**

- Engine stalls.
- Erroneous idling
- Rough driving

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**



EN-00940

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CHECK OPERATION OF EACH FUEL INJECTOR.</b> While cranking the engine, check that each fuel injector emits “operating” sound. Use a sound scope or attach a screwdriver to injector for this check. Does the fuel injector operate?</p>	Operates.	Check the fuel pressure. <Ref. to ME(H4DOSTC)-26, FUEL PRESSURE, .>	Go to step 2.
<p><b>2 CHECK POWER SUPPLY TO EACH FUEL INJECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from #1 cylinder fuel injector. 3) Turn the ignition switch to ON. 4) Measure the power supply voltage between the fuel injector terminal and engine ground. <b>Connector &amp; terminal</b> <b>#1 (E5) No. 2 (+) — Engine ground (-):</b> <b>#2 (E16) No. 2 (+) — Engine ground (-):</b> <b>#3 (E6) No. 2 (+) — Engine ground (-):</b> <b>#4 (E17) No. 2 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?</p>	10 V	Go to step 3.	Repair the harness and connector.  <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in fuel injector connector</li> </ul>
<p><b>3 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b> 1) Disconnect the connector from ECM. 2) Measure the resistance of harness between ECM and fuel injector connector. <b>Connector &amp; terminal</b> <b>(B137) No. 1 — (E5) No. 1:</b> <b>(B136) No. 6 — (E16) No. 1:</b> <b>(B136) No. 5 — (E6) No. 1:</b> <b>(B136) No. 4 — (E6) No. 1:</b> Is the measured value less than the specified value?</p>	1 Ω	Go to step 4.	Repair the harness and connector.  <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in the harness between ECM and fuel injector connector</li> <li>• Poor contact in the coupling connector</li> </ul>
<p><b>4 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b> Measure the resistance of harness between ECM and fuel injector connector. <b>Connector &amp; terminal</b> <b>(B137) No. 1 — Chassis ground:</b> <b>(B136) No. 6 — Chassis ground:</b> <b>(B136) No. 5 — Chassis ground:</b> <b>(B136) No. 4 — Chassis ground:</b> Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 5.	Repair the ground short circuit in harness between ECM and fuel injector connector.
<p><b>5 CHECK EACH FUEL INJECTOR.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between each fuel injector terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b> Is the measured value within the specified value?</p>	5 — 20 Ω	Go to step 6.	Replace the faulty fuel injector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Inspection using "General Diagnostic Table". <Ref. to EN(H4DOSTC)-246, INSPECTION, General Diagnostic Table.>



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## Z: DTC P0327 — KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR) —


### • TROUBLE SYMPTOM:

- Poor driving performance
- Knocking occurs.

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00941

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>      <b>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connector from ECM.            3) Measure the resistance between ECM harness connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 4 — Chassis ground:</b>            Does the measured value exceed the specified value?</p>	700 kΩ	Go to step 2.	Repair the harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between knock sensor and ECM connector</li> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>2</b>      <b>CHECK KNOCK SENSOR.</b>            1) Disconnect the connector from knock sensor.            2) Measure the resistance between knock sensor connector terminal and engine ground.</p> <p><b>Terminal</b>  <b>No. 2 — Engine ground:</b>            Does the measured value exceed the specified value?</p>	700 kΩ	Go to step 3.	Repair the harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between knock sensor and ECM connector</li> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>3</b>      <b>CHECK CONDITION OF KNOCK SENSOR INSTALLATION.</b>            Is the knock sensor installation bolt tightened securely?</p>	Tightened securely.	Replace the knock sensor. <Ref. to FU(H4DOSTC)-31, Knock Sensor.>	Tighten the knock sensor installation bolt securely.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AA:DTC P0328 — KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR) —


### • TROUBLE SYMPTOM:

- Poor driving performance
- Knocking occurs.

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00941

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>     <b>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.</b>                      Measure the resistance of harness between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 4 — Chassis ground:</b>                      Is the measured value less than the specified value?</p>	400 kΩ	Go to step 2.	Go to step 3.
<p><b>2</b>     <b>CHECK KNOCK SENSOR.</b>                      1) Disconnect the connector from knock sensor.                      2) Measure the resistance between knock sensor connector terminal and engine ground.  <b>Terminal</b>  <b>No. 2 — Engine ground:</b>                      Is the measured value less than the specified value?</p>	400 kΩ	Replace the knock sensor. <Ref. to FU(H4DOSTC)-31, Knock Sensor.>	Repair the ground short circuit in harness between knock sensor connector and ECM connector.  NOTE: The harness between both connectors is shielded. Repair the short circuit of harness together with shield.
<p><b>3</b>     <b>CHECK INPUT SIGNAL FOR ECM.</b>                      1) Connect the connectors to ECM and knock sensor.                      2) Turn the ignition switch to ON.                      3) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 4 (+) — Chassis ground (-):</b>                      Does the measured value exceed the specified value?</p>	2 V	Even if MI lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)  NOTE: In this case, repair the following: • Poor contact in knock sensor connector • Poor contact in ECM connector • Poor contact in coupling connector	Repair the poor contact in ECM connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### AB:DTC P0335 — CRANKSHAFT POSITION SENSOR “A” CIRCUIT —


**• TROUBLE SYMPTOM:**

- Engine stalls.
- Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**



EN-00942

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>     <b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from crankshaft position sensor.                  3) Measure the resistance of harness between crankshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E10) No. 1 — Engine ground:</b></p> <p>Does the measured value exceed the specified value?</p>	100 kΩ	Repair the harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between crankshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Go to step 2.
<p><b>2</b>     <b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>Measure the resistance of harness between crankshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E10) No. 1 — Engine ground:</b></p> <p>Is the measured value less than the specified value?</p>	10 Ω	Repair the ground short circuit in harness between crankshaft position sensor and ECM connector.  NOTE: The harness between both connectors are shielded. Repair the ground short circuit in harness together with shield.	Go to step 3.
<p><b>3</b>     <b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>Measure the resistance of harness between crankshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E10) No. 2 — Engine ground:</b></p> <p>Is the measured value less than the specified value?</p>	5 Ω	Go to step 4.	Repair the harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between crankshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>4</b>     <b>CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.</b></p> <p>Is the crankshaft position sensor installation bolt tightened securely?</p>	Tightened securely.	Go to step 5.	Tighten the crankshaft position sensor installation bolt securely.
<p><b>5</b>     <b>CHECK CRANKSHAFT POSITION SENSOR.</b></p> <p>1) Remove the crankshaft position sensor.                  2) Measure the resistance between connector terminals of crankshaft position sensor.</p> <p><b>Terminals</b>  <b>No. 1 — No. 2:</b></p> <p>Is the measured value within the specified value?</p>	1 — 4 kΩ	Repair the poor contact in crankshaft position sensor connector.	Replace the crankshaft position sensor. <Ref. to FU(H4DOSTC)-29, Crankshaft Position Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)

**AC:DTC P0340 — CAMSHAFT POSITION SENSOR “A” CIRCUIT (BANK 1 OR SINGLE SENSOR)N —**



**• TROUBLE SYMPTOM:**

- Engine stalls.
- Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**



EN-00943



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>     <b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from camshaft position sensor. 3) Measure the resistance of harness between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b></p> <p>Does the measured value exceed the specified value?</p>	100 kΩ	<p>Repair the harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Go to step 2.
<p><b>2</b>     <b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>Measure the resistance of harness between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b></p> <p>Is the measured value less than the specified value?</p>	10 Ω	<p>Repair the ground short circuit in harness between camshaft position sensor and ECM connector.</p> <p><b>NOTE:</b> The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.</p>	Go to step 3.
<p><b>3</b>     <b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>Measure the resistance of harness between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E15) No. 2 — Engine ground:</b></p> <p>Is the measured value less than the specified value?</p>	5 Ω	Go to step 4.	<p>Repair the harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>4</b>     <b>CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b></p> <p>Is the camshaft position sensor installation bolt tightened securely?</p>	Tightened securely.	Go to step 5.	Tighten the camshaft position sensor installation bolt securely.
<p><b>5</b>     <b>CHECK CAMSHAFT POSITION SENSOR.</b></p> <p>1) Remove the camshaft position sensor. 2) Measure the resistance between connector terminals of camshaft position sensor.</p> <p><b>Terminals</b> <b>No. 1 — No. 2:</b></p> <p>Is the measured value within the specified value?</p>	1 — 4 kΩ	Repair the poor contact in camshaft position sensor connector.	Replace the camshaft position sensor. <Ref. to FU(H4DOSTC)-30, Camshaft Position Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AD:DTC P0350 — IGNITION COIL PRIMARY/SECONDARY CIRCUIT —


• **TROUBLE SYMPTOM:**

- Failure of engine to start
- Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H4DOSTC)-35, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-00944

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK SPARK PLUG CONDITION.</b> 1) Remove the spark plug. <Ref. to IG(H4DOSTC)-5, REMOVAL, Spark Plug.> 2) Check the spark plug condition. <Ref. to IG(H4DOSTC)-6, INSPECTION, Spark Plug.> Is spark plug's status OK?	OK	Go to step 2.	Replace the spark plug.
<b>2 CHECK IGNITION SYSTEM FOR SPARKS.</b> 1) Connect the spark plug to ignition coil. 2) Release the fuel pressure. <Ref. to FU(H4DOSTC)-44, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.> 3) Contact the spark plug's thread portion on engine. 4) While opening throttle valve fully, crank the engine to check that spark occurs at each cylinder. Does the spark occur at each cylinder?	Spark occurs.	Check the fuel pump system. <Ref. to EN(H4DOSTC)-60, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>	Go to step 3.
<b>3 CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL &amp; IGNITOR ASSEMBLY.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ignition coil & ignitor assembly. 3) Turn the ignition switch to ON. 4) Measure the power supply voltage between ignition coil & ignitor assembly connector and engine ground. <b>Connector &amp; terminal</b> (E31) No. 3 (+) — Engine ground (-): (E32) No. 3 (+) — Engine ground (-): (E33) No. 3 (+) — Engine ground (-): (E34) No. 3 (+) — Engine ground (-): Does the measured value exceed the specified value?	10 V	Go to step 4.	Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ignition coil &amp; ignitor assembly, and ignition switch connector</li> <li>• Poor contact in coupling connectors</li> </ul>
<b>4 CHECK HARNESS OF IGNITION COIL &amp; IGNITOR ASSEMBLY GROUND CIRCUIT.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between ignition coil & ignitor assembly connector and engine ground. <b>Connector &amp; terminal</b> (E31) No. 2 — Engine ground: (E32) No. 2 — Engine ground: (E33) No. 2 — Engine ground: (E34) No. 2 — Engine ground: Is the measured value less than the specified value?	5 Ω	Go to step 5.	Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ignition coil &amp; ignitor assembly connector and engine grounding terminal</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>5</b>    <b>CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from ECM.                  3) Disconnect the connector from ignition coil &amp; ignitor assembly.                  4) Measure the resistance of harness between ECM and ignition coil &amp; ignitor assembly connector.</p> <p><b>Connector &amp; terminal</b>                  (B136) No. 21 — (E34) No. 1:                  (B136) No. 22 — (E33) No. 1:                  (B136) No. 23 — (E32) No. 1:                  (B136) No. 24 — (E31) No. 1:</p> <p>Is the measured value less than the specified value?</p>	1 Ω	Go to step 6.	Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and ignition coil & ignitor assembly connector • Poor contact in coupling connector
<p><b>6</b>    <b>CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM and engine ground.</p> <p><b>Connector &amp; terminal:</b>                  (B136) No. 21 — Engine ground:                  (B136) No. 22 — Engine ground:                  (B136) No. 23 — Engine ground:                  (B136) No. 24 — Engine ground:</p> <p>Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 7.	Repair the ground short circuit in harness between ECM and ignition coil & ignitor assembly connector.
<p><b>7</b>    <b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in ECM connector.                  Is there poor contact in ECM connector?</p>	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ignition coil and ignitor assembly.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AE:DTC P0444 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT OPEN —


### • TROUBLE SYMPTOM:

- Erroneous idling

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00945

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b></p> <p>1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 16 (+) — Chassis ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	<p>Even if MI lights up, the circuit has returned to a normal condition at this time. Contact SUBARU distributor service.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	Go to step 2.
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from purge control solenoid valve and ECM. 3) Measure the resistance of harness between purge control solenoid valve connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E4) No. 2 — Engine ground:</b></p> <p>Is the measured value less than the specified value?</p>	10 Ω	<p>Repair the ground short circuit in harness between ECM and purge control solenoid valve connector.</p>	Go to step 3.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM and purge control solenoid valve of harness connector.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 16 — (E4) No. 2:</b></p> <p>Is the measured value less than the specified value?</p>	1 Ω	Go to step 4.	<p>Repair the open circuit in harness between ECM and purge control solenoid valve connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and purge control solenoid valve connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>4</b></p> <p><b>CHECK PURGE CONTROL SOLENOID VALVE.</b></p> <p>1) Remove the purge control solenoid valve. 2) Measure the resistance between purge control solenoid valve terminals.</p> <p><b>Terminals</b> <b>No. 1 — No. 2:</b></p> <p>Is the measured value within the specified value?</p>	10 — 100 Ω	Go to step 5.	<p>Replace the purge control solenoid valve. &lt;Ref. to EC(H4DOSTC)-6, Purge Control Solenoid Valve.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>5</b>    <b>CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between purge control solenoid valve and engine ground. <b>Connector &amp; terminal</b> <b>(E4) No. 1 (+) — Engine ground (-):</b> Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Repair the open circuit in harness between main relay and purge control solenoid valve connector.
<p><b>6</b>    <b>CHECK POOR CONTACT.</b> Check poor contact in purge control solenoid valve connector. Is there poor contact in purge control solenoid valve connector?</p>	There is poor contact.	Repair the poor contact in purge control solenoid valve connector.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AF:DTC P0445 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT SHORTED —


**• TROUBLE SYMPTOM:**

- Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**



EN-00945

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CHECK OUTPUT SIGNAL FROM ECM.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of center console box.                  3) Turn the ignition switch to ON.                  4) While operating the purge control solenoid valve, measure the voltage between ECM and chassis ground.</p> <p>NOTE:                  Purge control solenoid valve operation can be executed using the Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". &lt;Ref. to EN(H4DOSTC)-36, Compulsory Valve Operation Check Mode.&gt;</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 16 (+) — Chassis ground (-):</b>                  Is the measured value within the specified value?</p>	0 — 13 V	Go to step 2.	Even if MI light up, the circuit has returned to a normal condition at this time. In this case, repair the poor contact in ECM connector.
<p><b>2 CHECK OUTPUT SIGNAL FROM ECM.</b></p> <p>1) Turn the ignition switch to ON.                  2) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 16 (+) — Chassis ground (-):</b>                  Does the measured value exceed the specified value?</p>	10 V	Go to step 4.	Go to step 3.
<p><b>3 CHECK POOR CONTACT.</b>                  Check poor contact in ECM connector.                  Is there poor contact in ECM connector?</p>	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<p><b>4 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from purge control solenoid valve.                  3) Turn the ignition switch to ON.                  4) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 16 (+) — Chassis ground (-):</b>                  Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between ECM and purge control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 5.
<p><b>5 CHECK PURGE CONTROL SOLENOID VALVE.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Measure the resistance between purge control solenoid valve terminals.</p> <p><b>Terminals</b>  <b>No. 1 — No. 2:</b>                  Is the measured value less than the specified value?</p>	1 Ω	Replace the purge control solenoid valve <Ref. to EC(H4DOSTC)-6, Purge Control Solenoid Valve.> and ECM <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## AG:DTC P0500 — VEHICLE SPEED SENSOR —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00946

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1</b> <b>CHECK SPEEDOMETER OPERATION IN COMBINATION METER.</b> Does the speedometer operate normally?	Operates normally.	Go to step 2.	Check the speedometer and vehicle speed sensor. <Ref. to IDI-19, Speedometer.>
<b>2</b> <b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from combination meter. 3) Measure the resistance between ECM and combination meter. <b>Connector &amp; terminal</b> <b>(B134) No. 1 — (i10) No. 11:</b> Is the measured value less than the specified value?	10 Ω	Repair the poor contact in ECM connector.	Repair the harness and connector.  <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and combination meter connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in combination meter connector</li> <li>• Poor contact in coupling connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AH:DTC P0508 — IDLE CONTROL SYSTEM CIRCUIT LOW —


### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Engine breathing

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00947



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>     <b>CHECK OUTPUT SIGNAL FROM ECM.</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B136) No. 10 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value?</p>	3 V	Repair the poor contact in ECM connector.	Go to step 2.
<p><b>2</b>     <b>CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connector from idle air control solenoid valve.            3) Turn the ignition switch to ON.            4) Measure the voltage between idle air control solenoid valve and engine ground.  <b>Connector &amp; terminal</b>  <b>(E7) No. 2 (+) — Engine ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Go to step 3.	Repair the harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between idle air control solenoid valve and main relay connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>3</b>     <b>CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connector from ECM.            3) Measure the resistance of harness between ECM and idle air control solenoid valve connector.  <b>Connector &amp; terminal</b>  <b>(B136) No. 10 — (E7) No. 1:</b>            Is the measured value less than the specified value?</p>	1 Ω	Go to step 4.	Repair the harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and idle air control solenoid valve connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>4</b>     <b>CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</b>            Measure the resistance of harness between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B136) No. 10 — Chassis ground:</b>            Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 5.	Repair the ground short circuit in harness between ECM and idle air control solenoid valve connector.
<p><b>5</b>     <b>CHECK GROUND CIRCUIT OF IDLE AIR CONTROL SOLENOID VALVE.</b>            Measure the resistance of harness between idle air control solenoid valve connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E7) No. 3 — Engine ground:</b>            Is the measured value less than the specified value?</p>	5 Ω	Go to step 6.	Repair the open circuit in harness between idle air control solenoid valve connector and engine ground cable.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM and idle air control solenoid valve connectors. Is there poor contact in ECM and idle air control solenoid valve connectors?	There is poor contact.	Repair the poor contact in ECM and idle air control solenoid valve connectors.	Replace the idle air control solenoid valve. <Ref. to FU(H4DOSTC)-35, Idle Air Control Solenoid Valve.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AI: DTC P0509 — IDLE CONTROL SYSTEM CIRCUIT HIGH —


### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Engine breathing

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00947

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK THROTTLE CABLE.</b> Does the throttle cable have play for adjustment?	Cable has play correctly.	Go to step 2.	Adjust the throttle cable. <Ref. to SP(H4SO)-10, Accelerator Control Cable.>
<b>2 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 3.	Go to step 4.
<b>3 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from idle air control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair the battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Replace the idle air control solenoid valve <Ref. to FU(H4DOSTC)-35, Idle Air Control Solenoid Valve.> and replace ECM <Ref. to FU(H4DOSTC)-40, Engine Control Module.>.
<b>4 CHECK OUTPUT SIGNAL FROM ECM.</b> Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b> Does the measured value change by shaking harness and connector of ECM while monitoring the value with voltage meter?	The value changes.	Repair the battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Contact SUBARU distributor service. NOTE: Insepection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AJ:DTC P0512 — STARTER REQUEST CIRCUIT —


### • TROUBLE SYMPTOM:

- Failure of engine to start

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00930

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1</b> <b>CHECK OPERATION OF STARTER MOTOR.</b> NOTE: Place the inhibitor switch in each position. Does the starter motor operate when ignition switch to "ON"?	Operates.	Repair the battery short circuit in starter motor circuit. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Check the starter motor circuit. <Ref. to EN(H4DOSTC)-52, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AK:DTC P0562 — SYSTEM VOLTAGE LOW —


### • TROUBLE SYMPTOM:

- Charge warning light comes on.

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.>.

### • WIRING DIAGRAM:





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK GENERATOR.</b> 1) Start the engine. 2) Idling after warm-up. 3) Measure the voltage between generator B terminal and chassis ground. <b>Terminal</b> <b>Generator B terminal (+) — Chassis ground (-):</b> Is the measured value less than the specified value?	10.8 V	Go to step 2.	Repair the generator. <Ref. to SC(H4DOSTC)-14, Generator.>
<b>2 CHECK GENERATOR.</b> 1) Run the engine at 5,000 rpm. 2) Measure the voltage between generator B terminal and chassis ground. <b>Terminal</b> <b>Generator B terminal (+) — Chassis ground (-):</b> Is the measured value less than the specified value?	10.8 V	Go to step 3.	Repair the generator. <Ref. to SC(H4DOSTC)-14, Generator.>
<b>3 CHECK BATTERY TERMINAL.</b> Turn the ignition switch to OFF. Are the positive and negative battery terminals tightly clamped?	Clamped tightly.	Go to step 4.	Tighten the clamp of terminal.
<b>4 CHECK INPUT VOLTAGE OF ECM.</b> 1) Run the engine at idle. 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 1 (+) — Chassis ground (-):</b> <b>(B136) No. 2 (+) — Chassis ground (-):</b> Is the measured value less than the specified value?	10.8 V	Go to step 5.	Repair the harness connector between battery, main relay and ECM.
<b>5 CHECK POOR CONTACT IN CONNECTORS.</b> Is there poor contact in connectors between generator, battery and ECM?	There is poor contact.	Repair the connector.	Go to step 6.
<b>6 CHECK ECM.</b> 1) Connect all connectors. 2) Erase the memory. <Ref. to EN(H4DOSTC)-35, Clear Memory Mode.> 3) Perform the inspection mode. <Ref. to EN(H4DOSTC)-33, Inspection Mode.> 4) Read out the DTC. <Ref. to EN(H4DOSTC)-32, Read Diagnostic Trouble Code.> Is the same DTC as in the current diagnosis still being output?	DTC indicated.	Replace the generator.	Go to step 7.
<b>7 CHECK ANY OTHER DTCs APPEARANCE.</b> Are other DTCs being output?	DTCs indicated.	Proceed with the diagnosis corresponding to the DTC.	A temporary poor contact.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AL:DTC P0563 — SYSTEM VOLTAGE HIGH —


### • TROUBLE SYMPTOM:

- Charge warning light comes on.

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.>.

### • WIRING DIAGRAM:



EN-00948

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK GENERATOR.</b> 1) Start the engine. 2) Idling after warm-up. 3) Measure the voltage between generator B terminal and chassis ground. <b>Terminal</b> <b>Generator B terminal (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	16.2 V	Go to step 2.	Repair the generator. <Ref. to SC(H4DOSTC)-14, Generator.>
<b>2 CHECK GENERATOR.</b> 1) Run the engine at 5,000 rpm. 2) Measure the voltage between generator B terminal and chassis ground. <b>Terminal</b> <b>Generator B terminal (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	16.2 V	Go to step 3.	Repair the generator. <Ref. to SC(H4DOSTC)-14, Generator.>
<b>3 CHECK BATTERY TERMINAL.</b> Turn the ignition switch to OFF. Are the positive and negative battery terminals tightly clamped?	Clamped tightly.	Go to step 4.	Tighten the clamp of terminal.
<b>4 CHECK INPUT VOLTAGE OF ECM.</b> 1) Run the engine at idle. 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 1 (+) — Chassis ground (-):</b> <b>(B136) No. 2 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	16.2 V	Go to step 5.	Repair the harness connector between battery, main relay and ECM.
<b>5 CHECK POOR CONTACT IN CONNECTORS.</b> Is there poor contact in connectors between generator, battery and ECM?	There is poor contact.	Repair the connector.	Go to step 6.
<b>6 CHECK ECM.</b> 1) Connect all connectors. 2) Erase the memory. <Ref. to EN(H4DOSTC)-35, Clear Memory Mode.> 3) Perform the inspection mode. <Ref. to EN(H4DOSTC)-33, Inspection Mode.> 4) Read out the DTC. <Ref. to EN(H4DOSTC)-32, Read Diagnostic Trouble Code.> Is the same DTC as in the current diagnosis still being output?	DTC indicated.	Replace the generator.	Go to step 7.
<b>7 CHECK ANY OTHER DTCs APPEARANCE.</b> Are other DTCs being output?	DTCs indicated.	Proceed with the diagnosis corresponding to the DTC.	A temporary poor contact.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AM:DTC P0851 — NEUTRAL SWITCH INPUT CIRCUIT LOW (AT MODEL) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-01003

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK ANY OTHER DTC ON DISPLAY.</b> Is any other DTC displayed?	DTC indicated.	Inspect the relevant DTC using "List of Diagnostics Trouble Code (DTC)". <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 (+) — Chassis ground (-):</b> Is the measured value within the specified value at except "N" and "P" position?	4.5 V — 5.5 V	Even if MI lights up, the circuit has returned to a normal condition at this time.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connectors from ECM and transmission harness connector (T3). 3) Measure resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 — Chassis ground:</b> Does the measured value exceed the specified value?	1 MΩ	Go to step 4.	Repair ground short circuit in harness between ECM and transmission harness connector.
<b>4 CHECK TRANSMISSION HARNESS CONNECTOR.</b> 1) Disconnect connector from inhibitor switch. 2) Measure resistance of harness between transmission harness connector and engine ground. <b>Connector &amp; terminal</b> <b>(T3) No. 12 — Engine ground:</b> Does the measured value exceed the specified value?	1 MΩ	Go to step 5.	Repair ground short circuit in harness between transmission harness and inhibitor switch connector.
<b>5 CHECK INHIBITOR SWITCH.</b> Measure resistance between inhibitor switch connector receptacle's terminals in select lever except for "N" position. <b>Terminals</b> <b>No. 7 — No. 12:</b> Does the measured value exceed the specified value at except "N" and "P" positions?	1 MΩ	Go to step 6.	Replace inhibitor switch. <Ref. to AT-49, Inhibitor Switch.>
<b>6 CHECK SELECTOR CABLE CONNECTION.</b> Is there any fault in selector cable connection to inhibitor switch?	There is a fault.	Repair selector cable connection. <Ref. to CS-12, Select Cable.>	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AN:DTC P0851 — NEUTRAL SWITCH INPUT CIRCUIT LOW (MT MODEL) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN-01004

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value in neutral position?	5 V	Go to step 2.	Go to step 4.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 (+) — Chassis ground (-):</b> Is the measured value less than the specified value at except neutral position?	1 V	Go to step 3.	Go to step 4.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>4 CHECK NEUTRAL POSITION SWITCH.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from transmission harness. 3) Measure resistance between transmission harness and connector terminals. <b>Connector &amp; terminal</b> <b>(T9) No. 1 — No. 2:</b> Does the measured value exceed the specified value in neutral position?	1 MΩ	Go to step 5.	Repair short circuit in transmission harness or replace neutral position switch.
<b>5 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR.</b> 1) Disconnect connector from ECM. 2) Measure resistance between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 — Chassis ground:</b> Does the measured value exceed the specified value?	1 MΩ	Repair ground short circuit in harness between ECM and transmission harness connector.	Go to step 6.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in transmission harness connector. Is there poor contact in transmission harness connector?	There is poor contact.	Repair poor contact in transmission harness connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AO:DTC P0852 — NEUTRAL SWITCH INPUT CIRCUIT HIGH (AT MODEL) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-01003



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK ANY OTHER DTC ON DISPLAY.</b> Is any other DTC displayed?	DTC indicated.	Inspect the relevant DTC using "List of Diagnostics Trouble Code (DTC)". <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground in select level "N" and "P" positions. <b>Connector &amp; terminal</b> <b>(B134) No. 8 (+) — Chassis ground</b> Is the measured value less than the specified value?	1 V	Go to step 3.	Go to step 5.
<b>3 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM and chassis ground in select level "N" and "P" positions. <b>Connector &amp; terminal</b> <b>(B134) No. 8 (+) — Chassis ground</b> Is the measured value within the specified range?	4.5 - 5.5 V	Go to step 4.	Go to step 5.
<b>4 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector.	There is poor contact.	Repair poor contact in ECM connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>5 CHECK HARNESS BETWEEN ECM AND INHIBITOR SWITCH CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM and inhibitor switch. 3) Measure resistance of harness between ECM and inhibitor switch connector. <b>Connector &amp; terminal</b> <b>(B134) No. 8 — (T7) No. 12:</b> Is the measured value less than the specified value?	1 Ω	Go to step 6.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and inhibitor switch connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in inhibitor switch connector</li> <li>• Poor contact in ECM connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>6 CHECK INHIBITOR SWITCH GROUND LINE.</b> Measure resistance of harness between inhibitor switch connector and engine ground. <b>Connector &amp; terminal</b> <b>(T7) No. 7 — Engine ground:</b> Is the measured value less than the specified value?</p>	5 Ω	Go to step 7.	Repair open circuit in harness between inhibitor switch connector and starter motor ground line.  <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between inhibitor switch connector and starter motor ground line</li> <li>• Poor contact in starter motor connector</li> <li>• Poor contact in starter motor ground</li> <li>• Starter motor</li> </ul>
<p><b>7 CHECK INHIBITOR SWITCH.</b> Measure resistance between inhibitor switch connector receptacle's terminals in select level "N" and "P" positions. <b>Terminal</b> <b>No. 7 — No. 12:</b> Is the measured value less than the specified value?</p>	1 Ω	Go to step 8.	Replace inhibitor switch. <Ref. to AT-49, Inhibitor Switch.>
<p><b>8 CHECK SELECTOR CABLE CONNECTION.</b> Is there any fault in selector cable connection to inhibitor switch?</p>	There is a fault.	Repair selector cable connection. <Ref. to CS-12, Select Cable.>	Contact SUBARU distributor service.  <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AP:DTC P0852 — NEUTRAL SWITCH INPUT CIRCUIT HIGH (MT MODEL) —

• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


• **TROUBLE SYMPTOM:**

- Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-01004

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value in neutral position?	5 V	Go to step 2.	Go to step 4.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 (+) — Chassis ground (-):</b> Is the measured value less than the specified value at except neutral position?	1 V	Go to step 3.	Go to step 5.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>4 CHECK NEUTRAL POSITION SWITCH.</b> Measure resistance between transmission harness connector terminals. <b>Connector &amp; terminal</b> <b>(T9) No. 1 — No. 2:</b> Is the measured value less than the specified value at except neutral position?	1 Ω	Go to step 5.	Repair open circuit in transmission harness or replace neutral position switch.
<b>5 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR.</b> 1) Disconnect connector from ECM. 2) Measure resistance of harness between ECM and transmission harness connector. <b>Connector &amp; terminal</b> <b>(B134) No. 8 — (B128) No. 1:</b> Is the measured value less than the specified value?	1 Ω	Go to step 6.	Repair open circuit in harness between ECM and transmission harness connector.
<b>6 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR.</b> Measure resistance of harness between transmission harness connector and engine ground. <b>Connector &amp; terminal</b> <b>(B128) No. 2 — Engine ground:</b> Is the measured value less than the specified value?	5 Ω	Go to step 7.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between transmission harness connector and engine grounding terminal • Poor contact in coupling connector

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
7 <b>CHECK POOR CONTACT.</b> Check poor contact in transmission harness connector. Is there poor contact in transmission harness connector?	There is poor contact.	Repair poor contact in transmission harness connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**AQ:DTC P1110 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (LOW INPUT) —**

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

	Step	Value	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b> Does the Subaru Select Monitor indicate DTC P1110?	DTC P1110 indicated.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>  NOTE: Atmospheric pressure sensor is built into ECM.	It is not necessary to inspect DTC P1110.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

---

## AR:DTC P1111 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (HIGH INPUT) —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

	Step	Value	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b> Does the Subaru Select Monitor indicate DTC P1111?	DTC P1111 indicated.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>  NOTE: Atmospheric pressure sensor is built into ECM.	It is not necessary to inspect DTC P1111.



**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## AS: DTC P1130 — O2 SENSOR CIRCUIT (OPEN) (BANK1 SENSOR1) —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00933

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.            2) Disconnect the connectors from ECM and front oxygen (A/F) sensor connector.            3) Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 29 — (B18) No. 3:</b>  <b>(B137) No. 19 — (B18) No. 4:</b></p> <p>Is the measured value less than the specified value?</p>	<p>1 Ω</p>	<p>Go to step 2.</p>	<p>Repair the harness and connector.</p> <p><b>NOTE:</b>            In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and front oxygen (A/F) sensor connector</li> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in front oxygen (A/F) sensor connector.            Is there poor contact in front oxygen (A/F) sensor connector?</p>	<p>There is poor contact.</p>	<p>Repair the poor contact in front oxygen (A/F) sensor connector.</p>	<p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(H4DOSTC)-38, Front Oxygen (A/F) Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## AT: DTC P1131 — O2 SENSOR CIRCUIT (SHORT) (BANK1 SENSOR1) —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00933

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 19 — Chassis ground:</b> Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 2.	Repair the ground short circuit in harness between ECM and front oxygen (A/F) sensor connector.
<p><b>2 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 29 — Chassis ground:</b> Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 3.	Repair the ground short circuit in harness between ECM and front oxygen (A/F) sensor connector.
<p><b>3 CHECK OUTPUT SIGNAL FOR ECM.</b></p> <p>1) Connect the connector to ECM. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 19 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?</p>	4.5 V	Go to step 4.	Go to step 5.
<p><b>4 CHECK OUTPUT SIGNAL FOR ECM.</b></p> <p>Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 19 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Repair the poor contact in ECM connector.
<p><b>5 CHECK OUTPUT SIGNAL FOR ECM.</b></p> <p>Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 29 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?</p>	4.95 V	Go to step 6.	Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOSTC)-38, Front Oxygen (A/F) Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>6</b>      <b>CHECK OUTPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 29 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Repair the poor contact in ECM connector.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## AU:DTC P1134 — A/F SENSOR MICRO-COMPUTER PROBLEM —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00933



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b> Does the Subaru Select Monitor indicate DTC P1134?	DTC P1134 indicated.	Replace the ECM. <Ref. to FU(H4DOSTC)- 40, Engine Con- trol Module.>	It is not necessary to inspect DTC P1134.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)




ENGINE (DIAGNOSTICS)

## AV:DTC P1199 — DIFFERENTIAL PRESSURE SENSOR —

- TROUBLE SYMPTOM:
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .



EN-01006

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK POWER SUPPLY TO DIFFERENTIAL PRESSURE SENSOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from differential pressure sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between differential pressure sensor and engine ground. <b>Connector &amp; terminal</b> <b>(B221) No. 1(+)</b> — <b>Engine ground (-):</b> Does the measured value exceed the specified value?	4.5 V	Go to step 2.	Repair or replace the harness connector between ECM and differential pressure connector.
<b>2 CHECK HARNESS BETWEEN ECM AND DIFFERENTIAL PRESSURE SENSOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance between ECM and differential pressure sensor. <b>Connector &amp; terminal</b> <b>(B221) No. 2</b> — <b>(B135) No. 19:</b> <b>(B221) No. 3</b> — <b>(B135) No. 15:</b> Is the measured value less than the specified value?	1 Ω	Go to step 3.	Repair the open circuit between ECM and differential pressure sensor.
<b>3 CHECK HARNESS BETWEEN ECM AND DIFFERENTIAL PRESSURE SENSOR.</b> Measure the resistance between differential pressure sensor and engine ground. <b>Connector &amp; terminal</b> <b>(B221) No. 3</b> — <b>engine ground:</b> Does the measured value exceed the specified value?	1 MΩ	Go to step 4.	Repair the ground short circuit between ECM and differential pressure sensor.
<b>4 CHECK DIFFERENTIAL PRESSURE SENSOR.</b> 1) Turn the ignition switch to OFF. 2) Install the vacuum pump to secondary turbocharger side hose fitting. 3) Apply 5 V to the terminals No.1 and No.2, then connect terminal NO.3 to positive side and terminal No.2 to negative side. 4) Measure the voltage between differential pressure sensor terminals. <b>Terminal</b> <b>No. 3 (+)</b> — <b>No. 2 (-):</b> Does the voltage change as in the specified range?	3.5 V at 66.7 kPa (500 mmHg, 19.69 inHg) 2.0 V at 0 kPa (0 mmHg, 0 inHg) 0.5 V at -66.7 kPa (-500 mmHg, -19.69 inHg)	Go to step 5.	Replace the differential pressure sensor.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in ECM and differential pressure sensor connectors. Is there poor contact in ECM and differential pressure sensor connectors.	There is poor contact.	Repair the poor contact in ECM and differential pressure sensor connectors.	Replace the ECM.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## AW:DTC P1230 — FUEL PUMP CONTROLLER —

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-00932

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>      <b>CHECK POWER SUPPLY CIRCUIT TO FUEL PUMP CONTROLLER.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from fuel pump controller.                  3) Turn the ignition switch to ON.                  4) Measure the voltage between fuel pump controller and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 10 (+) — Chassis ground (-):</b>                  Does the measured value exceed the specified value?</p>	10 V	Go to step 2.	Repair the power supply circuit. NOTE: In this case repair the following: <ul style="list-style-type: none"> <li>• Open or ground short circuit in harness between fuel pump relay and fuel pump controller.</li> <li>• Poor contact in fuel pump controller connector.</li> <li>• Poor contact in fuel pump relay connector.</li> </ul>
<p><b>2</b>      <b>CHECK GROUND CIRCUIT OF FUEL PUMP CONTROLLER.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Measure the resistance of harness between fuel pump controller and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 5 — Chassis ground:</b>                  Is the measured value less than the specified value?</p>	5 Ω	Go to step 3.	Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit between fuel pump controller and chassis ground.</li> <li>• Poor contact in fuel pump controller connector.</li> </ul>
<p><b>3</b>      <b>CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND FUEL PUMP CONNECTOR.</b></p> <p>1) Disconnect the connector from fuel pump.                  2) Measure the resistance of harness between fuel pump controller and fuel pump connector.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 7 — (R58) No. 2:</b>  <b>(R122) No. 6 — (R58) No. 1:</b>                  Is the measured value less than the specified value?</p>	1 Ω	Go to step 4.	Repair the open circuit between fuel pump controller and fuel pump.
<p><b>4</b>      <b>CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND FUEL PUMP CONNECTOR.</b></p> <p>Measure the resistance of harness between fuel pump controller and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 7 — Chassis ground:</b>  <b>(R122) No. 6 — Chassis ground:</b>                  Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 5.	Repair the ground short circuit between fuel pump controller and fuel pump.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>5 CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ECM.                      3) Measure the resistance of harness between fuel pump controller and ECM connector.  <b>Connector &amp; terminal</b>                      (R122) No. 9 — (B134) No. 13:                      (R122) No. 8 — (B136) No. 16:                      Is the measured value less than the specified value?</p>	1 Ω	Go to step 6.	Repair the harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit between fuel pump controller and ECM. • Poor contact in fuel pump controller and ECM connector.
<p><b>6 CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND ECM CONNECTOR.</b>                      Measure the resistance of harness between fuel pump controller and chassis ground.  <b>Connector &amp; terminal</b>                      (R122) No. 9 — Chassis ground:                      (R122) No. 8 — Chassis ground:                      Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 7.	Repair the ground short circuit between fuel pump controller and ECM.
<p><b>7 CHECK POOR CONTACT.</b>                      Check poor contact in ECM and fuel pump controller connector.                      Is there poor contact in ECM and fuel pump controller connector.</p>	There is poor contact.	Repair the poor contact in ECM and fuel pump controller.	Replace the fuel pump controller. <Ref. to FU(H4DOSTC)-43, Fuel Pump Controller.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AX:DTC P1235 — INTAKE CONTROL SOLENOID VALVE CIRCUIT LOW —


• **TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• **WIRING DIAGRAM:**





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK INPUT SIGNAL TO ECM.</b></p> <p>1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 22 (+) — Chassis ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	Even if MI lights up, the circuit has returned to a normal condition at this time. Contact SUBARU distributor service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN INTAKE AIR VALVE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from intake air valve control solenoid valve and ECM. 3) Measure the resistance of harness between intake air valve control solenoid valve connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B220) No. 10 — Engine ground:</b></p> <p>Does the measured value exceed the specified value?</p>	1 M $\Omega$	Go to step 3.	Repair the ground short circuit in harness between ECM and intake air valve control solenoid valve connector.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN INTAKE AIR VALVE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM and intake air valve control solenoid valve of harness connector.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 22 — (B220) No. 10:</b></p> <p>Is the measured value less than the specified value?</p>	1 $\Omega$	Go to step 4.	Repair the open circuit in harness between ECM and intake air valve control solenoid valve connector.
<p><b>4</b></p> <p><b>CHECK INTAKE AIR VALVE CONTROL SOLENOID VALVE.</b></p> <p>Measure the resistance between intake air valve control solenoid valve terminals.</p> <p><b>Terminals</b> <b>No. 9 — No. 10:</b></p> <p>Is the measured value within the specified value?</p>	37 — 44 $\Omega$	Go to step 5.	Replace the intake air valve control solenoid valve. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
<p><b>5</b></p> <p><b>CHECK POWER SUPPLY TO INTAKE AIR VALVE CONTROL SOLENOID VALVE.</b></p> <p>1) Turn the ignition switch to ON. 2) Measure the voltage between intake air valve control solenoid valve and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B220) No. 9 (+) — Engine ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Repair the open circuit in harness between main relay and intake air valve control solenoid valve connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in intake air valve control solenoid valve and ECM connectors. Is there poor contact in intake air valve control solenoid valve and ECM connectors?	There is poor contact.	Repair the poor contact in intake air valve control solenoid valve and ECM connectors.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## AY:DTC P1236 — INTAKE CONTROL SOLENOID VALVE CIRCUIT HIGH —


### • TROUBLE SYMPTOM:

- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL TO ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 22 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 3.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<b>3 CHECK HARNESS BETWEEN INTAKE AIR VALVE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from intake air valve control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 12 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair the battery short circuit in harness between ECM and intake air valve control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 4.
<b>4 CHECK INTAKE AIR VALVE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between intake air valve control solenoid valve terminals. <b>Terminals</b> <b>No. 9 — No. 10:</b> Is the measured value less than the specified value?	1 Ω	Replace the intake air valve control solenoid valve <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.> and ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 5.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in ECM and intake air valve control solenoid valve connectors. Is there poor contact in ECM and intake air valve control solenoid valve connectors?	There is poor contact.	Repair the poor contact in ECM and intake air valve control solenoid valve connectors.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AZ:DTC P1237 — EXHAUST CONTROL VALVE SOLENOID CIRCUIT LOW (POSITIVE PRESSURE) —


• **TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-00939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>     <b>CHECK OUTPUT SIGNAL FROM ECM.</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B136) No. 1 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Even if MI lights up, the circuit has returned to a normal condition at this time. Contact with your Subaru distributor.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<p><b>2</b>     <b>CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL SOLENOID VALVE (POSITIVE PRESSURE) AND ECM CONNECTOR.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connectors from exhaust valve control solenoid valve (positive pressure) and ECM.            3) Measure the resistance of harness between exhaust valve control solenoid valve (positive pressure) connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(B220) No. 8 — Engine ground:</b>            Does the measured value exceed the specified value?</p>	1 M $\Omega$	Repair the ground short circuit in harness between ECM and exhaust valve control solenoid valve (positive pressure) connector.	Go to step 3.
<p><b>3</b>     <b>CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL SOLENOID VALVE (POSITIVE PRESSURE) AND ECM CONNECTOR.</b>            Measure the resistance of harness between ECM and exhaust valve control solenoid valve (positive pressure) of harness connector.  <b>Connector &amp; terminal</b>  <b>(B136) No. 1 — (B220) No. 8:</b>            Does the measured value exceed the specified value?</p>	1 M $\Omega$	Go to step 4.	Repair the open circuit in harness between ECM and exhaust valve control solenoid valve (positive pressure) connector.
<p><b>4</b>     <b>CHECK EXHAUST VALVE CONTROL SOLENOID VALVE (POSITIVE PRESSURE).</b>            Measure the resistance between exhaust valve control solenoid valve (positive pressure) terminals.  <b>Terminals</b>  <b>No. 7 — No. 8:</b>            Is the measured value within the specified value?</p>	37 — 44 $\Omega$	Go to step 5.	Replace the exhaust valve control solenoid valve (positive pressure). <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
<p><b>5</b>     <b>CHECK POWER SUPPLY TO EXHAUST VALVE CONTROL SOLENOID VALVE (POSITIVE PRESSURE).</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between exhaust valve control solenoid valve (positive pressure) and engine ground.  <b>Connector &amp; terminal</b>  <b>(B220) No. 7 (+) — Engine ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Repair open circuit in harness between main relay and exhaust valve control solenoid valve (positive pressure) connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in exhaust valve control solenoid valve (positive pressure) and ECM connectors. Is there poor contact in exhaust valve control solenoid valve (positive pressure) and ECM connectors?	There is poor contact.	Repair the poor contact in exhaust valve control solenoid valve (positive pressure) and ECM connectors.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BA:DTC P1238 — EXHAUST CONTROL VALVE SOLENOID CIRCUIT HIGH (POSITIVE PRESSURE) —


• **TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-00939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL TO ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 1 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 3.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b> Check the poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<b>3 CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL SOLENOID VALVE (POSITIVE PRESSURE) AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from exhaust valve control solenoid valve (positive pressure). 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 1 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair the battery short circuit in harness between ECM and exhaust valve control solenoid valve (positive pressure) connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 4.
<b>4 CHECK EXHAUST VALVE CONTROL SOLENOID VALVE (POSITIVE PRESSURE).</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between exhaust valve control solenoid valve (positive pressure) terminals. <b>Terminals</b> <b>No. 7 — No. 8:</b> Is the measured value less than the specified value?	1 Ω	Replace the exhaust valve control solenoid valve (positive pressure). <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.> and ECM <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 5.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in ECM and exhaust valve control solenoid valve (positive pressure). Is there poor contact in ECM and exhaust valve control solenoid valve (positive pressure)?	There is poor contact.	Repair the poor contact in ECM and exhaust valve control solenoid valve (positive pressure).	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BB:DTC P1239 — EXHAUST CONTROL VALVE SOLENOID CIRCUIT LOW (NEGATIVE PRESSURE) —


• **TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-00939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK INPUT SIGNAL TO ECM.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 3 (+) — Chassis ground (-):</b>                      Does the measured value exceed the specified value?</p>	10 V	Even if MI lights up, the circuit has returned to a normal condition at this time. Contact SUBARU distributor service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL SOLENOID VALVE (NEGATIVE PRESSURE) AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connectors from exhaust valve control solenoid valve (negative pressure) and ECM.                      3) Measure the resistance of harness between exhaust valve control solenoid valve (negative pressure) connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 3 — Engine ground:</b>                      Does the measured value exceed the specified value?</p>	1 M $\Omega$	Repair the ground short circuit in harness between ECM and exhaust valve control solenoid valve (negative pressure) connector.	Go to step 3.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL SOLENOID VALVE (NEGATIVE PRESSURE) AND ECM CONNECTOR.</b>                      Measure the resistance of harness between ECM and exhaust valve control solenoid valve (negative pressure) of harness connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 3 — (B220) No. 6:</b>                      Is the measured value less than the specified value?</p>	1 $\Omega$	Go to step 4.	Repair the open circuit in harness between ECM and exhaust valve control solenoid valve (negative pressure) connector.
<p><b>4</b></p> <p><b>CHECK EXHAUST VALVE CONTROL SOLENOID VALVE. (NEGATIVE PRESSURE)</b>                      Measure the resistance between exhaust valve control solenoid valve (negative pressure) terminals.</p> <p><b>Terminals</b>  <b>No. 5 — No. 6:</b>                      Is the measured value within the specified value?</p>	30 — 34 $\Omega$	Go to step 5.	Replace the exhaust valve control solenoid valve (negative pressure). <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>5</b>     <b>CHECK POWER SUPPLY TO EXHAUST VALVE CONTROL SOLENOID VALVE (NEGATIVE PRESSURE).</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between exhaust valve control solenoid valve (negative pressure) and engine ground.  <b>Connector &amp; terminal</b>  <b>(B220) No. 5 (+) — Engine ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Repair the open circuit in harness between main relay and exhaust valve control solenoid valve (negative pressure) connector.
<p><b>6</b>     <b>CHECK POOR CONTACT.</b>            Check poor contact in exhaust valve control solenoid valve (negative pressure) and ECM connectors.            Are there poor contact in exhaust valve control solenoid valve (negative pressure) and ECM connectors?</p>	There are poor contacts.	Repair the poor contact in exhaust valve control solenoid valve (negative pressure) and ECM connectors.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## BC:DTC P1240 — EXHAUST CONTROL VALVE SOLENOID CIRCUIT HIGH (NEGATIVE PRESSURE) —


### • TROUBLE SYMPTOM:

- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1 CHECK INPUT SIGNAL TO ECM.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B136) No. 3 (+) — Chassis ground (-):</b>                      Does the measured value exceed the specified value?</p>	10 V	Go to step 3.	Go to step 2.
<p><b>2 CHECK POOR CONTACT.</b>                      Check poor contact in ECM connector.                      Is there poor contact in ECM connector?</p>	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<p><b>3 CHECK HARNESS BETWEEN EXHAUST VALVE CONTROL SOLENOID VALVE (NEGATIVE PRESSURE) AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from exhaust valve control solenoid valve (negative pressure).                      3) Turn the ignition switch to ON.                      4) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B136) No. 3 (+) — Chassis ground (-):</b>                      Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between ECM and exhaust valve control solenoid valve (negative pressure) connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 4.
<p><b>4 CHECK EXHAUST VALVE CONTROL SOLENOID VALVE (NEGATIVE PRESSURE).</b>                      1) Turn the ignition switch to OFF.                      2) Measure the resistance between exhaust valve control solenoid valve (negative pressure) terminals.  <b>Terminals</b>  <b>No. 5 — No. 6:</b>                      Is the measured value less than the specified value?</p>	1 Ω	Replace the exhaust valve control solenoid valve (negative pressure) <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.> and ECM <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 5.
<p><b>5 CHECK POOR CONTACT.</b>                      Check poor contact in ECM and exhaust valve control solenoid valve (negative pressure) connectors.                      Are there poor contact in ECM and exhaust valve control solenoid valve (negative pressure) connectors?</p>	There are poor contacts.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BD:DTC P1241 — 2STAGE TWIN TURBO SYSTEM (SINGLE) —

### • TROUBLE SYMPTOM:

- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:

Step	Value	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b> Is any other DTC displayed?	DTC indicated.	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 <b>CHECK OPERATION OF RELIEF VALVE CONTROL SOLENOID VALVE 2.</b> Operate the relief valve control solenoid valve 2. <Ref. to EN(H4DOSTC)-36, Compulsory Valve Operation Check Mode.> Does the relief valve control solenoid valve 2 produce operating sound?	Operating sound produced.	Go to step 3.	Replace the relief valve control solenoid valve 2. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
3 <b>CHECK OPERATION OF EXHAUST CONTROL VALVE.</b> 1) Operate the exhaust valve control solenoid valve. <Ref. to EN(H4DOSTC)-36, Compulsory Valve Operation Check Mode.> 2) Check the operation of exhaust control valve actuator. Does the actuator rod operate correctly?  NOTE: Actuator rod operates in approx. 7 second cycle, and stroke is approx. 30 mm (1.18 in).	Operates correctly.	Go to step 4.	Check the exhaust valve control solenoid valve and vacuum hose. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
4 <b>CHECK OPERATION OF INTAKE AIR CONTROL VALVE.</b> 1) Operate the intake air valve control solenoid valve. <Ref. to EN(H4DOSTC)-36, Compulsory Valve Operation Check Mode.> 2) Check the operation of intake air control valve actuator. Does the actuator rod operate correctly?  NOTE: Actuator rod operates in approx. 2 second cycle, and stroke is approx. 12 mm (0.47 in).	Operates correctly.	Go to step 5.	Check the intake air control solenoid valve and vacuum hose. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
5 <b>CHECK RELIEF VALVE.</b> 1) Remove the relief valve. 2) Check the relief valve. Is there a fault in the relief valve and hose routing?	There is no problem.	Go to step 6.	Replace or repair the relief valve and vacuum hose.
6 <b>CHECK VACUUM HOSES OF EXHAUST VALVE CONTROL SOLENOID VALVE (POSITIVE PRESSURE).</b> Are there cracks, stuck or improper routing on vacuum hose?	There is no problem.	Go to step 7.	Repair or replace the vacuum hoses.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>7 CHECK VACUUM HOSES OF DIFFERENTIAL PRESSURE SENSOR.</b> Are there cracks, stuck or improper routing on vacuum hose?	There is no problem.	Go to step <b>8</b> .	Repair or replace the vacuum hoses.
<b>8 CHECK VACUUM HOSES OF PRIMARY TURBOCHARGER WASTEGATE CONTROL VALVE.</b> Are there cracks, stuck or improper routing on vacuum hose?	There is no problem.	Go to step <b>9</b> .	Repair or replace the vacuum hoses.
<b>9 CHECK VACUUM HOSES BETWEEN SOLENOID BOX AND SURGE TANK.</b> Are there cracks, stuck or improper routing on vacuum hose?	There is no problem.	Go to step <b>10</b> .	Repair or replace the vacuum hoses.
<b>10 CHECK PRIMARY TURBOCHARGER WASTEGATE VALVE.</b> Is there a fault on the primary turbocharger wastegate valve?	There is no problem.	Go to step <b>11</b> .	Replace the primary turbocharger. <Ref. to IN(H4DOSTC)-15, Turbocharger.>
<b>11 CHECK LH AND RH INTAKE DUCT.</b> Are there cracks or stuck on the LH and RH intake duct?	There is no problem.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Replace the air intake duct. <Ref. to IN(H4DOSTC)-12, Intake Duct.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BE:DTC P1242 — 2STAGE TWIN TURBO SYSTEM (TWIN) —

### • TROUBLE SYMPTOM:

- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:

Step	Value	Yes	No
<b>1 CHECK ANY OTHER DTC ON DISPLAY.</b> Is any other DTC displayed?	DTC indicated.	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2 CHECK OPERATION OF RELIEF VALVE CONTROL SOLENOID VALVE 2.</b> Operate the relief valve control solenoid valve 2. <Ref. to EN(H4DOSTC)-36, Compulsory Valve Operation Check Mode.> Does the relief valve control solenoid valve 2 produce operating sound?	Operating sound produced.	Go to step 3.	Replace the relief valve control solenoid valve 2. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
<b>3 CHECK OPERATION OF EXHAUST CONTROL VALVE.</b> 1) Operate the exhaust valve control solenoid valve. <Ref. to EN(H4DOSTC)-36, Compulsory Valve Operation Check Mode.> 2) Check the operation of exhaust control valve actuator. Does the actuator rod operate correctly?  NOTE: Actuator rod operates in approx. 7 second cycle, and stroke is approx. 30 mm (1.18 in).	Operate correctly.	Go to step 4.	Check the exhaust valve control solenoid valve and vacuum hose. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
<b>4 CHECK OPERATION OF INTAKE AIR CONTROL VALVE.</b> 1) Operate the intake air valve control solenoid valve. <Ref. to EN(H4DOSTC)-36, Compulsory Valve Operation Check Mode.> 2) Check the operation of intake air control valve actuator. Does the actuator rod operate correctly?  NOTE: Actuator rod operates in approx. 2 second cycle, and stroke is approx. 12 mm (0.47 in).	Operate correctly.	Go to step 5.	Check the intake valve control solenoid valve and vacuum hose. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
<b>5 CHECK RELIEF VALVE.</b> 1) Remove the relief valve. 2) Check the relief valve. Is there a fault in the relief valve and hose routing?	There is no problem.	Go to step 6.	Replace or repair the relief valve and vacuum hose.
<b>6 CHECK VACUUM HOSES OF EXHAUST VALVE CONTROL SOLENOID VALVE (POSITIVE PRESSURE).</b> Are there cracks, stuck or improper routing on vacuum hose?	There is no problem.	Go to step 7.	Repair or replace the vacuum hoses.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>7 CHECK VACUUM HOSES OF DIFFERENTIAL PRESSURE SENSOR.</b> Are there cracks, stuck or improper routing on vacuum hose?	There is no problem.	Go to step <b>8</b> .	Repair or replace the vacuum hoses.
<b>8 CHECK VACUUM HOSES OF PRIMARY TURBOCHARGER WASTEGATE CONTROL VALVE.</b> Are there cracks, stuck or improper routing on vacuum hose?	There is no problem.	Go to step <b>9</b> .	Repair or replace the vacuum hoses.
<b>9 CHECK VACUUM HOSES BETWEEN SOLENOID BOX AND SURGE TANK.</b> Are there cracks, stuck or improper routing on vacuum hose?	There is no problem.	Go to step <b>10</b> .	Repair or replace the vacuum hoses.
<b>10 CHECK PRIMARY TURBOCHARGER WASTEGATE VALVE.</b> Is there a fault on the primary turbocharger wastegate valve?	There is no problem.	Go to step <b>11</b> .	Replace the primary turbocharger. <Ref. to IN(H4DOSTC)-15, Turbocharger.>
<b>11 CHECK LH AND RH INTAKE DUCT.</b> Are there cracks or stuck on the LH and RH intake duct?	There is no problem.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Replace the air intake duct. <Ref. to IN(H4DOSTC)-12, Intake Duct.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### BF:DTC P1247 — RELIEF VALVE CONTROL SOLENOID VALVE 1 CIRCUIT LOW


**• TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

**• WIRING DIAGRAM:**



EN-00939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK INPUT SIGNAL TO ECM.</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 12 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Even if MI lights up, the circuit has returned to a normal condition at this time. Contact with your Subaru distributor.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN RELIEF VALVE CONTROL SOLENOID VALVE 1 AND ECM CONNECTOR.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connectors from relief valve control solenoid valve 1 and ECM.            3) Measure the resistance of harness between relief valve control solenoid valve 1 connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B220) No. 4 — Engine ground:</b>            Does the measured value exceed the specified value?</p>	1 M $\Omega$	Go to step 3.	Repair the ground short circuit in harness between ECM and relief valve control solenoid valve 1 connector.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN RELIEF VALVE CONTROL SOLENOID VALVE 1 AND ECM CONNECTOR.</b>            Measure the resistance of harness between ECM and relief valve control solenoid valve 1 of harness connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 12 — (B220) No. 4:</b>            Is the measured value less than the specified value?</p>	1 $\Omega$	Go to step 4.	Repair the open circuit in harness between ECM and relief valve control solenoid valve 1 connector.
<p><b>4</b></p> <p><b>CHECK RELIEF VALVE CONTROL SOLENOID VALVE 1.</b>            Measure the resistance between relief valve control solenoid valve 1 terminals.</p> <p><b>Terminals</b>  <b>No. 3 — No. 4:</b>            Is the measured value within the specified value?</p>	37 — 44 $\Omega$	Go to step 5.	Replace the relief valve control solenoid valve 1. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
<p><b>5</b></p> <p><b>CHECK POWER SUPPLY TO RELIEF VALVE CONTROL SOLENOID VALVE 1.</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between relief valve control solenoid valve 1 and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B220) No. 3 (+) — Engine ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Repair the open circuit in harness between main relay and relief valve control solenoid valve 1 connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in relief valve control solenoid valve 1 and ECM connectors. Are there poor contact in relief valve control solenoid valve 1 and ECM connectors?	There are poor contacts.	Repair the poor contact in relief valve control solenoid valve 1 and ECM connectors.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BG:DTC P1248 — RELIEF VALVE CONTROL SOLENOID VALVE 1 CIRCUIT HIGH —


• **TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-00939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>    <b>CHECK INPUT SIGNAL TO ECM.</b>            1) Turn the ignition switch to ON.            2) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B136) No. 12 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Go to step 3.	Go to step 2.
<p><b>2</b>    <b>CHECK POOR CONTACT.</b>            Check poor contact in ECM connector.            Is there poor contact in ECM connector?</p>	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<p><b>3</b>    <b>CHECK HARNESS BETWEEN RELIEF VALVE CONTROL SOLENOID VALVE 1 AND ECM CONNECTOR.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connector from relief valve control solenoid valve 1.            3) Turn the ignition switch to ON.            4) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B136) No. 12 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value?</p>	10 V	Repair the battery short circuit in harness between ECM and relief valve control solenoid valve 1 connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 4.
<p><b>4</b>    <b>CHECK RELIEF VALVE CONTROL SOLENOID VALVE 1.</b>            1) Turn the ignition switch to OFF.            2) Measure the resistance between relief valve control solenoid valve 1 terminals.  <b>Terminals</b>  <b>No. 3 — No. 4:</b>            Is the measured value less than the specified value?</p>	1 Ω	Replace the relief valve control solenoid valve 1 <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.> and replace ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 5.
<p><b>5</b>    <b>CHECK POOR CONTACT.</b>            Check poor contact in ECM and relief valve control solenoid valve 1 connectors.            Are there poor contact in ECM and relief valve control solenoid valve 1 connectors?</p>	There are poor contacts.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
**ENGINE (DIAGNOSTICS)**


**BH:DTC P1249 — RELIEF VALVE CONTROL SOLENOID VALVE 2 CIRCUIT LOW —**

- **TROUBLE SYMPTOM:**
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN-00939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK INPUT SIGNAL TO ECM.</b></p> <p>1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B136) No. 11 (+) — Chassis ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	<p>Even if MI lights up, the circuit has returned to a normal condition at this time. Contact SUBARU distributor service.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	Go to step 2.
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN RELIEF VALVE CONTROL SOLENOID VALVE 2 AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from relief valve control solenoid valve 2 and ECM. 3) Measure the resistance of harness between relief valve control solenoid valve 2 connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B220) No. 2 — Engine ground:</b></p> <p>Does the measured value exceed the specified value?</p>	1 M $\Omega$	Go to step 3.	Repair the ground short circuit in harness between ECM and relief valve control solenoid valve 2 connector.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN RELIEF VALVE CONTROL SOLENOID VALVE 2 AND ECM CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM and relief valve control solenoid valve 2 of harness connector.</p> <p><b>Connector &amp; terminal</b> <b>(B136) No. 11 — (B220) No. 2:</b></p> <p>Is the measured value less than the specified value?</p>	1 $\Omega$	Go to step 4.	Repair the open circuit in harness between ECM and relief valve control solenoid valve 2 connector.
<p><b>4</b></p> <p><b>CHECK RELIEF VALVE CONTROL SOLENOID VALVE 2.</b></p> <p>Measure the resistance between relief valve control solenoid valve 2 terminals.</p> <p><b>Terminals</b> <b>No. 1 — No. 2:</b></p> <p>Is the measured value within the specified value?</p>	37 — 44 $\Omega$	Go to step 5.	Replace the relief valve control solenoid valve 2. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.>
<p><b>5</b></p> <p><b>CHECK POWER SUPPLY TO RELIEF VALVE CONTROL SOLENOID VALVE 2.</b></p> <p>1) Turn the ignition switch to ON. 2) Measure the voltage between wastegate control solenoid valve and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B220) No. 1 (+) — Engine ground (-):</b></p> <p>Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Repair the open circuit in harness between main relay and relief valve control solenoid valve 2 connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM and relief valve control solenoid valve 2 and ECM connectors. Are there poor contact in ECM and relief valve control solenoid valve 2 and ECM connectors?	There are poor contacts.	Repair the poor contact in ECM and relief valve control solenoid valve 2 and ECM connectors.	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**MEMO:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BI: DTC P1250 — RELIEF VALVE CONTROL SOLENOID VALVE 2 CIRCUIT HIGH —


### • TROUBLE SYMPTOM:

- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00939



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL TO ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 11 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Go to step 3.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair the poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<b>3 CHECK HARNESS BETWEEN RELIEF VALVE CONTROL SOLENOID VALVE 2 AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from relief valve control solenoid valve 2. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 11 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair the battery short circuit in harness between ECM and relief valve control solenoid valve 2 connector. After repair, replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 4.
<b>4 CHECK RELIEF VALVE CONTROL SOLENOID VALVE 2.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between relief valve control solenoid valve 2 terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b> Is the measured value less than the specified value?	1 Ω	Replace the relief valve control solenoid valve 2. <Ref. to IN(H4DOSTC)-19, Solenoid Box Assembly.> and replace ECM <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Go to step 5.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in ECM and relief valve control solenoid valve 2 connectors. Are there poor contact in ECM and relief valve control solenoid valve 2 connectors?	There are poor contacts.	Repair the poor contact in ECM and relief valve control solenoid valve 2 connectors.	Replace the ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### BJ:DTC P1507 — IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —


#### • TROUBLE SYMPTOM:

- Engine keeps running at higher revolution than specified idling revolution.
- Fuel is cut according to fail-safe function.

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

#### • WIRING DIAGRAM:



EN-00947

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK ANY OTHER DTC ON DISPLAY.</b> Is any other DTC displayed?	DTC indicated.	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOSTC)-62, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0507.	Go to step 2.
<b>2 CHECK AIR INTAKE SYSTEM.</b> 1) Turn the ignition switch to ON. 2) Start the engine, and idle it. 3) Check the following items: •Loose installation of intake manifold, idle air control solenoid valve and throttle body •Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket •Disconnections of vacuum hoses Is there a fault in the air intake system?	There is no problem.	Go to step 3.	Repair the air suction and leaks.
<b>3 CHECK THROTTLE CABLE.</b> Does the throttle cable have play for adjustment?	Cable has play correctly.	Go to step 4.	Adjust the throttle cable. <Ref. to SP(H4SO)-10, Accelerator Control Cable.>
<b>4 CHECK AIR BY-PASS LINE.</b> 1) Turn the ignition switch to OFF. 2) Remove the idle air control solenoid valve from throttle body. <Ref. to FU(H4DOSTC)-35, Idle Air Control Solenoid Valve.> 3) Confirm that there are no foreign particles in the by-pass air line. Are foreign particles in the by-pass air line?	Foreign particles are in the by-pass air line.	Remove the foreign particles from by-pass air line.	Replace the idle air control solenoid valve. <Ref. to FU(H4DOSTC)-35, Idle Air Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BK:DTC P1518 — STARTER SWITCH CIRCUIT LOW INPUT —


### • TROUBLE SYMPTOM:

- Failure of engine to start

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00930

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1</b> <b>CHECK OPERATION OF STARTER MOTOR.</b> Does the starter motor operate when ignition switch to "ST"?	Operates.	Repair the harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open or ground short circuit in harness between ECM and starter motor connector.</li> <li>• Poor contact in ECM connector.</li> </ul>	Check the starter motor circuit. <Ref. to EN(H4DOSTC)-52, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

## BL:DTC P1560 — BACK-UP VOLTAGE CIRCUIT MALFUNCTION —

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-00931

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn the ignition switch to OFF. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 10 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair the poor contact in ECM connector.	Go to step 2.
<b>2 CHECK HARNESS BETWEEN ECM AND MAIN FUSE BOX CONNECTOR.</b> 1) Disconnect the connector from ECM. 2) Measure the resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 10 — Chassis ground:</b> Does the measured value exceed the specified value?	1 MΩ	Go to step 3.	Repair the ground short circuit in harness between ECM connector and battery terminal.
<b>3 CHECK FUSE SBF-5.</b> Is the fuse blown?	Fuse is blown-out.	Replace the fuse.	Repair the harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and battery</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in battery terminal</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BM:DTC P1698 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT MALFUNCTION (LOW INPUT) —


### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-01007



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b>     <b>CHECK OUTPUT SIGNAL FROM ECM.</b>            1) Start engine, and warm-up the engine.            2) Turn ignition switch to OFF.            3) Turn ignition switch to ON.            4) Measure voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 14 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value?</p>	3 V	Repair poor contact in ECM connector.	Go to step 2.
<p><b>2</b>     <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b>            1) Turn ignition switch to OFF.            2) Disconnect connectors from ECM and TCM.            3) Measure resistance of harness between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 14 — Chassis ground:</b>            Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 3.	Repair ground short circuit in harness between ECM and TCM connector.
<p><b>3</b>     <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b>            Measure resistance of harness between ECM and TCM connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 14 — (B55) No. 10:</b>            Is the measured value less than the specified value?</p>	1 Ω	Repair poor contact in ECM or TCM connector.	Repair open circuit in harness between ECM and TCM connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BN:DTC P1699 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT MALFUNCTION (HIGH INPUT) —


### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-01007

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p><b>1</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b></p> <p>1) Start engine, and warm-up the engine.            2) Turn ignition switch to OFF.            3) Disconnect connector from TCM.            4) Turn ignition switch to ON.            5) Measure voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 14 (+) — Chassis ground (-):</b>            Is the measured value less than the specified value?</p>	3 V	Go to step 2.	Repair battery short circuit in harness between ECM and TCM connector. After repair, replace ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.            2) Measure voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 14 (+) — Chassis ground (-):</b>            Does the measured value exceed the specified value by shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	10 V	Repair battery short circuit in harness between ECM and TCM connector. After repair, replace ECM. <Ref. to FU(H4DOSTC)-40, Engine Control Module.>	Contact SUBARU distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BO:DTC P1711 — ENGINE TORQUE CONTROL SIGNAL #1 CIRCUIT MALFUNCTION —

### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault


### • TROUBLE SYMPTOM:

- Excessive shift shock

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.> .

### • WIRING DIAGRAM:



EN-01008

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 19 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	4.5 V	Go to step 2.	Go to step 4.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 19 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair battery short circuit in harness between ECM and TCM connector.	Go to step 3.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>4 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connectors from ECM and TCM. 3) Measure resistance of harness between ECM and TCM connector. <b>Connector &amp; terminal</b> <b>(B134) No. 19 — (B56) No. 5:</b> Is the measured value less than the specified value?	1 $\Omega$	Go to step 5.	Repair open circuit in harness between ECM and TCM connector.
<b>5 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 19 — Chassis ground:</b> Does the measured value exceed the specified value?	1 M $\Omega$	Go to step 6.	Repair ground short circuit in harness between ECM and TCM connector.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in TCM connector. Is there poor contact in TCM connector?	There is poor contact.	Repair poor contact in TCM connector.	Replace TCM. <Ref. to AT-76, Transmission Control Module (TCM).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BP:DTC P1712 — ENGINE TORQUE CONTROL SIGNAL #2 CIRCUIT MALFUNCTION —

• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


• **TROUBLE SYMPTOM:**

- Excessive shift shock

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(H4DOSTC)-35, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOSTC)-33, OPERATION, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-01009

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 18 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	4.5 V	Go to step 2.	Go to step 4.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 18 (+) — Chassis ground (-):</b> Does the measured value exceed the specified value?	10 V	Repair battery short circuit in harness between ECM and TCM connector.	Go to step 3.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Contact SUBARU distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>4 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connectors from ECM and TCM. 3) Measure resistance of harness between ECM and TCM connector. <b>Connector &amp; terminal</b> <b>(B134) No. 18 — (B56) No. 14:</b>	1 $\Omega$	Go to step 5.	Repair open circuit in harness between ECM and TCM connector.
<b>5 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 18 — Chassis ground:</b> Is the measured value less than the specified value?	10 $\Omega$	Go to step 6.	Repair ground short circuit in harness between ECM and TCM connector.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in TCM connector. Is there poor contact in TCM connector?	There is poor contact.	Repair poor contact in TCM connector.	Replace TCM. <Ref. to AT-76, Transmission Control Module (TCM).>

# GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

## 18. General Diagnostic Table

### A: INSPECTION

#### 1. ENGINE

NOTE:

Malfunction of parts other than those listed is also possible. <Ref. to ME(H4DOSTC)-90, Engine Trouble in General.>

Symptom	Problem parts
1. Engine does not start. (internal combustion does not occur.)	1) ECM power supply 2) Engine ground terminal 3) Crankshaft position sensor 4) Camshaft position sensor 5) Fuel pump 6) Pressure regulator 7) Ignition coil & ignitor 8) Spark plug 9) Fuel injector
2. Engine does not start. (internal combustion occurs.)	1) ECM power supply 2) Spark plug 3) Engine coolant temperature sensor 4) Pressure regulator 5) Pressure sensor 6) Fuel pump 7) Fuel injector 8) Camshaft position sensor 9) Crankshaft position sensor 10) Idle air control solenoid valve
3. Engine does not start. (engine stalls after internal combustion.)	1) ECM power supply 2) Pressure sensor 3) Engine coolant temperature sensor 4) Spark plug 5) Ignition coil 6) Fuel pump 7) Pressure regulator 8) Fuel injector 9) Idle air control solenoid valve
4. Engine stalls during idling.	1) Idle air control solenoid valve 2) Pressure sensor 3) Mass air flow and intake temperature sensor 4) Ignition parts (*1) 5) Engine coolant temperature sensor (*2) 6) Crankshaft position sensor (*3) 7) Camshaft position sensor (*3) 8) Fuel injection parts (*4)
5. Rough idling	1) Idle air control solenoid valve 2) Pressure sensor 3) Mass air flow and intake temperature sensor 4) Engine coolant temperature sensor (*2) 5) Ignition parts (*1) 6) Air intake system (*5) 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Crankshaft position sensor (*3) 10) Camshaft position sensor (*3) 11) Oxygen sensor 12) Fuel pump and fuel pump relay



# GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

Symptom	Problem parts
6. Engine does not return to idle.	1) Idle air control solenoid valve 2) Engine coolant temperature sensor 3) Accelerator cable (*6) 4) Throttle position sensor 5) Pressure sensor 6) Mass air flow sensor
7. Poor acceleration	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Throttle position sensor 4) Fuel injection parts (*4) 5) Fuel pump and fuel pump relay 6) Engine coolant temperature sensor (*2) 7) Crankshaft position sensor (*3) 8) Camshaft position sensor (*3) 9) A/C switch and A/C cut relay 10) Engine torque control signal circuit 11) Ignition parts (*1)
8. Engine stalls or engine sags or hesitates at acceleration.	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Crankshaft position sensor (*3) 5) Camshaft position sensor (*3) 6) Purge control solenoid valve 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Fuel pump and fuel pump relay
9. Surge	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Crankshaft position sensor (*3) 5) Camshaft position sensor (*3) 6) Fuel injection parts (*4) 7) Throttle position sensor 8) Fuel pump and fuel pump relay
10. Spark knock	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor 4) Knock sensor 5) Fuel injection parts (*4) 6) Fuel pump and fuel pump relay
11. After burning in exhaust system	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Fuel injection parts (*4) 5) Fuel pump and fuel pump relay

- \*1: Check the ignition coil & ignitor assembly and spark plug.
- \*2: Indicate the symptom occurring only in cold temperatures.
- \*3: Ensure the secure installation.
- \*4: Check the fuel injector, fuel pressure regulator and fuel filter.
- \*5: Inspect air leak in the air intake system.
- \*6: Adjust the accelerator cable.

# GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

---

**MEMO:**