

ENGINE SECTION 2

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

FUEL INJECTION (FUEL SYSTEMS) FU(H6DO)

**EMISSION CONTROL
(AUX. EMISSION CONTROL DEVICES) EC(H6DO)**

INTAKE (INDUCTION) IN(H6DO)

MECHANICAL ME(H6DO)

EXHAUST EX(H6DO)

COOLING CO(H6DO)

LUBRICATION LU(H6DO)

SPEED CONTROL SYSTEMS SP(H6DO)

IGNITION IG(H6DO)

STARTING/CHARGING SYSTEMS SC(H6DO)

ENGINE (DIAGNOSTICS) EN(H6DO)

ENGINE (DIAGNOSTICS)

EN(H6DO)

	Page
1. Basic Diagnostic Procedure	2
2. Check List for Interview	4
3. General Description	6
4. Electrical Components Location.....	10
5. Engine Control Module (ECM) I/O Signal	24
6. Engine Condition Data	29
7. Transmission Control Module (TCM) I/O Signal	30
8. Data Link Connector	31
9. OBD-II General Scan Tool	32
10. Subaru Select Monitor.....	34
11. Read Diagnostic Trouble Code	46
12. Inspection Mode	47
13. Drive Cycle.....	52
14. Clear Memory Mode.....	54
15. Compulsory Valve Operation Check Mode	55
16. Engine Malfunction Indicator Lamp (MI)	58
17. Diagnostics for Engine Starting Failure	71
18. List of Diagnostic Trouble Code (DTC)	89
19. Diagnostic Procedure with Diagnostic Trouble Code (DTC)	96
20. General Diagnostic Table.....	332

BASIC DIAGNOSTIC PROCEDURE

ENGINE (DIAGNOSTICS)

1. Basic Diagnostic Procedure

A: PROCEDURE

1. ENGINE

Step	Value	Yes	No
1 CHECK ENGINE START FAILURE. 1) Ask the customer when and how the trouble occurred using the interview check list. <Ref. to EN(H6DO)-4, CHECK, Check List for Interview.> 2) Start the engine. Does the engine start?	Engine starts.	Go to step 2.	Inspection using "Diagnostics for Engine Start Failure". <Ref. to EN(H6DO)-71, Diagnostics for Engine Starting Failure.>
2 CHECK ILLUMINATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI). Does CHECK ENGINE malfunction indicator lamp illuminate?	Indicator lamp illuminates.	Go to step 3.	Inspection using "General Diagnostics Table". <Ref. to EN(H6DO)-332, INSPECTION, General Diagnostic Table.>
3 CHECK INDICATION OF DTC ON DISPLAY. 1) Turn ignition switch to OFF. 2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector. 3) Turn ignition switch to ON and the Subaru Select Monitor or OBD-II general scan tool switch to ON. 4) Read DTC on the Subaru Select Monitor or OBD-II general scan tool. Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC?	DTC indicated.	Go to step 4.	Repair the related parts. NOTE: If DTC is not shown on display although the MI illuminates, perform diagnostics of MI (CHECK ENGINE malfunction indicator lamp) circuit or combination meter. <Ref. to EN(H6DO)-58, Engine Malfunction Indicator Lamp (MI).>
4 PERFORM THE DIAGNOSIS. 1) Inspect using "Diagnostics Procedure with Diagnostic Trouble Code (DTC)". NOTE: <Ref. to EN(H6DO)-96, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> NOTE: Carry out the basic check, only when DTC about automatic transmission is shown on display. <Ref. to EN(H6DO)-46, Read Diagnostic Trouble Code.> 2) Repair the trouble cause. 3) Perform the clear memory mode. <Ref. to EN(H6DO)-54, Clear Memory Mode.> 4) Perform the inspection mode. <Ref. to EN(H6DO)-47, Inspection Mode.> Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC?	DTC indicated.	Inspect using "Diagnostics Procedure with Diagnostic Trouble Code (DTC)". NOTE: <Ref. to EN(H6DO)-96, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Complete the diagnosis.

2. AUTOMATIC TRANSMISSION

When trouble code about automatic transmission is shown on display, carry out the following basic check. After that, carry out the replacement or repair work.

- 1) ATF level check <Ref. to AT-30, Automatic Transmission Fluid.>
- 2) Differential gear oil level check <Ref. to AT-31, Differential Gear Oil.>
- 3) ATF leak check <Ref. to AT-30, Automatic Transmission Fluid.>
- 4) Differential gear oil leak check <Ref. to AT-31, Differential Gear Oil.>
- 5) Stall test <Ref. to AT-33, Stall Test.>
- 6) Line pressure test <Ref. to AT-36, Line Pressure Test.>
- 7) Transfer clutch pressure test <Ref. to AT-38, Transfer Clutch Pressure Test.>
- 8) Time lag test <Ref. to AT-35, Time Lag Test.>
- 9) Road test <Ref. to AT-32, Road Test.>
- 10) Shift characteristics <Ref. to AT-38, Transfer Clutch Pressure Test.>

CHECK LIST FOR INTERVIEW

ENGINE (DIAGNOSTICS)

2. Check List for Interview

A: CHECK

1. CHECK LIST NO. 1

Check the following items when problem has occurred.

NOTE:

Use copies of this page for interviewing customers.

Customer's name		Engine no.	
Date of sale		Fuel brand	
Date of repair		Odometer reading	km
Vin no.			miles
Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Various/Others:		
Outdoor temperature	°F (°C)		
	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold		
Place	<input type="checkbox"/> Highway <input type="checkbox"/> Suburbs <input type="checkbox"/> Inner city <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Others:		
Engine temperature	<input type="checkbox"/> Cold <input type="checkbox"/> Warming-up <input type="checkbox"/> After warming-up <input type="checkbox"/> Any temperature <input type="checkbox"/> Others:		
Engine speed	rpm		
Vehicle speed	MPH		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH)		
Headlight	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Rear defogger	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Blower	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Radio	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
A/C compressor	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	CD/Cassette	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Cooling fan	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Car phone	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Front wiper	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	CB	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Rear wiper	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF		

CHECK LIST FOR INTERVIEW

ENGINE (DIAGNOSTICS)

2. CHECK LIST NO. 2

Check the following items about the vehicle's state when MI turns on.

NOTE:

Use copies of this page for interviewing customers.

a) Other warning lights or indicators turn on. <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<input type="checkbox"/> Low fuel warning light <input type="checkbox"/> Charge indicator light <input type="checkbox"/> AT diagnostics indicator light <input type="checkbox"/> ABS warning light <input type="checkbox"/> VDC warning light <input type="checkbox"/> Engine oil pressure warning light
b) Fuel level
<ul style="list-style-type: none">• Lack of gasoline: <input type="checkbox"/> Yes/<input type="checkbox"/> No• Indicator position of fuel gauge:
c) Intentional connecting or disconnecting of harness connectors or spark plug cords: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none">• What:
d) Intentional connecting or disconnecting of hoses: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none">• What:
e) Installing of parts other than genuine parts: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none">• What:• Where:
f) Occurrence of noise: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none">• From where:• What kind:
g) Occurrence of smell: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none">• From where:• What kind:
h) Intrusion of water into engine compartment or passenger compartment: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
i) Troubles occurred
<input type="checkbox"/> Engine does not start. <input type="checkbox"/> Engine stalls during idling. <input type="checkbox"/> Engine stalls while driving. <input type="checkbox"/> Engine speed decreases. <input type="checkbox"/> Engine speed does not decrease. <input type="checkbox"/> Rough idling <input type="checkbox"/> Poor acceleration <input type="checkbox"/> Back fire <input type="checkbox"/> After fire <input type="checkbox"/> No shift <input type="checkbox"/> Excessive shift shock

GENERAL DESCRIPTION

ENGINE (DIAGNOSTICS)

3. General Description

A: CAUTION

1) Airbag system wiring harness is routed near the engine control module (ECM), main relay and fuel pump relay.

CAUTION:

- All Airbag system wiring harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.
- Be careful not to damage Airbag system wiring harness when servicing the engine control module (ECM), transmission control module (TCM), main relay and fuel pump relay.

2) Never connect the battery in reverse polarity.

- The ECM will be destroyed instantly.
- The fuel injector and other part will be damaged in just a few minutes more.

3) Do not disconnect the battery terminals while the engine is running.

- A large counter electromotive force will be generated in the alternator, and this voltage may damage electronic parts such as ECM, etc.

4) Before disconnecting the connectors of each sensor and the ECM, be sure to turn OFF the ignition switch.

5) Poor contact has been identified as a primary cause of this problem. To measure the voltage and/or resistance of individual sensors or all electrical control modules at the harness side connector, use a tapered pin with a diameter of less than 0.64 mm (0.025 in). Do not insert the pin more than 5 mm (0.20 in) into the part.

6) Before removing ECM from the located position, disconnect two cables on battery.


- Otherwise, the ECM may be damaged.

CAUTION:

When replacing ECM, be careful not to use the wrong spec. ECM to avoid any damage on fuel injection system.


7) The connectors to each sensor in the engine compartment and the harness connectors on the engine side and body side are all designed to be waterproof. However, it is still necessary to take care not to allow water to get into the connectors when washing the vehicle, or when servicing the vehicle on a rainy day.

8) Use ECM mounting stud bolts at the body head grounding point when measuring voltage and resistance inside the passenger compartment.




(A) Stud bolt

9) Use engine grounding terminal or engine proper as the grounding point to the body when measuring voltage and resistance in the engine compartment.



10) Use TCM mounting stud bolts at the body head grounding point when measuring voltage and resistance inside the passenger compartment.



(A) Stud bolt

11) Every MFI-related part is a precision part. Do not drop them.

12) Observe the following cautions when installing a radio in MFI equipped models.

CAUTION:

- The antenna must be kept as far apart as possible from the control unit.
(The ECM is located under the steering column, inside of the instrument panel lower trim panel.)
- The antenna feeder must be placed as far apart as possible from the ECM and MFI harness.
- Carefully adjust the antenna for correct matching.
- When mounting a large power type radio, pay special attention to the three items above mentioned.
- Incorrect installation of the radio may affect the operation of the ECM.

13) Before disconnecting the fuel hose, disconnect the fuel pump connector and crank the engine for more than five seconds to release pressure in the fuel system. If engine starts during this operation, run it until it stops.

14) Problems in the electronic-controlled automatic transmission may be caused by failure of the engine, the electronic control system, the transmission proper, or by a combination of these. These three causes must be distinguished clearly when performing diagnostics.

15) Diagnostics should be conducted by rotating with simple, easy operations and proceeding to complicated, difficult operations. The most important thing in diagnostics is to understand the customer's complaint, and distinguish between the three causes.

16) In AT vehicles, do not continue the stall for more than five seconds at a time (from closed throttle, fully open throttle to stall engine speed).

17) On ABS vehicle, when performing driving test in jacked-up or lifted-up position, sometimes the warning light may be lit, but this is not a malfunction of the system. The reason for this is the speed difference between the front and rear wheels. After diagnosis of engine control system, perform the ABS memory clearance procedure of self-diagnosis system.

B: INSPECTION

Before performing diagnostics, check the following items which might affect engine problems:

1. BATTERY

1) Measure battery voltage and specific gravity of electrolyte.


Standard voltage: 12 V

Specific gravity: Above 1.260

2) Check the condition of the main and other fuses, and harnesses and connectors. Also check for proper grounding.

2. ENGINE GROUNDING

Make sure the engine grounding terminal is properly connected to the engine.



C: NOTE

1. DESCRIPTION

- The on-board diagnostics (OBD) system detects and indicates a fault in various inputs and outputs of the complex electronic control. CHECK ENGINE malfunction indicator lamp (MI) in the combination meter indicates occurrence of a fault or trouble.
- Further, against such a failure or sensors as may disable the drive, the fail-safe function is provided to ensure the minimal driveability.
- The OBD system incorporated with the vehicles within this engine family complies with Section 1968.1, California Code of Regulations (OBD-II regulation) and EC instruction No. 98/69/EC. The OBD system monitors the components and the system malfunction listed in Engine Section which affects on emissions.
- When the system decides that a malfunction occurs, MI illuminates. At the same time of the MI illumination or blinking, a diagnostic trouble code (DTC) and a freeze frame engine conditions are stored into on-board computer.
- The OBD system stores freeze frame engine condition data (engine load, engine coolant temperature, fuel trim, engine speed and vehicle speed, etc.) into on-board computer when it detects a malfunction first.
- If the OBD system detects the various malfunctions including the fault of fuel trim or misfire, the OBD system first stores freeze frame engine conditions about the fuel trim or misfire.
- When the malfunction does not occur again for three consecutive driving cycles, MI is turned off, but DTC remains at on-board computer.
- The OBD-II system is capable of communication with a general scan tool (OBD-II general scan tool) formed by ISO 9141 CARB.
- The OBD-II diagnostics procedure is different from the usual diagnostics procedure. When troubleshooting OBD-II vehicles, connect Subaru Select Monitor or the OBD-II general scan tool to the vehicle.

2. ENGINE AND EMISSION CONTROL SYSTEM

- The Multipoint Fuel Injection (MFI) system is a system that supplies the optimum air-fuel mixture to the engine for all the various operating conditions through the use of the latest electronic technology.

With this system fuel, which is pressurized at a constant pressure, is injected into the intake air passage of the cylinder head. The injection quantity of fuel is controlled by an intermittent injection system where the electro-magnetic injection valve (fuel injector) opens only for a short period of time, de-

pending on the quantity of air required for one cycle of operation. In actual operation, the injection quantity is determined by the duration of an electric pulse applied to the fuel injector and this permits simple, yet highly precise metering of the fuel.

- Further, all the operating conditions of the engine are converted into electric signals, and this results in additional features of the system, such as large improved adaptability, easier addition of compensating element, etc.

The MFI system also has the following features:

- Reduced emission of harmful exhaust gases.
- Reduced in fuel consumption.
- Increased engine output.
- Superior acceleration and deceleration.
- Superior startability and warm-up performance in cold weather since compensation is made for coolant and intake air temperature.



3. AUTOMATIC TRANSMISSION AND ELECTRONIC-HYDRAULIC CONTROL SYSTEM

The electronic-hydraulic control system consists of various sensors and switches, a transmission control module (TCM) and the hydraulic controller including solenoid valves. The system controls the transmission proper including shift control, lock-up control, overrunning clutch control, line pressure control and shift timing control. It also controls the AWD transfer clutch. In other words, the system detects various operating conditions from various input signals and sends output signals to shift solenoids 1, 2 and low clutch timing solenoid and 2-4 brake timing solenoid, line pressure duty solenoid, lock-up duty solenoid, transfer duty solenoid and 2-4 brake duty solenoid (a total of eight solenoids).

GENERAL DESCRIPTION

ENGINE (DIAGNOSTICS)

D: PREPARATION TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST24082AA210	24082AA210 (Newly adopted tool)	CARTRIDGE	Troubleshooting for electrical systems.
 ST22771AA030	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems. <ul style="list-style-type: none">• English: 22771AA030 (Without printer)• German: 22771AA070 (Without printer)• French: 22771AA080 (Without printer)• Spanish: 22771AA090 (Without printer)

ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)

4. Electrical Components Location


A: LOCATION

1. ENGINE

- **MODULE**
- LHD model







- RHD model



- | | |
|--|--|
| (1) Engine control module (ECM) | (3) Test mode connector |
| (2) Data link connector (for Subaru Select Monitor and OBD-II general scan tool) | (4) CHECK ENGINE malfunction indicator lamp (MI) |

ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)



ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)

• SENSOR










- (1) Intake air temperature sensor
- (2) Intake manifold pressure sensor
- (3) Engine coolant temperature sensor

- (4) Throttle position sensor
- (5) Knock sensor
- (6) Camshaft position sensor
- (7) Crankshaft position sensor


ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)








ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)



- | | | |
|------------------------------------|------------------------------------|------------------------------------|
| (1) Front oxygen (A/F) sensor (LH) | (3) Rear oxygen sensor | (5) Front catalytic converter (RH) |
| (2) Front oxygen (A/F) sensor (RH) | (4) Front catalytic converter (LH) | (6) Rear catalytic converter |




SUBARU

ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)

- LHD model



EN-01068


- RHD model



EN-01069

(1) Fuel level sensor

(2) Fuel sub level sensor




EN-01070

EN-01071

ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)

• SOLENOID VALVE, EMISSION CONTROL SYSTEM PARTS AND IGNITION SYSTEM PARTS



(1) Induction control solenoid valve

(3) Purge control solenoid valve

(5) Induction control valve







(2) Idle air control solenoid valve

(4) EGR solenoid valve

(6) Ignition coil & ignitor ASSY

ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)




ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)

• LHD model










• RHD model



- | | | |
|----------------------|-------------------------------|---------------------------|
| (1) Inhibitor switch | (5) Radiator main fan relay-1 | (9) Starter |
| (2) Fuel pump | (6) Radiator sub fan relay-1 | (10) Fuel pump controller |
| (3) Main relay | (7) Radiator main fan relay-2 | |
| (4) Fuel pump relay | (8) Radiator sub fan relay-2 | |

ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)




ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)

2. TRANSMISSION

- **MODULE**
- LHD model



- RHD model





(1) Transmission Control Module (TCM)

(2) AT diagnostic indicator light

ELECTRICAL COMPONENTS LOCATION





ENGINE (DIAGNOSTICS)



ELECTRICAL COMPONENTS LOCATION




ENGINE (DIAGNOSTICS)

• SENSOR



- (1) Rear vehicle speed sensor
- (2) Front vehicle speed sensor
- (3) Torque converter turbine speed sensor
- (4) ATF temperature sensor
- (5) Brake light switch

• SOLENOID VALVE AND SWITCH




- (1) Inhibitor switch
- (2) Shift solenoid valve 1
- (3) Shift solenoid valve 2
- (4) Line pressure duty solenoid
- (5) Lock-up duty solenoid
- (6) Transfer duty solenoid
- (7) 2-4 brake duty solenoid
- (8) Low clutch timing solenoid valve
- (9) 2-4 brake timing solenoid valve

ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

5. Engine Control Module (ECM) I/O Signal

A: ELECTRICAL SPECIFICATION



EN-00798

Content		Con- nector No.	Termi- nal No.	Signal (V)		Note	
				Ignition SW ON (Engine OFF)	Engine ON (Idling)		
Crankshaft position sen- sor	Signal (+)	B135	2	0	—	Sensor output wave- form <Ref. to EN(H6DO)-28, WAVE- FORM, MEASURE- MENT, Engine Control Module (ECM) I/O Sig- nal.>	
	Signal (-)	B135	11	0	0		
	Shield	B135	21	0	0		
Camshaft position sen- sor	Signal (+)	B135	1	0	—	Sensor output wave- form <Ref. to EN(H6DO)-28, WAVE- FORM, MEASURE- MENT, Engine Control Module (ECM) I/O Sig- nal.>	
	Signal (-)	B135	10	0	0		
Throttle posi- tion sensor	Signal	B135	7	Fully closed: 0.3 — 0.8 Fully open: 4.2 — 4.7	0.3 — 0.8	—	
	Power supply	B135	9	5	5	—	
	GND (sensor)	B135	19	0	0	—	
Rear oxy- gen sensor	Signal	B135	17	0 — 0.5	0 — 0.9	—	
	Shield	B135	26	0	0	—	
Front oxygen (A/F) sensor heater	Signal	LH1	B137	7	—	—	—
		LH2	B137	6	—	—	—
		RH1	B137	5	—	—	—
		RH2	B137	4	—	—	—
Rear oxygen sensor heater signal		B136	13	—	—	—	
Vehicle speed signal		B134	1	0 or 5	0 or 5	"5" and "0" are repeat- edly displayed when vehicle is driven.	

ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

Content		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Engine coolant temperature sensor	Signal	B135	18	—	—	After warm-up the engine.
	GND (sensor)	B134	7 15	0	0	After warm-up the engine.
Generator signal		B137	12	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 10 — 13	Waveform
Starter switch		B134	16	0	0	Cranking: 9 — 12
A/C switch		B134	6	ON: 10 — 13 OFF: 0	ON: 13 — 14 OFF: 0	—
Ignition switch		B134	14	10 — 13	13 — 14	—
Neutral position switch		B134	8	ON: 0 OFF: 5		Switch is ON when shift is in "N" or "P" position.
Test mode connector		B134	5	5	5	When connected: 0
Knock sensor	Signal	B135	1	2.5	2.5	—
			2	2.5	2.5	—
	Shield	B135	22	0	0	—
Back-up power supply		B137	10	10 — 13	13 — 14	Ignition switch "OFF": 10 — 13
Immobilizer communication 1		B135	5	Less than 1 ↔ More than 4	Less than 1 ↔ More than 4	—
Immobilizer communication 2		B135	14	Less than 1 ↔ More than 4	Less than 1 ↔ More than 4	—
Control unit power supply		B137	2	10 — 13	13 — 14	—
			3	10 — 13	13 — 14	—
Sensor power supply		B135	9	5	5	—
Line end check 1		B134	10	0	0	—
Ignition control	#1	B136	24	0	—	Waveform
	#2	B136	23	0	—	Waveform
	#3	B136	22	0	—	Waveform
	#4	B136	21	0	—	Waveform
	#5	B136	20	0	—	Waveform
	#6	B136	19	0	—	Waveform
Fuel injector	#1	B137	1	10 — 13	1 — 14	Waveform
	#2	B136	6	10 — 13	1 — 14	Waveform
	#3	B136	5	10 — 13	1 — 14	Waveform
	#4	B136	4	10 — 13	1 — 14	Waveform
	#5	B136	3	10 — 13	1 — 14	Waveform
	#6	B136	1	10 — 13	1 — 14	Waveform
Idle air control solenoid valve	Signal	B136	10	10 — 13	—	Waveform
Fuel pump controller	Signal	B136	16	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less	—
A/C relay control		B137	27	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—
Radiator fan relay 1 control		B137	17	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—
Radiator fan relay 2 control		B137	28	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	With A/C vehicles only
Radiator fan relay 3 control		B137	24	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—

ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

Content	Con- nector No.	Termi- nal No.	Signal (V)		Note
			Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Self-shutoff control	B134	2	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less	—
Malfunction indicator lamp	B137	15	—	—	Light "ON": 1, or less Light "OFF": 10 — 14
Engine speed output	B136	9	—	0 — 13	Waveform
Torque control 1 signal	B134	19	5	5	—
Torque control 2 signal	B134	18	5	5	—
Torque control cut signal	B136	14	8	8	—
EGR solenoid valve (A-)	B137	26	10 — 13	13 — 14	—
EGR solenoid valve (B-)	B137	25	10 — 13	13 — 14	—
EGR solenoid valve (A+)	B137	14	10 — 13	13 — 14	—
EGR solenoid valve (B+)	B137	13	10 — 13	13 — 14	—
Induction control solenoid valve	B137	23	0	ON: 0 OFF: 13 — 14	—
Purge control solenoid valve	B137	16	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—
Fuel level sensor	B135	25	0.12 — 4.75	0.12 — 4.75	—
A/C pressure switch	B135	23	OFF: 5	ON: 1, or less OFF: 5	—
AT diagnosis input signal	B135	20	Less than 1 ↔ More than 4	Less than 1 ↔ More than 4	Waveform
AT load signal	B135	28	4.3 — 4.4	0.9 — 1.4	—
Small light switch	B134	17	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Blower fan switch	B134	9	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Rear defogger switch	B134	3	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Wiper switch	B135	3	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Front oxygen (A/F) sensor signal RH (+)	B137	29	3.7 — 3.9	3.7 — 3.9	—
Front oxygen (A/F) sensor signal RH (-)	B137	19	2.6 — 4.4	3.4 — 3.6	—
Front oxygen (A/F) sensor signal LH (+)	B137	30	3.7 — 3.9	3.7 — 3.9	—
Front oxygen (A/F) sensor signal LH (-)	B137	20	2.6 — 4.4	3.4 — 3.6	—
Front oxygen (A/F) sensor shield	B137	18	0	0	—
Pressure sensor	B135	8	3.0 — 4.2	1.0 — 2.6	—
Intake air temperature sensor	B135	27	—	—	—
Power steering switch	B135	24	ON: 0 OFF: 5	ON: 0 OFF: 5	—
SSM/GST communication line	B134	21	Less than 1 ↔ More than 4	Less than 1 ↔ More than 4	—
GND (sensors)	B134	15	0	0	—
GND (injectors)	B136	8	0	0	—
GND (ignition system)	B136	18	0	0	—
GND (power supply)	B134	22	0	0	—
	B136	17	0	0	—
GND (control systems)	B134	7	0	0	—
		15	0	0	—

ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

Content		Con- nector No.	Termi- nal No.	Signal (V)		Note
				Ignition SW ON (Engine OFF)	Engine ON (Idling)	
GND (oxygen sensor heater LH)	1	B137	21	0	0	—
	2	B137	31			
GND (oxygen sensor heater RH)	1	B137	9	0	0	—
	2	B137	8			


ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

B: MEASUREMENT

Measure input/output signal voltage.

1. WAVEFORM



6. Engine Condition Data

A: ELECTRICAL SPECIFICATION

Content	Specified data
Engine load	1.6 — 4.0 (%): Idling
	6.4 — 12.8 (%): 2,500 rpm racing

Measuring condition:

- After warm-up the engine.
- Gear position is in “N” or “P” position.
- A/C is turned OFF.
- All accessory switches are turned OFF.

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

7. Transmission Control Module (TCM) I/O Signal

A: ELECTRICAL SPECIFICATION

For electrical specification of transmission control module (TCM) input/output signal, refer to AT section.
<Ref. to AT-14, ELECTRICAL SPECIFICATION, Transmission Control Module (TCM) I/O Signal.>


8. Data Link Connector

A: NOTE

This connector is used both for OBD-II general scan tools and the Subaru Select Monitor.

CAUTION:

Do not connect any scan tools other than the OBD-II general scan tools and the Subaru Select Monitor, because the circuit for the Subaru Select Monitor may be damaged.



(A) Data link connector

Terminal No. 4 to No. 6 of the data link connector is used for the Subaru Select Monitor signal.

Terminal No.	Contents	Terminal No.	Contents
1	Power supply	9	Blank
2	Blank	10	K line of ISO 9141 CARB
3	Blank	11	Blank
4	Blank	12	Ground
5	Blank	13	Ground
6	—	14	Blank
7	Blank	15	Blank
8	—	16	Blank

OBD-II GENERAL SCAN TOOL


ENGINE (DIAGNOSTICS)

9. OBD-II General Scan Tool

A: OPERATION

1. HOW TO USE OBD-II GENERAL SCAN TOOL

- 1) Prepare a general scan tool (OBD-II general scan tool) required by SAE J1978.
- 2) Open the cover and connect the OBD-II general scan tool to the data link connector (A) located in the lower portion of the instrument panel (on the driver's side).



(A) Data link connector

2. MODE \$01 (CURRENT POWERTRAIN DIAGNOSTIC DATA)

Refers to data denoting the current operating condition of analog input/output, digital input/output and/or the powertrain system.

A list of the support data and PID (Parameter Identification) codes are shown in the following table.

PID	Data	Unit of measure
01	Number of emission-related powertrain trouble codes and MI status	ON/OFF and number
03	Fuel system control status	%
04	Calculated engine load value	%
05	Engine coolant temperature	°C
06	Short term fuel trim (Bank 1)	%
07	Long term fuel trim (Bank 1)	%
08	Short term fuel trim (Bank 2)	%
09	Long term fuel trim (Bank 2)	%
0B	Intake manifold absolute pressure	kPa
0C	Engine revolution	rpm
0D	Vehicle speed	km/h
0E	Ignition timing advance	°
10	Air flow rate from pressure sensor	g/sec
11	Throttle valve opening angle	%
13	Check whether oxygen sensor is installed.	—
24	Oxygen sensor output voltage and short term fuel trim associated with oxygen sensor—bank 1	V and %
28	Oxygen sensor output voltage and short term fuel trim associated with oxygen sensor—bank 2	V and %
1C	On-board diagnosis system	—

- 3) Using the OBD-II general scan tool, call up diagnostic trouble code(s) and freeze frame data.

OBD-II general scan tool functions consist of:

- (1) MODE \$01: Current powertrain diagnostic data
- (2) MODE \$02: Powertrain freeze frame data
- (3) MODE \$03: Emission-related powertrain diagnostic trouble codes
- (4) MODE \$04: Clear/Reset emission-related diagnostic information

Read out data according to repair procedures. (For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual.)

NOTE:

For details concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC).
<Ref. to EN(H6DO)-89, List of Diagnostic Trouble Code (DTC).>

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to access generic OBD-II PIDs (MODE \$01).

3. MODE \$02 (POWERTRAIN FREEZE FRAME DATA)

Refers to data denoting the operating condition when trouble is sensed by the on-board diagnosis system. A list of the support data and PID (Parameter Identification) codes are shown in the following table.

PID	Data	Unit of measure
02	Trouble code that caused CARB required freeze frame data storage	—
03	Fuel system control status	—
04	Calculated engine load value	%
05	Engine coolant temperature	°C
06	Short term fuel trim (Bank 1)	%
07	Long term fuel trim (Bank 1)	%
08	Short term fuel trim (Bank 2)	%
09	Long term fuel trim (Bank 2)	%
0B	Intake manifold absolute pressure	kPa
0C	Engine revolution	rpm
0D	Vehicle speed	km/h

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to access freeze frame data (MODE \$02).

4. MODE \$03 (EMISSION-RELATED POWERTRAIN DIAGNOSTIC TROUBLE CODE)

Refer to Read Diagnostic Trouble Code for information about data denoting emission-related powertrain diagnostic trouble codes. <Ref. to EN(H6DO)-46, Read Diagnostic Trouble Code.>

5. MODE \$04 (CLEAR/RESET EMISSION-RELATED DIAGNOSTIC INFORMATION)

Refers to the mode used to clear or reset emission-related diagnostic information (OBD-II trouble diagnostic information).

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to clear or reset emission-related diagnostic information (MODE \$04).

SUBARU SELECT MONITOR


ENGINE (DIAGNOSTICS)

10. Subaru Select Monitor

A: OPERATION


1. HOW TO USE SUBARU SELECT MONITOR

1) Prepare Subaru Select Monitor kit. <Ref. to EN(H6DO)-9, PREPARATION TOOL, General Description.>




2) Connect diagnosis cable to Subaru Select Monitor.

3) Insert cartridge into Subaru Select Monitor. <Ref. to EN(H6DO)-9, PREPARATION TOOL, General Description.>



4) Connect Subaru Select Monitor to data link connector.

(1) Data link connector located in the lower portion of the instrument panel (on the driver's side).




(A) Data link connector

(2) Connect diagnosis cable to data link connector.

CAUTION:

Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.

5) Turn ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

6) Using Subaru Select Monitor, call up diagnostic trouble code(s) and various data, then record them.

2. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE. (NORMAL MODE)

Refer to Read Diagnostic Trouble Code for information about how to indicate DTC. <Ref. to EN(H6DO)-46, Read Diagnostic Trouble Code.>

3. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE. (OBD MODE)

Refer to Read Diagnostic Trouble Code for information about how to indicate DTC. <Ref. to EN(H6DO)-46, Read Diagnostic Trouble Code.>

4. READ CURRENT DATA FOR ENGINE. (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
 - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
 - 3) Press the [YES] key after displayed the information of engine type.
 - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
 - 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
 - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Battery voltage	Battery Voltage	V
Vehicle speed signal	Vehicle Speed	km/h or MPH
Engine speed signal	Engine Speed	rpm
Engine coolant temperature signal	Coolant Temp.	°C or °F
Ignition timing signal	Ignition Timing	deg
Throttle position signal	Throttle Opening Angle	%
Throttle position signal	Throttle Sensor Voltage	V
Injection pulse width 1	Fuel Injection #1 Pulse	ms
Injection pulse width 2	Fuel Injection #2 Pulse	ms
Idle air control signal	ISC Valve Duty Ratio	%
Engine load data	Engine Load	%
Front oxygen (A/F) sensor output signal 1	A/F Sensor #1	—
Front oxygen (A/F) sensor output signal 2	A/F Sensor #2	—
Front oxygen (A/F) sensor resistance 1	A/F Sensor #1 Resistance	Ω
Front oxygen (A/F) sensor resistance 2	A/F Sensor #2 Resistance	Ω
Rear oxygen sensor output signal	Rear O2 Sensor	V
Short term fuel trim 1	A/F Correction #1	%
Short term fuel trim 2	A/F Correction #2	%
Knock sensor signal	Knocking Correction	deg
Atmospheric absolute pressure signal	Atmosphere Pressure	mmHg or kPa or inHg or psig
Intake manifold relative pressure signal	Mani. Relative Pressure	mmHg or kPa or inHg or psig
EGR control signal	No. of EGR Steps	STEP
Front oxygen (A/F) sensor 1 current	A/F Sensor #1 Current	mA
Front oxygen (A/F) sensor 2 current	A/F Sensor #2 Current	mA
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg or kPa or inHg or psig
A/F correction (short term fuel trim) by rear oxygen sensor	A/F Correction #3	%
Long term whole fuel trim 1	A/F Learning #1	%
Long term whole fuel trim 2	A/F Learning #2	%
Long term whole fuel trim 3	A/F Learning #3	%
Front oxygen (A/F) sensor heater current 1	A/F Heater Current 1	A
Front oxygen (A/F) sensor heater current 2	A/F Heater Current 2	A
Rear oxygen sensor heater voltage	Rear O2 Heater Voltage	V
Canister purge control solenoid valve duty ratio	CPC Valve Duty Ratio	%
Fuel level signal	Fuel Level	V
Intake air temperature signal	Intake Air Temp.	°C or °F
Ignition switch signal	Ignition Switch	ON or OFF
Alternator output signal	Alternator Control Output	%
Fuel pump controller control duty ratio	FPC Duty Ratio	%
Test mode connector signal	Test Mode Signal	ON or OFF

SUBARU SELECT MONITOR

ENGINE (DIAGNOSTICS)

Contents	Display	Unit of measure
Neutral position switch signal	Neutral Position Switch	ON or OFF
Air conditioner switch signal	A/C Switch	ON or OFF
Radiator fan relay signal 1	Radiator Fan Relay #1	ON or OFF
Fuel pump relay signal	Fuel Pump Relay	ON or OFF
Knocking signal	Knocking Signal	ON or OFF
Radiator fan relay signal 2	Radiator Fan Relay #2	ON or OFF
Engine torque control signal #1	Torque Control Signal #1	ON or OFF
Engine torque control signal #2	Torque Control Signal #2	ON or OFF
Engine torque control permission signal	Torque Control Permission Signal	ON or OFF
Starter switch signal	Starter Switch	ON or OFF
Idle switch signal	Idle Switch Signal	ON or OFF
Crankshaft position sensor signal	Crankshaft Position Sig.	ON or OFF
Camshaft position sensor signal	Camshaft Position Sig.	ON or OFF
Rear defogger switch signal	Rear Defogger SW	ON or OFF
Blower fan switch signal	Blower Fan SW	ON or OFF
Small light switch signal	Light Switch	ON or OFF
Power steering switch signal	P/S Switch	ON or OFF
Air conditioner lock switch signal	A/C Lock Signal	ON or OFF
Air conditioner mid pressure switch signal	A/C Mid Pressure Switch	ON or OFF
Air conditioner compressor signal	A/C Compressor Signal	ON or OFF
Radiator fan relay signal 3	Radiator Fan Relay #3	ON or OFF
Induction control solenoid signal	Variable Intake Air Sol.	ON or OFF
Rear oxygen sensor rich signal	Rear O2 Rich Signal	ON or OFF
Electric load signal (Wiper switch signal)	Electric load signal	ON or OFF

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For select monitor display details, refer to the following.

Engine Load

Display: 0 — 100%

The engine load is displayed. The ECM calculates the engine load via the engine speed and signals from the pressure sensor. The engine load increases when the engine speed and absolute pressure of the intake manifold increase.

Coolant Temp.

Display: -40 to 215°C (-40 to 419°F)

The coolant temperature transmitted from the engine coolant temperature sensor is displayed.

ATF Correction #1, #2 and #3

Display: -100 to 99%

Using the signal from the front oxygen (A/F) sensor, the correction value of the fuel supply amount regulated by the ECM is indicated. When the A/F is lean and when displayed value becomes 0 % or more, ECM increases the fuel. When the A/F is rich and when displayed value becomes 0 % or less, ECM decreases the fuel.

A/F Learning #1, #2 and #3

Display: -100 to 99.2%

The ECM calculates the long-term fuel trim value from the short-term fuel trim value. The long-term fuel trim value means the correction value of long-term fuel supply amount. If the displayed value is less than 0 %, the fuel system is in rich status and the ECM restricts the fuel supply (by shortening the injector pulse). If the displayed value is more than 0 %, the fuel system is in lean status and the ECM increases the fuel supply (by extending the injector pulse).

Mani Absolute Pressure

Display: 0 — 254.9 kPa (0 — 1,912.5 mmHg, 0 — 75.3 inHg)

The pressure in the intake manifold is displayed. The ECM detects the pressure in the intake tube via the signal from the pressure sensor. The ECM calculates the air mass required for the engine.

Engine Speed

Display: 0 — 16,383 rpm

The engine speed transmitted from the crankshaft position sensor is detected.

Vehicle Speed**Display: 0 — 255 km/h (0 — 158 MPH)**

The vehicle speed transmitted from the vehicle speed sensor is displayed.

Ignition Timing**Display: -64 to 63.5 deg.**

The advanced ignition timing value is displayed. The ECM calculates the advanced ignition timing value using engine coolant temperature, engine speed, and engine load.

Intake Air Temp.**Display: 40 — 215°C (104 — 419°F)**

The intake air temperature is displayed. The ECM detects the intake air temperature via the signal from the intake air temperature sensor, and corrects the ignition timing and fuel supply amount.

Rear O2 Sensor**Display: 0 — 327.7 Volt**

The ECM corrects air-fuel ratio by the signal sent from O2 sensor. Also, the signal is used for catalyst degradation diagnosis.

Battery Voltage**Display: 0 — 20.4 V**

The battery voltage is displayed.

Throttle Sensor Voltage**Display: 0 — 5 V**

The throttle angle is displayed in voltage. When the throttle is fully-closed, the displayed voltage value is approx. 0.5 V. When it is fully-open, the voltage is approx. 4 V or more.

Fuel Injection #1 and #2 Pulse**Display: 0 — 65.3 msec (0 — 214.2 ft/sec)**

The injector valve opening time is displayed. The longer the injector valve opening time, the more the fuel is supplied. The higher the engine load, the longer the injector valve opening time becomes.

Knocking Correction**Display: -64 to 63.5 deg.**

The ECM controls the ignition timing via the signal from the knock sensor.

Atmosphere Pressure**Display: 0 — 254.9 kPa (0 — 1,912.5 mmHg, 0 — 75.3 inHg)**

The atmospheric pressure is displayed. The ECM detects the atmospheric pressure via the signal from the atmosphere sensor.

Mani. Relative Pressure**Display: -128 — 128 kPa (-952 — 952 mm-Hg, -37.5 — 37.5 inHg)**

A value calculated by subtracting the absolute pressure in the intake tube from the atmospheric pressure is displayed. A larger load leads to a larger value.

Front O2 Heater #1, #2 Current**Display: 0 — 25.5 A**

The heater current of the A/F sensor is displayed. A larger current value leads to increased heat generation.

Fuel Level**Display: 0 — 5 V**

The float inside the fuel tank is a variable resistor which varies the resistance based on fuel level. The ECM then averages this voltage and the signal voltage from the fuel tank in order to determine fuel level. The scan tool displays close to 0.7 volts for an empty tank, and close to 5 volts for a full tank.

CPC Valve Duty Ratio**Display: 0 — 100%**

The purge control solenoid valve is regulated by the ECM. The displayed value of 0 % indicates that the purge amount is 0, and 100 % indicates that the purge amount becomes the maximum.

A/F sensor #1, #2**Display: 0 — 2**

The air surplus ratio output from the front oxygen (A/F) sensor is displayed. Air overflow ratio = 1.0 is regarded as a stoichiometric A/F ratio. A value above 1.0 indicates A/F lean range, and below 1.0 indicates A/F rich range.

A/F Correction #3**Display:**

The correction value of fuel supply amount regulated by the ECM via the signal from the rear oxygen sensor is displayed.

A/F Sensor #1, #2 Current**Display: -16 — 15.9 mA**

A value of 0 mA is regarded as a stoichiometric A/F ratio. A negative value indicates A/F rich range, and positive value indicates A/F lean range.

A/F Sensor #1, #2 Resistance**Display: 0 — 255 Ω**

The resistance value of the front oxygen (A/F) sensor is displayed. At idle after warm-up, the resistance value shows 27 to 32 ohm.

SUBARU SELECT MONITOR

ENGINE (DIAGNOSTICS)

ISC Valve Duty Ratio

Display: 0 — 127.5%

The duty value of the idle air control solenoid valve is displayed. This value is regulated by the ECM. The displayed value of 0 % indicates that the air bypass circuit is closed, and 100 % indicates that it is fully-open.

No of EGR Steps

Display: 0 — 255 step

The number of the EGR valve steps is displayed. The EGR valve is driven by the stepping motor, and the number of steps is regulated by the ECM. A value of 0 steps indicates that the EGR ratio is 0 %.

Rear O2 Heater Voltage

Display: 0 — 5.1 V

The heater voltage value of the rear oxygen sensor is displayed. The heater current duty-controlled by driving range regulates heater temperature.

A/F Heater Current 1, 2

Display: 0 — 25.5 A

The heater voltage value of the front oxygen (A/F) sensor is displayed. To stabilize the output, the heater current is regulated to keep heater temperature to the specified value.

AT Vehicle ID Signal

Display: ON or OFF

AT and MT vehicles are identified. For AT vehicles, ON is displayed, and for MT ones, OFF is displayed.

Neutral Position Switch

Display: ON or OFF

When the shift lever stays in the neutral position, ON is displayed. When in other positions, OFF is displayed.

Idle Switch Signal

Display: ON or OFF

When the accelerator pedal is released fully, ON is displayed. When depressed fully, OFF is displayed.

P/S Switch

Display: ON or OFF

When the steering wheel is turned fully, ON is displayed. When returned, OFF is displayed. This signal is used for idle control or other controls.

A/C Switch

Display: ON or OFF

When the A/C switch is turned ON, ON is displayed. When turned OFF, OFF is displayed. This signal is used for idle control or other controls.

Starter Switch

Display: ON or OFF

When the vehicle is cranking, ON is displayed. When not cranking, OFF is displayed.

Rear O2 Rich Signal

Display: ON or OFF

When the A/F ratio is rich, ON is displayed. When lean, OFF is displayed.

Knocking Signal

Display: ON or OFF

When knocking occurs and the ignition timing is retarded, ON is displayed. At any other time, OFF is displayed.

Crankshaft Position Sig.

Display: ON or OFF

When a crankshaft signal exists, ON is displayed. At any other time (at engine stall), OFF is displayed.

Camshaft Position Sig.

Display: ON or OFF

When a camshaft signal exists, ON is displayed. At any other time (at engine stall), OFF is displayed.

Rear Defogger SW

Display: ON or OFF

When the rear defogger switch is turned ON, ON is displayed. When turned OFF, OFF is displayed. This signal is used for idle control or other controls.

Blower Fan SW

Display: ON or OFF

When the blower fan switch is turned ON, ON is displayed. When turned OFF, OFF is displayed. This signal is used for idle control or other controls.

Light Switch

Display: ON or OFF

When the light switch is turned ON, ON is displayed. When turned OFF, OFF is displayed. This signal is used for idle control or other controls.

A/C Lock Signal

Display: ON or OFF

Whether or not the A/C compressor is active is detected. When it is active, ON is displayed. When inactive, OFF is displayed.

A/C Mid Pressure Switch

Display: ON or OFF

The status of the A/C compressor is detected. When the A/C compressor voltage is high, ON is displayed. When low, OFF is displayed.

A/C Compressor Signal**Display: ON or OFF**

When the A/C clutch is engaged, ON is displayed.
When disengaged, OFF is displayed.

Radiator Fan Relay #1, #2, #3**Display: ON or OFF**

When the radiator fan relay is ON (radiator operates), ON is displayed. When OFF (radiator stops), OFF is displayed.

Fuel Pump Relay**Display: ON or OFF**

When the radiator fan relay is ON (fuel pump operates), ON is displayed. When OFF (fuel pump stops), OFF is displayed.

Torque Control Signal #1, #2**Display: ON or OFF**

When a torque down signal exists, ON is displayed.
When it doesn't, OFF is displayed.

Torque Permission Signal**Display: ON or OFF**

The signal which notifies whether or not torque down is possible is displayed. This signal is transmitted from the ECU in response to a torque down signal from the TCU. When torque down is prohibited, ON is displayed. When permitted, OFF is displayed.

Variable Intake Air Sol.**Display: ON or OFF**

The status of the induction control valve is displayed. When the valve is closed for the control to improve low- and mid-speed range, ON is displayed. When open, OFF is displayed.

Alternator output signal**Display: 0% or 100%**

Alternator control status is displayed. When in control 100% is shown. When not in control, 0% is shown.

Fuel pump controller control duty ratio**Display: 33% or 66% or 100%**

Duty ratio controlling fuel pump is displayed. This value is controlled by ECM.

Electric load signal**Display: ON or OFF**

When power switch is ON, ON is displayed. When power switch is OFF, OFF is displayed. This signal is used for alternator control, etc.

SUBARU SELECT MONITOR

ENGINE (DIAGNOSTICS)

5. READ CURRENT DATA FOR ENGINE. (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
 - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
 - 3) Press the [YES] key after displayed the information of engine type.
 - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
 - 5) On the «OBD Menu» display screen, select the {Current Data Display & Save} and press the [YES] key.
 - 6) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
 - 7) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Number of diagnosis code	Number of Diag Code:	—
Malfunction indicator lamp status	MI (MI)	ON or OFF
Monitoring test of misfire	Misfire monitoring	Complete or incomplete
Monitoring test of fuel system	Fuel system monitoring	Complete or incomplete
Monitoring test of comprehensive component	Component monitoring	Complete or incomplete
Test of catalyst	Catalyst Diagnosis	Complete or incomplete
Test of heated catalyst	Heated catalyst	No support
Test of evaporative emission purge control system	Evaporative purge system	No support
Test of secondary air system	Secondary air system	No support
Test of air conditioning system refrigerant	A/C system refrigerant	No support
Test of oxygen sensor (Bank 1, Bank 2, Rear)	Oxygen sensor	Complete or incomplete
Test of oxygen sensor heater (Bank 1, Bank 2, Rear)	O2 Heater Diagnosis	Complete or incomplete
Test of EGR system	EGR Diagnosis	Complete or incomplete
Air fuel ratio control system for bank 1	Fuel System for Bank 1	C1 normal
Air fuel ratio control system for bank 2	Fuel System for Bank 2	C1 normal
Engine load data	Calculated load valve	%
Engine coolant temperature signal	Coolant Temp.	°C or °F
Short term fuel trim by front oxygen (A/F) sensor bank 1	Short term fuel trim B1	%
Long term fuel trim by front oxygen (A/F) sensor bank 1	Long term fuel trim B1	%
Short term fuel trim by front oxygen (A/F) sensor bank 2	Short term fuel trim B2	%
Long term fuel trim by front oxygen (A/F) sensor bank 2	Long term fuel trim B2	%
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg or kPa or inHg or psig
Engine speed signal	Engine Speed	rpm
Vehicle speed signal	Vehicle Speed	km/h or MPH
Ignition timing for #1 cylinder	Ignition timing #1	°
Intake air temperature signal	Intake Air Temp.	°C or °F
Throttle position signal	Throttle Opening Angle	%
Oxygen sensor output signal	Oxygen Sensor #12	V
Air fuel ratio correction by rear oxygen sensor	Short term fuel trim #12	%
On-board diagnostic system	OBD System	—
Oxygen sensor equipment	Oxygen Sensor #11	Supported
Oxygen sensor equipment	Oxygen Sensor #12	Supported
Oxygen sensor equipment	Oxygen Sensor #21	Supported
A/F sensor equipment	A/F Sensor #11	—
A/F sensor output signal	A/F Sensor #11	V
A/F sensor equipment	A/F Sensor #21	—
A/F sensor output signal	A/F Sensor #21	V

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

6. READ FREEZE FRAME DATA FOR ENGINE. (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
 - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
 - 3) Press the [YES] key after displayed the information of engine type.
 - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
 - 5) On the «OBD Menu» display screen, select the {Freeze Frame Data} and press the [YES] key.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Diagnostic trouble code (DTC) for freeze frame data	Freeze frame data	DTC
Air fuel ratio control system for bank 1	Fuel system for Bank1	ON or OFF
Air fuel ratio control system for bank 2	Fuel System for Bank 2	ON or OFF
Engine load data	Engine Load	%
Engine coolant temperature signal	Coolant Temp.	°C or °F
Short term fuel trim by front oxygen (A/F) sensor bank 1	Short term fuel trim B1	%
Long term fuel trim by front oxygen (A/F) sensor bank 1	Long term fuel trim B1	%
Short term fuel trim by front oxygen (A/F) sensor bank 2	Short term fuel trim B2	%
Long term fuel trim by front oxygen (A/F) sensor bank 2	Long term fuel trim B2	%
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg or kPa or inHg or psi
Engine speed signal	Engine Speed	rpm
Vehicle speed signal	Vehicle Speed	km/h or MPH

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

SUBARU SELECT MONITOR

ENGINE (DIAGNOSTICS)

7. LED OPERATION MODE FOR ENGINE

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
 - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
 - 3) Press the [YES] key after displayed the information of engine type.
 - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
 - 5) On the «Data Display Menu» display screen, select the {Data & LED Display} and press the [YES] key.
 - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Message	LED "ON" requirements
Ignition switch signal	Ignition Switch	ON or OFF	When ignition switch is turned ON.
Test mode connector signal	Test Mode Signal	ON or OFF	When test mode connector is connected.
Neutral position switch signal	Neutral Position Switch	ON or OFF	When neutral position signal is entered.
Air conditioning switch signal	A/C Switch	ON or OFF	When air conditioning switch is turned ON.
Air conditioning relay signal	A/C Relay	ON or OFF	When air conditioning relay is functioning.
Radiator main fan relay signal	Radiator Fan Relay #1	ON or OFF	When radiator main fan relay is functioning.
Fuel pump relay signal	Fuel Pump Relay	ON or OFF	When fuel pump relay is functioning.
Knocking signal	Knocking Signal (#1 or #2)	ON or OFF	When knocking signal is entered.
Radiator sub fan relay signal	Radiator Fan Relay #2	ON or OFF	When radiator sub fan relay is functioning.
Engine torque control signal #1	Torque Control Signal #1	ON or OFF	When engine torque control signal 1 is entered.
Engine torque control signal #2	Torque Control Signal #2	ON or OFF	When engine torque control signal 2 is entered.
Engine torque control permission signal	Torque Control Permit	ON or OFF	When engine torque control permission signal is entered.
Rear oxygen sensor rich signal	Rear O2 Rich Signal	ON or OFF	When rear oxygen sensor mixture ratio is rich.
Starter switch signal	Starter Switch Signal	ON or OFF	When starter switch signal is entered.
Idle switch signal	Idle Switch Signal	ON or OFF	When idle switch signal is entered.
Crankshaft position sensor signal	Crankshaft Position Sig.	ON or OFF	When crankshaft position sensor signal is entered.
Camshaft position sensor signal	Camshaft Position Sig.	ON or OFF	When camshaft position sensor signal is entered.
Radiator sub fan relay 2 signal	Radiator Fan Relay 3	ON or OFF	When radiator sub fan relay is functioning.
Air conditioner mid pressure switch signal	A/C Mid Pressure Switch	ON or OFF	When air conditioner mid pressure switch is entered.
Air conditioner lock switch signal	A/C Lock Signal	ON or OFF	When air conditioner lock switch is entered.

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

8. READ CURRENT DATA FOR AT.

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
 - 2) On the «System Selection Menu» display screen, select the {Transmission Control System} and press the [YES] key.
 - 3) Press the [YES] key after displayed the information of transmission type.
 - 4) On the «Transmission Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
 - 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
 - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Battery voltage	Battery Voltage	V
Rear vehicle speed sensor signal	Vehicle Speed #1	km/h or MPH
Front vehicle speed sensor signal	Vehicle Speed #2	km/h or MPH
Engine speed signal	Engine Speed	rpm
Automatic transmission fluid temperature signal	ATF Temp.	°C or °F
Throttle position signal	Throttle Sensor Voltage	V
Gear position	Gear Position	—
Line pressure control duty ratio	Line Pressure Duty Ratio	%
Lock up clutch control duty ratio	Lock Up Duty Ratio	%
Transfer clutch control duty ratio	Transfer Duty Ratio	%
Power supply for throttle position sensor	Throttle Sensor Power	V
Torque converter turbine speed signal	AT Turbine Speed	rpm
2-4 brake timing pressure control duty ratio	2-4B Duty Ratio	%
Intake manifold pressure sensor voltage	Mani. Pressure Voltage	V
2 wheel drive switch signal	2WD Switch	ON or OFF
Stop lamp switch signal	Stop Lamp Switch	ON or OFF
Anti lock brake system signal	ABS Signal	ON or OFF
Cruise control system signal	Cruise Control Signal	ON or OFF
Neutral/Parking range signal	N/P Range Signal	ON or OFF
Reverse range signal	R Range Signal	ON or OFF
Drive range signal	D Range Signal	ON or OFF
3rd range signal	3rd Range Signal	ON or OFF
2nd range signal	2nd Range Signal	ON or OFF
1st range signal	1st Range Signal	ON or OFF
Shift control solenoid A	Shift Solenoid #1	ON or OFF
Shift control solenoid B	Shift Solenoid #2	ON or OFF
Torque control output signal #1	Torque Control Signal #1	ON or OFF
Torque control output signal #2	Torque Control Signal #2	ON or OFF
Torque control cut signal	Torque Control Cut Sig.	ON or OFF
2-4 brake timing control solenoid valve	2-4 Brake Timing Sol.	ON or OFF
Low clutch timing control solenoid valve	Low Clutch Timing Sol.	ON or OFF
Automatic transmission diagnosis indicator lamp	AT Diagnosis Lamp	ON or OFF

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For select monitor display details, refer to the following.

SUBARU SELECT MONITOR

ENGINE (DIAGNOSTICS)

Front Wheel Speed

Display: 0 — 255 km/h (0 — 158 MPH)

The front wheel speed is displayed. This signal is used for the shift control, lock-up control, line pressure control, and transfer control.

ATF Temp.

Display: -40 to 215°C (-40 to 419°F)

The ATF temperature via the signal from the ATF temperature sensor is displayed.

Gear Position

Display:

The present gear position is displayed. The gear position is calculated from the engine speed and torque converter turbine speed.

Line Pressure Duty Ratio

Display: 0 — 123%

The duty value of the line pressure duty solenoid is displayed. The line pressure duty solenoid is regulated by the TCM, adjusting the line pressure to the optimum value depending on driving conditions.

Lock Up Duty Ratio

Display: 0 — 123%

The duty value of the lock-up duty solenoid is displayed. The lock-up duty solenoid is regulated by the TCM. Because the lock-up duty solenoid controls the lock-up control valve, the lock-up clutch engages and disengages smoothly.

Transfer Duty Ratio

Display: 0 — 123%

The duty value of the transfer duty solenoid is displayed. The transfer duty solenoid is regulated by the TCM, adjusting the transfer clutch oil pressure and controlling the driving force of the rear wheels.

Turbine Revolution Speed

Display: 0 — 8,160 rpm

The input shaft speed detected by the torque converter speed sensor is displayed. This signal is used to control the line pressure and 2 - 4 brake pressure control timing during shifting.

Throttle Sensor Power

Display: 0 — 256 V

The supply voltage to the throttle sensor is displayed. This signal is used for the throttle sensor output correction.

Brake Clutch Duty Ratio

Display: 0 — 123%

The duty value of the 2 - 4 brake duty solenoid. The 2 - 4 brake duty solenoid is regulated by the TCM, adjusting the 2 - 4 brake pressure during shifting and relieving from harsh shifting.

Rear Wheel Speed

Display: 0 — 255 km/h (0 — 158 MPH)

The rear wheel speed is displayed. This signal is used to control the transfer. If the front vehicle speed sensor is malfunctioning, this signal is used as a substitute.

Cruise Control Signal

Display: ON or OFF

When the cruise control switch is ON, ON is displayed. When OFF, OFF is displayed.

ABS Signal

Display: ON or OFF

When the ABS function is active, ON is displayed. When inactive, OFF is displayed.

Stop Light Signal

Display: ON or OFF

When the brake pedal is depressed, ON is displayed. When released, OFF is displayed.

1st, 2nd, 3rd, D, R, Range Signal

Display: ON or OFF

When the switch for each range is ON, ON is displayed.

2-4 Brake Timing Sol.

Display: ON or OFF

When the 2-4 brake timing solenoid is ON, ON is displayed. When OFF, OFF is displayed. The 2-4 brake timing solenoid is regulated by the TCM, controlling the release timing of the 2-4 brake.

Low Clutch Timing Sol.

Display: ON or OFF

When the low clutch timing solenoid is ON, ON is displayed. When OFF, OFF is displayed. The low clutch timing solenoid is regulated by the TCM, controlling the release timing of the low clutch.

Shift Solenoid #1, #2

Display: ON or OFF

When the solenoid valve is ON, ON is displayed. When OFF, OFF is displayed. By combining No. 1 and No. 2 solenoids, the shifting mechanism is controlled.

P Range

Display: ON or OFF

When the shift lever stays in P range, ON is displayed. When not in P range, OFF is displayed.

N Range

Display: ON or OFF

When the shift lever stays in N range, ON is displayed. When not in N range, OFF is displayed.

Torque Control Signal #1, #2

Display: ON or OFF

When the torque down signal exists, ON is displayed. When it does not exist, OFF is displayed.

Torque Permission Signal

Display: ON or OFF

The signal which notifies whether or not torque down is possible is displayed. This signal is transmitted from the ECU in response to a torque down signal from the TCU. When torque down is prohibited, ON is displayed. When permitted, OFF is displayed.

READ DIAGNOSTIC TROUBLE CODE

ENGINE (DIAGNOSTICS)

11. Read Diagnostic Trouble Code

A: OPERATION

1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {Diagnostic Code(s) Display} and press the [YES] key.
- 5) On the «Diagnostic Code(s) Display» display screen, select the {Current Diagnostic Code(s)} or {History Diagnostic Code(s)} and press the [YES] key.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
 - For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC).
- <Ref. to EN(H6DO)-89, List of Diagnostic Trouble Code (DTC).>

2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {Diagnosis Code(s) Display} and press the [YES] key.
- 6) Make sure that a diagnostic trouble code (DTC) is shown on the display screen.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC).

<Ref. to EN(H6DO)-89, List of Diagnostic Trouble Code (DTC).>

3. OBD-II GENERAL SCAN TOOL

Refers to data denoting emission-related powertrain diagnostic trouble codes.

For details concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC).

<Ref. to EN(H6DO)-89, List of Diagnostic Trouble Code (DTC).>

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to access emission-related powertrain diagnostic trouble codes (MODE \$03).

12. Inspection Mode

A: OPERATION

Carry out trouble diagnosis shown in the following DTC table.

When performing trouble diagnosis which is not shown in the DTC table, refer to the next item Drive cycle.
<Ref. to EN(H6DO)-52, Drive Cycle.>

DTC No.	Item
P0030	HO2S Heater control circuit (Bank 1 Sensor 1)
P0031	HO2S Heater control circuit low (Bank 1 Sensor 1)
P0032	HO2S Heater control circuit high (Bank 1 Sensor 1)
P0037	HO2S Heater control circuit low (Bank 1 Sensor 2)
P0038	HO2S Heater control circuit high (Bank 1 Sensor 2)
P0050	HO2S Heater control circuit (Bank 2 Sensor 1)
P0051	HO2S Heater control circuit low (Bank 2 Sensor 1)
P0052	HO2S Heater control circuit high (Bank 2 Sensor 1)
P0068	Manifold absolute pressure/barometric pressure circuit range/performance
P0107	Manifold absolute pressure/barometric pressure circuit low input
P0108	Manifold absolute pressure/barometric pressure circuit high input
P0112	Intake air temperature circuit low input
P0113	Intake air temperature circuit high input
P0117	Engine coolant temperature circuit low input
P0118	Engine coolant temperature circuit high input
P0122	Throttle/pedal position sensor/switch "A" circuit low input
P0123	Throttle/pedal position sensor/switch "A" circuit high input
P0129	Barometric pressure too low
P0130	O2 sensor circuit (Bank 1 Sensor 1)
P0134	O2 sensor circuit no activity detected (Bank 1 Sensor 1)
P0137	O2 sensor circuit low voltage (Bank 1 Sensor 2)
P0138	O2 sensor circuit high voltage (Bank 1 Sensor 2)
P0150	O2 sensor circuit (Bank 2 Sensor 1)
P0154	O2 sensor circuit no activity detected (Bank 2 Sensor 1)
P0230	Fuel pump primary circuit
P0327	Knock sensor 1 circuit low input (Bank 1 or Single sensor)
P0328	Knock sensor 1 circuit high input (Bank 1 or Single sensor)
P0332	Knock sensor 2 circuit low input (Bank 2)
P0333	Knock sensor 2 circuit high input (Bank 2)
P0335	Crankshaft position sensor "A" circuit
P0336	Crankshaft position sensor "A" circuit range/performance
P0340	Camshaft position sensor "A" circuit (Bank 1 or Single Sensor)
P0341	Camshaft position sensor "A" circuit range/performance (Bank 1 or Single Sensor)
P0458	Evaporative emission control system purge control valve circuit low
P0462	Fuel level sensor circuit low input
P0463	Fuel level sensor circuit high input
P0502	Vehicle speed sensor circuit low input
P0503	Vehicle speed sensor intermittent/erratic/high
P0508	Idle control system circuit low
P0509	Idle control system circuit high
P0512	Starter request circuit
P0519	Idle air control circuit system performance
P0558	Alternator circuit low input
P0559	Alternator circuit high input
P0565	Cruise control on signal

INSPECTION MODE

ENGINE (DIAGNOSTICS)


DTC No.	Item
P0604	Internal control module random access memory (RAM) error
P0661	Intake manifold tuning valve control circuit low - bank 1
P0662	Intake manifold tuning valve control circuit high - bank 2
P0691	Cooling fan 1 control circuit low
P0692	Cooling fan 1 control circuit high
P0703	Torque converter/brake switch "B" circuit
P0705	Transmission range sensor circuit (PRNDL input)
P0710	Transmission fluid temperature sensor circuit
P0716	Input/turbine speed sensor circuit range/performance
P0720	Output speed sensor circuit
P0726	Engine speed input circuit range/performance
P0731	Gear 1 incorrect ratio
P0732	Gear 2 incorrect ratio
P0733	Gear 3 incorrect ratio
P0734	Gear 4 incorrect ratio
P0741	Torque converter clutch circuit performance or stuck off
P0743	Torque converter clutch circuit electrical
P0748	Pressure control solenoid "A" electrical
P0753	Shift solenoid "A" electrical
P0758	Shift solenoid "B" electrical
P0771	Shift solenoid "E" performance or stuck off
P0778	Pressure control solenoid "B" electrical
P0785	Shift/timing solenoid
P0851	Neutral switch input circuit low
P0852	Neutral switch input circuit high
P0864	TCM communication circuit range/performance
P0865	TCM communication circuit low
P0866	TCM communication circuit high
P1110	Atmospheric pressure sensor circuit malfunction (low input)
P1111	Atmospheric pressure sensor circuit malfunction (high input)
P1134	A/F sensor micro-computer problem
P1152	O2 sensor circuit range/performance (low) (Bank 1 Sensor 1)
P1153	O2 sensor circuit range/performance (high) (Bank 1 Sensor 2)
P1154	O2 sensor circuit range/performance (low) (Bank 2 Sensor 1)
P1155	O2 sensor circuit range/performance (high) (Bank 2 Sensor 1)
P1518	Starter switch circuit low input
P1560	Back-up voltage circuit malfunction
P1698	Engine torque control cut signal circuit malfunction (low input)
P1699	Engine torque control cut signal circuit malfunction (high input)
P1700	Throttle position sensor circuit malfunction for AT
P1711	Engine torque control signal #1 circuit malfunction
P1712	Engine torque control signal #2 circuit malfunction

1. PREPARATION FOR THE INSPECTION MODE

- 1) Make sure that fuel remains approx. half amount [20 to 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)], and battery voltage is 12V or more.
- 2) Raise the vehicle using a garage jack and place on safety stands or drive the vehicle onto free rollers.

WARNING:

- Before raising the vehicle, ensure parking brakes are applied.
- Do not use a pantograph jack in place of a safety stand.
- Secure a rope or wire to the front and rear towing or tie-down hooks to prevent the lateral runout of front wheels.
- Do not abruptly depress/release clutch pedal or accelerator pedal during works even when engine is operating at low speeds since this may cause vehicle to jump off free rollers.
- In order to prevent the vehicle from slipping due to vibration, do not place any wooden blocks or similar items between the safety stands and the vehicle.
- Since the rear wheels will also rotate, do not place anything near them. Also, make sure that nobody goes in front of the vehicle.



- (A) Safety stand
(B) Free rollers


- 3) Warm up engine.

2. SUBARU SELECT MONITOR


- 1) After performing diagnostics and clearing the memory, check for any remaining unresolved trouble data. <Ref. to EN(H6DO)-54, Clear Memory Mode.>
- 2) Prepare Subaru Select Monitor kit. <Ref. to EN(H6DO)-9, PREPARATION TOOL, General Description.>



- 3) Connect diagnosis cable to Subaru Select Monitor.
- 4) Insert cartridge into Subaru Select Monitor. <Ref. to EN(H6DO)-9, PREPARATION TOOL, General Description.>



- 5) Connect test mode connector at the lower portion of instrument panel (on the driver's side).




- (A) Test mode connector

- 6) Connect Subaru Select Monitor to data link connector.

INSPECTION MODE

ENGINE (DIAGNOSTICS)

- (1) Connect Subaru Select Monitor to data link connector (A) located in the lower portion of the instrument panel (on the driver's side).




(A) Data link connector

- (2) Connect diagnosis cable to data link connector.

CAUTION:

Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.

- 7) Turn ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch


- 8) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
 - 9) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
 - 10) Press the [YES] key after displayed the information of engine type.
 - 11) On the «Engine Diagnosis» display screen, select the {Dealer Check Mode Procedure} and press the [YES] key.
 - 12) When the “Perform Inspection (Dealer Check) Mode?” is shown on the display screen, press the [YES] key.
 - 13) Perform subsequent procedures as instructed on the display screen.
- If trouble still remains in the memory, the corresponding diagnostic trouble code (DTC) appears on the display screen.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC).
<Ref. to EN(H6DO)-89, List of Diagnostic Trouble Code (DTC).>
- Release the parking brake.
- The speed difference between front and rear wheels may light either the ABS warning light, but this indicates no malfunctions. When engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

3. OBD-II GENERAL SCAN TOOL

- 1) After performing diagnostics and clearing the memory, check for any remaining unresolved trouble data: <Ref. to EN(H6DO)-54, Clear Memory Mode.>
- 2) Connect test mode connector at the lower side of the instrument panel (on the driver's side).




(A) Test mode connector

- 3) Connect the OBD-II general scan tool to its data link connector in the lower portion of the instrument panel (on the driver's side).

CAUTION:

Do not connect the scan tools except for Subaru Select Monitor and OBD-II general scan tool.



(A) Data link connector

4) Start the engine.

NOTE:

Ensure the select lever is placed in the “P” position before starting.

5) Using the select lever, turn the “P” position switch and the “N” position switch to ON.

6) Depress the brake pedal to turn the brake switch ON.

7) Keep engine speed in the 2,500 — 3,000 rpm range for 40 seconds.

8) Place the select lever in the “D” position and drive the vehicle at 5 to 10 km/h (3 to 6 MPH).

NOTE:

- On AWD vehicles, release the parking brake.
- The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunctions. When engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

9) Using the OBD-II general scan tool, check for diagnostic trouble code(s) and record the result(s).

NOTE:

- For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.
- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC).

<Ref. to EN(H6DO)-89, List of Diagnostic Trouble Code (DTC).>

DRIVE CYCLE

ENGINE (DIAGNOSTICS)

13. Drive Cycle

A: OPERATION

There are 3 drive patterns for trouble diagnosis. Driving in the specified pattern allows to diagnose the malfunctioning items listed below. After the malfunctioning items listed below are repaired, always check whether they correctly resume their functions by driving in the required drive pattern.

1. PREPARATION FOR THE DRIVE CYCLE.

- 1) Make sure that fuel remains approx. half amount [20 to 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)], and battery voltage is 12V or more.
- 2) After performing diagnostics and cleaning the memory, check for any remaining unresolved trouble data. <Ref. to EN(H6DO)-54, Clear Memory Mode.>
- 3) Separate test mode connector.

NOTE:

- Except for water temperature specified items at starting, diagnosis is carried out after engine warm up.
- Carry out diagnosis which is marked * on DTC twice, Then, after finishing 1st diagnosis, stop engine and do the second time at the same condition.

2. AFTER RUNNING 20 MINUTES AT 80 KM/H (50 MPH), IDLE ENGINE FOR 1 MINUTE.

DTC No.	Item	Condition
*P0111	Intake air temperature circuit range/performance	Coolant temperature at start is less than 30°C (86°F).
*P0125	Insufficient coolant temperature for closed loop fuel control	Coolant temperature at start is less than 20°C (68°F).
*P0133	O2 sensor circuit slow response (Bank 1 Sensor 1)	—
*P0153	O2 sensor circuit slow response (Bank 2 Sensor 1)	—
*P0420	Catalyst System Efficiency Below Threshold (Bank 1)	—
P0459	Evaporative emission control system purge control valve circuit high	—
P0461	Fuel level sensor circuit range/performance	—


3. IDLE FOR 10 MINUTES

NOTE:

Before diagnosis, drive vehicle at 4 km/h (6 MPH) or more.

DTC No.	Item	Condition
*P0483	Cooling fan rationality check	—
*P0506	Idle control system RPM lower than expected	—
*P0507	Idle control system RPM higher than expected	—

4. DRIVE ACCORDING TO THE FOLLOWING DRIVE PATTERN



- | | | |
|---|--|---|
| (A) Idle engine for 1 minute. | (D) Decelerate with fully closed throttle to 64 km/h (40 MPH). | (F) Accelerate to 97 km/h (60 MPH) within 10 seconds. |
| (B) Accelerate to 97 km/h (60 MPH) within 20 seconds. | (E) Drive vehicle at 64 km/h (40 MPH) for 10 seconds. | (G) Stop vehicle with throttle fully closed. |
| (C) Drive vehicle at 97 km/h (60 MPH) for 20 seconds. | | |

DTC No.	Item	Condition
*P0121	Throttle/pedal position sensor/switch "A" circuit range/performance	Coolant temperature at start is more than 80°C (176°F).
*P0139	O2 sensor circuit slow response (Bank 1 Sensor 2)	—
*P0171	System too lean (Bank 1)	—
*P0172	System too rich (Bank 1)	—
*P0174	System too lean (Bank 2)	—
*P0175	System too rich (Bank 2)	—
*P0301	Cylinder 1 misfire detected	—
*P0302	Cylinder 2 misfire detected	—
*P0303	Cylinder 3 misfire detected	—
*P0304	Cylinder 4 misfire detected	—
*P0305	Cylinder 5 misfire detected	—
*P0306	Cylinder 6 misfire detected	—
*P0400	Exhaust gas recirculation flow	—

14. Clear Memory Mode

A: OPERATION

1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {Clear Memory} and press the [YES] key.
- 5) When the `Done' and `Turn Ignition Switch OFF' are shown on the display screen, turn the Subaru Select Monitor and ignition switch to OFF.

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {4. Diagnosis Code(s) Cleared} and press the [YES] key.
- 6) When the `Clear Diagnostic Code?' is shown on the display screen, press the [YES] key.
- 7) Turn Subaru Select Monitor and ignition switch to OFF.

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

3. OBD-II GENERAL SCAN TOOL

For clear memory procedures using the OBD-II general scan tool, refer to the OBD-II General Scan Tool Instruction Manual.

COMPULSORY VALVE OPERATION CHECK MODE

ENGINE (DIAGNOSTICS)

15. Compulsory Valve Operation Check Mode


A: OPERATION

1) Prepare Subaru Select Monitor kit. <Ref. to EN(H6DO)-9, PREPARATION TOOL, General Description.>




2) Connect diagnosis cable to Subaru Select Monitor.

3) Insert cartridge into Subaru Select Monitor. <Ref. to EN(H6DO)-9, PREPARATION TOOL, General Description.>




4) Connect test mode connector at the lower portion of instrument panel (on the driver's side).



(A) Test mode connector

5) Connect Subaru Select Monitor to data link connector.

(1) Data link connector is located in the lower portion of the instrument panel (on the driver's side).




(A) Data link connector

(2) Connect diagnosis cable to data link connector.

CAUTION:

Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.

6) Turn ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

7) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.

8) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.

9) Press the [YES] key after displayed the information of engine type.

10) On the «Engine Diagnosis» display screen, select the {System Operation Check Mode} and press the [YES] key.

11) On the «System Operation Check Mode» display screen, select the {Actuator ON/OFF Operation} and press the [YES] key.

12) Select the desired compulsory actuator on the «Actuator ON/OFF Operation» display screen and press the [YES] key.

COMPULSORY VALVE OPERATION CHECK MODE

ENGINE (DIAGNOSTICS)

13) Pressing the [NO] key completes the compulsory operation check mode. The display will then return to the «Actuator ON/OFF Operation» screen.

- A list of the support data is shown in the following table.

Contents	Display
Compulsory fuel pump relay operation check	Fuel Pump Relay
Compulsory radiator fan relay operation check	Radiator Fan Relay
Compulsory air conditioning relay operation check	A/C Compressor Relay
Compulsory purge control solenoid valve operation check	CPC Solenoid Valve
Compulsory air assist injector solenoid valve operation check	AAI Solenoid Valve

NOTE:

- The following parts will be displayed but not functional because they are not installed on the vehicle.

Display
ASV Solenoid Valve
FICD Solenoid
Pressure Switching Sol. 1
Pressure Switching Sol. 2
Fuel Tank Sensor Control Valve
AAI Solenoid Valve

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

COMPULSORY VALVE OPERATION CHECK MODE

ENGINE (DIAGNOSTICS)

MEMO:

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

16.Engine Malfunction Indicator Lamp (MI)

A: PROCEDURE

1. Activation of check engine malfunction indicator lamp (MI). <Ref. to EN(H6DO)-59, ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI), Engine Malfunction Indicator Lamp (MI).>
↓
2. Check engine malfunction indicator lamp (MI) does not come on. <Ref. to EN(H6DO)-60, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MI).>
↓
3. Check engine malfunction indicator lamp (MI) does not go off. <Ref. to EN(H6DO)-64, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT GO OFF., Engine Malfunction Indicator Lamp (MI).>
↓
4. Check engine malfunction indicator lamp (MI) does not blink at a cycle of 3 Hz. <Ref. to EN(H6DO)-66, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT BLINK AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MI).>
↓
5. Check engine malfunction indicator lamp (MI) remains blinking at a cycle of 3 Hz. <Ref. to EN(H6DO)-68, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) REMAINS BLINKING AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MI).>

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)


B: ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI)

1) When ignition switch is turned to ON (engine off), the CHECK ENGINE malfunction indicator lamp (MI) in the combination meter illuminates.

NOTE:


If the MI does not illuminate, perform diagnostics of the CHECK ENGINE light circuit or the combination meter circuit. <Ref. to EN(H6DO)-60, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MI).>

4) When ignition switch is turned to ON (engine off) or to "START" with the test mode connector connected, the MI blinks at a cycle of 3 Hz.





(A) Malfunction indicator lamp

2) After starting the engine, the MI goes out. If it does not, either the engine or the emission control system is malfunctioning.



3) If the diagnosis system senses a misfire which could damage the catalyzer, the MI will blink at a cycle of 1 Hz.




ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

C: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT COME ON.

- **DIAGNOSIS:**
 - The CHECK ENGINE malfunction indicator lamp (MI) circuit is open or shorted.
- **TROUBLE SYMPTOM:**
 - When ignition switch is turned ON (engine OFF), MI does not come on.
- **WIRING DIAGRAM:**




*1	LHD : 9 RHD : 38
*2	LHD : 13 RHD : 36
*3	LHD : 11 RHD : 34
*4	LHD : 10 RHD : 37
*5	LHD : C11 RHD : B10

B72




C: i12




A: i10




B137



B36



B157



B: i11



EN-01080

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn ignition switch to ON. 2) Measure voltage between ECM connector and chassis ground. Connector & terminal (B137) No. 15 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 4.	Go to step 2.
2 CHECK POOR CONTACT. Does the MI come on when shaking or pulling ECM connector and harness?	MI comes on.	Repair poor contact in ECM connector.	Go to step 3.
3 CHECK ECM CONNECTOR. Is ECM connector correctly connected?	Connected correctly.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	Repair connection of ECM connector.
4 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Remove combination meter. <Ref. to IDI-14, Combination Meter Assembly.> 3) Disconnect connector from ECM and combination meter. 4) Measure resistance of harness between ECM and combination meter connector. Connector & terminal LHD (B137) No. 15 — (i12) No. 11: RHD (B137) No. 15 — (i11) No. 10: Is the measured value less than the specified value?	1 Ω	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and combination meter connector • Poor contact in coupling connector
5 CHECK POOR CONTACT. Check poor contact in combination meter connector. Is there poor contact in combination meter connector?	There is poor contact.	Repair poor contact in combination meter connector.	Go to step 6.

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p>6 CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR. Measure voltage between combination meter connector and chassis ground. Connector & terminal <i>(i10) No. 8 (+) — Chassis ground (-):</i> <i>(i11) No. 5 (+) — Chassis ground (-):</i> Does the measured value exceed the specified value?</p>	10 V	Go to step 7.	Check the following and repair if necessary. NOTE: <ul style="list-style-type: none"> • Broken down ignition relay. • Blown out fuse (No. 5). • If replaced fuse (No. 5) blows easily, check the harness for short circuit of harness between fuse (No. 5) and ignition relay connector. • Open or short circuit in harness between fuse (No. 5) and battery terminal • Open circuit in harness between fuse (No. 5) and ignition relay connector • Poor contact in ignition relay connector • Poor contact in ignition switch connector
<p>7 CHECK LAMP BULB. Remove engine malfunction indicator lamp bulb. Is lamp bulb condition OK?</p>	Bulb is OK.	Repair combination meter connector.	Replace lamp bulb.

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)


MEMO:

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

D: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT GO OFF.

- **DIAGNOSIS:**
 - The CHECK ENGINE malfunction indicator lamp (MI) circuit is shorted.
- **TROUBLE SYMPTOM:**
 - Although MI comes on when engine runs, trouble code is not shown on Subaru select monitor or OBD-II general scan tool display.
- **WIRING DIAGRAM:**



*1	LHD : 9 RHD : 38
*2	LHD : 13 RHD : 36
*3	LHD : 11 RHD : 34
*4	LHD : 10 RHD : 37
*5	LHD : C11 RHD : B10

B72

1	2
3	4

C: i12

1	2	3	4	5	6	7	8		
9	10	11	12	13	14	15	16	17	18

A: i10

1	2	3	4	5	6	7	8	9	10	11	12	13	14		
15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

B137

1	2	3	4	5	6	7	8	9			
10	11	12	13	14	15	16	17	18	19	20	21
22	23	24	25	26	27	28	29	30	31		

B36

A1	A2	A3	A4	A5	A6
B1	B2	B3	B4	B5	B6
C1	C2	C3	C4	C5	C6
D1	D2	D3	D4	D5	D6
E1	E2	E3	E4	E5	E6
F1	F2	F3	F4	F5	F6
G1	G2	G3	G4	G5	G6
H1	H2	H3	H4	H5	H6
I1	I2	I3	I4	I5	I6
J1	J2	J3	J4	J5	J6
K1	K2	K3	K4	K5	K6
L1	L2	L3	L4	L5	L6
M1	M2	M3	M4	M5	M6
N1	N2	N3	N4	N5	N6
O1	O2	O3	O4	O5	O6
P1	P2	P3	P4	P5	P6

B157

1	2	3	4	5	6	7	8																						
9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38

B: i11

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

EN-01080

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Turn ignition switch to ON. Does the MI come on?	MI comes on.	Repair short circuit in harness between combination meter and ECM connector.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

E: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT BLINK AT A CYCLE OF 3 HZ.



• DIAGNOSIS:

- The CHECK ENGINE malfunction indicator lamp (MI) circuit is open or shorted.
- Test mode connector circuit is open.

• TROUBLE SYMPTOM:

- When inspection mode, MI does not blink at a cycle of 3 Hz.

• WIRING DIAGRAM:



EN-01081

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)



Step	Value	Yes	No
1 CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI). 1) Turn ignition switch to OFF. 2) Disconnect test mode connector. 3) Turn ignition switch to ON. (engine OFF) Does the MI come on?	MI comes on.	Go to step 2.	Repair the MI circuit. <Ref. to EN(H6DO)-60, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MI).>
2 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Turn ignition switch to ON. Does the MI come on?	MI comes on.	Repair ground short circuit in harness between combination meter and ECM connector.	Go to step 3.
3 CHECK HARNESS BETWEEN TEST MODE CONNECTOR AND CHASSIS GROUND. 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between test mode connector and chassis ground. Connector & terminal (B76) No. 1 — Chassis ground: Is the measured value less than the specified value?	1 Ω	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between test mode connector and chassis ground
4 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Go to step 5.
5 CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR. 1) Connect test mode connector. 2) Measure resistance of harness between ECM and chassis ground. Connector & terminal (B134) No. 5 — Chassis ground: Is the measured value less than the specified value?	1 Ω	Go to step 6.	Repair open circuit in harness between ECM and test mode connector.
6 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

F: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MI) REMAINS BLINKING AT A CYCLE OF 3 HZ.

- **DIAGNOSIS:**
 - Test mode connector circuit is shorted.
- **TROUBLE SYMPTOM:**
 - MI blinks at a cycle of 3 Hz when ignition switch is turned to ON.
- **WIRING DIAGRAM:**



EN-01081

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK TEST MODE CONNECTOR. 1) Disconnect test mode connector. 2) Turn ignition switch to ON. Does MI flash on and off?	MI comes on.	Go to step 2.	System is in good order. NOTE: MI blinks at a cycle of 3 Hz when test mode connector is connected.
2 CHECK HARNESS BETWEEN ECM CONNECTOR AND ENGINE GROUNDING TERMINAL. 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between ECM connector and chassis ground. Connector & terminal (B134) No. 5 — Chassis ground: Does the measured value exceed the specified value?	1 M Ω	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	Repair short circuit in harness between ECM and test mode connector.

ENGINE MALFUNCTION INDICATOR LAMP (MI)

ENGINE (DIAGNOSTICS)

MEMO:

17. Diagnostics for Engine Starting Failure

A: PROCEDURE

1. Inspection of starter motor circuit. <Ref. to EN(H6DO)-72, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
2. Inspection of ECM power supply and ground line. <Ref. to EN(H6DO)-76, CONTROL MODULE POWER SUPPLY AND GROUND LINE, Diagnostics for Engine Starting Failure.>
↓
3. Inspection of ignition control system. <Ref. to EN(H6DO)-80, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>
↓
4. Inspection of fuel pump circuit. <Ref. to EN(H6DO)-84, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
5. Inspection of fuel injector circuit. <Ref. to EN(H6DO)-86, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
6. Inspection using Subaru Select Monitor or OBD-II general scan tool <Ref. to EN(H6DO)-96, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> or inspection using "General Diagnostics Table". <Ref. to EN(H6DO)-332, General Diagnostic Table.>

DIAGNOSTICS FOR ENGINE STARTING FAILURE





ENGINE (DIAGNOSTICS)

B: STARTER MOTOR CIRCUIT

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H6DO)-54, OPERATION, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(H6DO)-47, OPERATION, Inspection Mode.>

• WIRING DIAGRAM:



EN-01082

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK OPERATION OF STARTER MOTOR. Does starter motor operate when the switch starts?	Starter motor operates.	Go to step 2.	Go to step 3.
2 CHECK DTC. Is diagnostic trouble code (DTC) displayed? <Ref. to EN(H6DO)-46, OPERATION, Read Diagnostic Trouble Code.>	Diagnostic trouble code (DTC) is displayed.	Check the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H6DO)-89, List of Diagnostic Trouble Code (DTC).>	Repair poor contact of ECM connector.
3 CHECK INPUT SIGNAL FOR STARTER MOTOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from starter motor. 3) Turn ignition switch to ST. 4) Measure power supply voltage between starter motor connector terminal and engine ground. Connector & terminal (B14) No. 1 (+) — Engine ground (-): Does the measured value exceed the specified value? NOTE: Place the selector lever in the "P" or "N" position.	10 V	Go to step 4.	Go to step 5.
4 CHECK GROUND CIRCUIT OF STARTER MOTOR. 1) Turn ignition switch to OFF. 2) Measure resistance between ground cable terminal and engine ground. Is the measured value less than the specified value?	5 Ω	Check starter motor. <Ref. to SC(H6DO)-6, Starter.>	Repair open circuit of ground cable.
5 CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR. 1) Ignition switch to OFF. 2) Disconnect connector from ignition switch. 3) Measure power supply voltage between ignition switch connector and chassis ground. Connector & terminal (B72) No. 1 (+) — Chassis ground (-): Does the measured value exceed the specified value?	10 V	Go to step 6.	Check the following items and repair, if necessary. • Blown out fuse • Open circuit in harness between ignition switch and battery
6 CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR. 1) Connect connector to ignition switch. 2) Turn ignition switch to START. 3) Measure voltage between ignition switch and chassis ground. Connector & terminal (B72) No. 3 (+) — Chassis ground (-): Does the measured value exceed the specified value?	10 V	Go to step 7.	Replace ignition switch.

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK INPUT VOLTAGE OF INHIBITOR SWITCH. 1) Turn ignition switch to OFF. 2) Disconnect connector from inhibitor switch. 3) Connect connector to ignition switch. 4) Measure input voltage between inhibitor switch connector terminal and engine ground while turning ignition switch to ST. Connector & terminal (B12) No. 12 (+) — Engine ground (-):	Is the voltage more than 10 V?	Go to step 8.	Repair open or ground short circuit in harness between inhibitor switch and ignition switch.
8 CHECK INHIBITOR SWITCH CIRCUIT. 1) Turn ignition switch to OFF. 2) Place the selector lever in the "P" or "N" position. 3) Separate transmission harness connector. 4) Measure resistance between transmission harness connector terminals. Connector & terminal (T3) No. 11 — No. 12: Is the measured value less than the specified value?	1 Ω	Repair open or short circuit in harness between starter motor and inhibitor switch.	Go to step 9.
9 CHECK TRANSMISSION HARNESS. 1) Disconnect connector from inhibitor switch. 2) Measure resistance of harness between transmission harness and inhibitor switch connector. Connector & terminal (T3) No. 12 — (T7) No. 12: (T3) No. 11 — (T7) No. 7: Is the measured value less than the specified value?	1 Ω	Go to step 10.	Repair open or short circuit in harness between transmission harness and inhibitor switch connector.
10 CHECK POOR CONTACT. Check poor contact in inhibitor switch connector. Is there poor contact in inhibitor switch connector?	There is poor contact.	Repair poor contact in inhibitor switch connector.	Replace inhibitor switch.

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

MEMO:

DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

C: CONTROL MODULE POWER SUPPLY AND GROUND LINE

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H6DO)-54, OPERATION, Clear Memory Mode.> and INSPECTION MODE. <Ref. to EN(H6DO)-47, OPERATION, Inspection Mode.>

• WIRING DIAGRAM:



EN-01083

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p>1 CHECK MAIN RELAY.</p> <p>1) Turn the ignition switch to OFF. 2) Remove main relay. 3) Connect battery to main relay terminals No. 1 and No. 2. 4) Measure resistance between main relay terminals.</p> <p>Terminals No. 3 — No. 5: No. 4 — No. 6:</p> <p>Is the measured value less than the specified value?</p>	10 Ω	Go to step 2.	Replace main relay.
<p>2 CHECK GROUND CIRCUIT OF ECM.</p> <p>1) Disconnect connector from ECM. 2) Measure resistance of harness between ECM and chassis ground.</p> <p>Connector & terminal (B134) No. 22 — Chassis ground: (B136) No. 8 — Chassis ground: (B136) No. 17 — Chassis ground: (B136) No. 18 — Chassis ground: (B137) No. 8 — Chassis ground: (B137) No. 9 — Chassis ground: (B137) No. 21 — Chassis ground: (B137) No. 31 — Chassis ground:</p> <p>Is the measured value less than the specified value?</p>	5 Ω	Go to step 3.	Repair open circuit in harness between ECM connector and engine grounding terminal.
<p>3 CHECK INPUT VOLTAGE OF ECM.</p> <p>1) Turn ignition switch to ON. 2) Measure voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B137) No. 10 (+) — Chassis ground (-): (B134) No. 14 (+) — Chassis ground (-):</p> <p>Does the measured value exceed the specified value?</p>	10 V	Go to step 4.	Repair open or ground short circuit of power supply circuit.
<p>4 CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR.</p> <p>1) Turn ignition switch to OFF. 2) Measure resistance between ECM and chassis ground.</p> <p>Connector & terminal (B134) No. 2 — Chassis ground:</p> <p>Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 5.	Repair ground short circuit in harness between ECM connector and main relay connector, then replace ECM.
<p>5 CHECK OUTPUT VOLTAGE FROM ECM.</p> <p>1) Connect connector to ECM. 2) Turn ignition switch to ON. 3) Measure voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B134) No. 2 (+) — Chassis ground (-):</p> <p>Does the measured value exceed the specified value?</p>	10 V	Go to step 6.	Replace ECM.

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
6 CHECK INPUT VOLTAGE OF MAIN RELAY. Check voltage between main relay connector and chassis ground. Connector & terminal (B47) No. 2 (+) — Chassis ground (-): Does the measured value exceed the specified value?	10 V	Go to step 7.	Repair open circuit in harness between ECM connector and main relay connector.
7 CHECK GROUND CIRCUIT OF MAIN RELAY. 1) Turn ignition switch to OFF. 2) Measure resistance between main relay connector and chassis ground. Connector & terminal (B47) No. 1 — Chassis ground: Is the measured value less than the specified value?	5 Ω	Go to step 8.	Repair open circuit between main relay and chassis ground.
8 CHECK INPUT VOLTAGE OF MAIN RELAY. Measure voltage between main relay connector and chassis ground. Connector & terminal (B47) No. 5 (+) — Chassis ground (-): (B47) No. 6 (+) — Chassis ground (-): Does the measured value exceed the specified value?	10 V	Go to step 9.	Repair open or ground short circuit in harness of power supply circuit.
9 CHECK INPUT VOLTAGE OF ECM. 1) Connect main relay connector. 2) Turn ignition switch to ON. 3) Measure voltage between ECM connector and chassis ground. Connector & terminal (B137) No. 2 (+) — Chassis ground (-): (B137) No. 3 (+) — Chassis ground (-): Does the measured value exceed the specified value?	10 V	Check ignition control system. <Ref. to EN(H6DO)-80, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>	Repair open or ground short circuit in harness between ECM connector and main relay connector.

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

MEMO:

DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

D: IGNITION CONTROL SYSTEM

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H6DO)-54, OPERATION, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(H6DO)-47, OPERATION, Inspection Mode.>

• WIRING DIAGRAM:



EN-00806

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK SPARK PLUG CONDITION. 1) Remove the spark plug. <Ref. to IG(H6DO)-4, REMOVAL, Spark Plug.> 2) Check the spark plug condition. <Ref. to IG(H6DO)-5, INSPECTION, Spark Plug.> Is the spark plug OK?	Spark plug is OK.	Go to step 2.	Replace the spark plug.
2 CHECK IGNITION SYSTEM FOR SPARKS. 1) Connect spark plug to ignition coil. 2) Lower fuel pressure. 3) Contact spark plug thread portion with engine block. 4) While opening throttle valve fully, crank engine to check that spark occurs at each cylinder. Does spark occur at each cylinder?	Spark occurs.	Check fuel pump system. <Ref. to EN(H6DO)-84, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>	Go to step 3.
3 CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL & IGNITOR ASSEMBLY. 1) Turn ignition switch to OFF. 2) Disconnect connector from ignition coil & ignitor assembly. 3) Turn ignition switch to ON. 4) Measure power supply voltage between ignition coil & ignitor assembly connector and engine ground. Connector & terminal (E31) No. 3 (+) — Engine ground (-): (E32) No. 3 (+) — Engine ground (-): (E33) No. 3 (+) — Engine ground (-): (E34) No. 3 (+) — Engine ground (-): (E45) No. 3 (+) — Engine ground (-): (E46) No. 3 (+) — Engine ground (-): Does the measured value exceed the specified value?	10 V	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ignition coil & ignitor assembly, and ignition switch connector • Poor contact in coupling connectors
4 CHECK HARNESS OF IGNITION COIL & IGNITOR ASSEMBLY GROUND CIRCUIT. 1) Turn ignition switch to OFF. 2) Measure resistance between ignition coil & ignitor assembly connector and engine ground. Connector & terminal (E31) No. 2 — Engine ground: (E32) No. 2 — Engine ground: (E33) No. 2 — Engine ground: (E34) No. 2 — Engine ground: (E45) No. 2 — Engine ground: (E46) No. 2 — Engine ground: Is the measured value less than the specified value?	5 Ω	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ignition coil & ignitor assembly connector and engine grounding terminal

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p>5 CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR.</p> <p>1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Disconnect connector from ignition coil & ignitor assembly. 4) Measure resistance of harness between ECM and ignition coil & ignitor assembly connector.</p> <p>Connector & terminal (B136) No. 24 — (E31) No. 1: (B136) No. 23 — (E32) No. 1: (B136) No. 22 — (E33) No. 1: (B136) No. 21 — (E34) No. 1: (B136) No. 20 — (E45) No. 1: (B136) No. 19 — (E46) No. 1:</p> <p>Is the measured value less than the specified value?</p>	1 Ω	Go to step 6.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and ignition coil & ignitor assembly connector • Poor contact in coupling connector
<p>6 CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR.</p> <p>Measure resistance of harness between ECM and engine ground.</p> <p>Connector & terminal: (B136) No. 24 — Engine ground: (B136) No. 23 — Engine ground: (B136) No. 22 — Engine ground: (B136) No. 21 — Engine ground: (B136) No. 20 — Engine ground: (B136) No. 19 — Engine ground:</p> <p>Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 7.	Repair ground short circuit in harness between ECM and ignition coil & ignitor assembly connector.
<p>7 CHECK INPUT SIGNAL FOR IGNITION COIL & IGNITOR ASSEMBLY.</p> <p>1) Connect connector to ignition coil & ignitor assembly. 2) Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignition coil & ignitor assembly connector and engine ground.</p> <p>Connector & terminal (E31) No. 1 (+) — Engine ground (-): (E32) No. 1 (+) — Engine ground (-): (E33) No. 1 (+) — Engine ground (-): (E34) No. 1 (+) — Engine ground (-): (E45) No. 1 (+) — Engine ground (-): (E46) No. 1 (+) — Engine ground (-):</p> <p>Does the measured value exceed the specified value?</p>	10 V	Go to step 8.	Replace ignition coil & ignitor assembly. <Ref. to IG(H6DO)-7, Ignition Coil and Ignitor Assembly.>
<p>8 CHECK POOR CONTACT.</p> <p>Check poor contact in ECM connector. Is there poor contact in ECM connector?</p>	There is poor contact.	Repair poor contact in ECM connector.	Check fuel pump circuit. <Ref. to EN(H6DO)-84, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

MEMO:

DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

E: FUEL PUMP CIRCUIT

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H6DO)-54, OPERATION, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(H6DO)-47, OPERATION, Inspection Mode.>.

- WIRING DIAGRAM:
- LHD model




EN-01084

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

- RHD model



Step	Value	Yes	No
<p>1</p> <p>CHECK OPERATING SOUND OF FUEL PUMP.</p> <p>Make sure that the fuel pump is in operation for 2 seconds when turning ignition switch to ON.</p> <p>NOTE: Fuel pump operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H6DO)-55, Compulsory Valve Operation Check Mode.></p> <p>Does the fuel pump produce operating sound?</p>	Operating sound produced.	Check fuel injector circuit. <Ref. to EN(H6DO)-86, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>	Read the diagnostic Trouble Code (DTC) and check related DTC. <Ref. to EN(H6DO)-89, List of Diagnostic Trouble Code (DTC).>


DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

F: FUEL INJECTOR CIRCUIT

CAUTION:

- Check or repair only faulty parts.
- After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(H6DO)-54, OPERATION, Clear Memory Mode.> and INSPECTION MODE. <Ref. to EN(H6DO)-47, OPERATION, Inspection Mode.>
- WIRING DIAGRAM:



EN-01086

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
<p>1 CHECK OPERATION OF EACH FUEL INJECTOR. While cranking the engine, check that each fuel injector emits “operating” sound. Use a sound scope or attach a screwdriver to injector for this check. Does the fuel injector emit “operating” sound?</p>	Operating sound produced.	Check fuel pressure. <Ref. to FU(H6DO)-50, Fuel.>	Go to step 2.
<p>2 CHECK POWER SUPPLY TO EACH FUEL INJECTOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from fuel injector. 3) Turn ignition switch to ON. 4) Measure power supply voltage between the fuel injector terminal and engine ground. Connector & terminal #1 (E5) No. 2 (+) — Engine ground (-): #2 (E16) No. 2 (+) — Engine ground (-): #3 (E6) No. 2 (+) — Engine ground (-): #4 (E17) No. 2 (+) — Engine ground (-): #5 (E43) No. 2 (+) — Engine ground (-): #6 (E44) No. 2 (+) — Engine ground (-): Does the measured value exceed the specified value?</p>	10 V	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between main relay and fuel injector connector • Poor contact in main relay connector • Poor contact in coupling connector • Poor contact in fuel injector connector
<p>3 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR. 1) Disconnect connector from ECM and fuel injector. 2) Measure resistance of harness between ECM and fuel injector connector. Connector & terminal (B137) No. 1 — (E5) No. 1: (B136) No. 6 — (E16) No. 1: (B136) No. 5 — (E6) No. 1: (B136) No. 4 — (E17) No. 1: (B136) No. 3 — (E43) No. 1: (B136) No. 1 — (E44) No. 1: Is the measured value less than the specified value?</p>	1 Ω	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and fuel injector connector • Poor contact in coupling connector
<p>4 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR. Measure resistance of harness between ECM and fuel injector connector. Connector & terminal (B137) No. 1 — Chassis ground: (B136) No. 6 — Chassis ground: (B136) No. 5 — Chassis ground: (B136) No. 4 — Chassis ground: (B136) No. 3 — Chassis ground: (B136) No. 1 — Chassis ground: Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 5.	Repair ground short circuit in harness between ECM and fuel injector connector.

DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Value	Yes	No
5 CHECK EACH FUEL INJECTOR. 1) Turn ignition switch to OFF. 2) Measure resistance between each fuel injector terminals. Terminals No. 1 — No. 2: Is the measured value within the specified range?	5 — 20 Ω	Go to step 6.	Replace faulty fuel injector.
6 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Inspection using "General Diagnostic Table". <Ref. to EN(H6DO)-332, INSPECTION, General Diagnostic Table.>

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

18. List of Diagnostic Trouble Code (DTC)

A: LIST

DTC No.	Item	Index
P0030	HO2S Heater control circuit (Bank 1 Sensor 1)	<Ref. to EN(H6DO)-96, DTC P0030 — HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0031	HO2S Heater control circuit low (Bank 1 Sensor 1)	<Ref. to EN(H6DO)-100, DTC P0031 — HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0032	HO2S Heater control circuit high (Bank 1 Sensor 1)	<Ref. to EN(H6DO)-104, DTC P0032 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0037	HO2S Heater control circuit low (Bank 1 Sensor 2)	<Ref. to EN(H6DO)-108, DTC P0037 — HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0038	HO2S Heater control circuit high (Bank 1 Sensor 2)	<Ref. to EN(H6DO)-112, DTC P0038 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0050	HO2S Heater control circuit (Bank 2 Sensor 1)	<Ref. to EN(H6DO)-114, DTC P0050 — HO2S HEATER CONTROL CIRCUIT (BANK 2 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0051	HO2S Heater control circuit low (Bank 2 Sensor 1)	<Ref. to EN(H6DO)-116, DTC P0051 — HO2S HEATER CONTROL CIRCUIT LOW (BANK 2 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0052	HO2S Heater control circuit high (Bank 2 Sensor 1)	<Ref. to EN(H6DO)-120, DTC P0052 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 2 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0068	Manifold absolute pressure/barometric pressure circuit range/performance	<Ref. to EN(H6DO)-124, DTC P0068 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT RANGE/PERFORMANCE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0107	Manifold absolute pressure/barometric pressure circuit low input	<Ref. to EN(H6DO)-126, DTC P0107 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0108	Manifold absolute pressure/barometric pressure circuit high input	<Ref. to EN(H6DO)-130, DTC P0108 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0111	Intake air temperature circuit range/performance	<Ref. to EN(H6DO)-134, DTC P0111 — INTAKE AIR TEMPERATURE CIRCUIT RANGE/PERFORMANCE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0112	Intake air temperature circuit low input	<Ref. to EN(H6DO)-136, DTC P0112 — INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0113	Intake air temperature circuit high input	<Ref. to EN(H6DO)-138, DTC P0113 — INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0117	Engine coolant temperature circuit low input	<Ref. to EN(H6DO)-142, DTC P0117 — ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0118	Engine coolant temperature circuit high input	<Ref. to EN(H6DO)-144, DTC P0118 — ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0121	Throttle/pedal position sensor/switch "A" circuit range/performance	<Ref. to EN(H6DO)-148, DTC P0121 — THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT RANGE/PERFORMANCE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0122	Throttle/pedal position sensor/switch "A" circuit low input	<Ref. to EN(H6DO)-150, DTC P0122 — THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0123	Throttle/pedal position sensor/switch "A" circuit high input	<Ref. to EN(H6DO)-154, DTC P0123 — THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0125	Insufficient coolant temperature for closed loop fuel control	<Ref. to EN(H6DO)-156, DTC P0125 — INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0129	Barometric pressure too low	<Ref. to EN(H6DO)-158, DTC P0129 — BAROMETRIC PRESSURE TOO LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0130	O2 sensor circuit (Bank 1 Sensor 1)	<Ref. to EN(H6DO)-160, DTC P0130 — O2 SENSOR CIRCUIT (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0133	O2 sensor circuit slow response (Bank 1 Sensor 1)	<Ref. to EN(H6DO)-162, DTC P0133 — O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0134	O2 sensor circuit no activity detected (Bank 1 Sensor 1)	<Ref. to EN(H6DO)-166, DTC P0134 — O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0137	O2 sensor circuit low voltage (Bank 1 Sensor 2)	<Ref. to EN(H6DO)-170, DTC P0138 — O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0138	O2 sensor circuit high voltage (Bank 1 Sensor 2)	<Ref. to EN(H6DO)-169, DTC P0137 — O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0139	O2 sensor circuit slow response (Bank 1 Sensor 2)	<Ref. to EN(H6DO)-174, DTC P0139 — O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0150	O2 sensor circuit (Bank 2 Sensor 1)	<Ref. to EN(H6DO)-176, DTC P0150 — O2 SENSOR CIRCUIT (BANK 2 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0153	O2 sensor circuit slow response (Bank 2 Sensor 1)	<Ref. to EN(H6DO)-180, DTC P0153 — O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 2 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0154	O2 sensor circuit no activity detected (Bank 2 Sensor 1)	<Ref. to EN(H6DO)-184, DTC P0154 — O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 2 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0171	System too lean (Bank 1)	<Ref. to EN(H6DO)-187, DTC P0171 — SYSTEM TOO LEAN (BANK 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0172	System too rich (Bank 1)	<Ref. to EN(H6DO)-188, DTC P0172 — SYSTEM TOO RICH (BANK 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0174	System too lean (Bank 2)	<Ref. to EN(H6DO)-191, DTC P0174 — SYSTEM TOO LEAN (BANK 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0175	System too rich (Bank 2)	<Ref. to EN(H6DO)-192, DTC P0175 — SYSTEM TOO RICH (BANK 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0230	Fuel pump primary circuit	<Ref. to EN(H6DO)-196, DTC P0230 — FUEL PUMP PRIMARY CIRCUIT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0301	Cylinder 1 misfire detected	<Ref. to EN(H6DO)-200, DTC P0301 — CYLINDER 1 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0302	Cylinder 2 misfire detected	<Ref. to EN(H6DO)-200, DTC P0302 — CYLINDER 2 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0303	Cylinder 3 misfire detected	<Ref. to EN(H6DO)-200, DTC P0303 — CYLINDER 3 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0304	Cylinder 4 misfire detected	<Ref. to EN(H6DO)-200, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0305	Cylinder 5 misfire detected	<Ref. to EN(H6DO)-200, DTC P0305 — CYLINDER 5 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0306	Cylinder 6 misfire detected	<Ref. to EN(H6DO)-202, DTC P0306 — CYLINDER 6 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0327	Knock sensor 1 circuit low input (Bank 1 or Single sensor)	<Ref. to EN(H6DO)-210, DTC P0327 — KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0328	Knock sensor 1 circuit high input (Bank 1 or Single sensor)	<Ref. to EN(H6DO)-212, DTC P0328 — KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0332	Knock sensor 2 circuit low input (Bank 2)	<Ref. to EN(H6DO)-214, DTC P0332 — KNOCK SENSOR 2 CIRCUIT LOW INPUT (BANK 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0333	Knock sensor 2 circuit high input (Bank 2)	<Ref. to EN(H6DO)-216, DTC P0333 — KNOCK SENSOR 2 CIRCUIT HIGH INPUT (BANK 2) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0335	Crankshaft position sensor “A” circuit	<Ref. to EN(H6DO)-218, DTC P0335 — CRANKSHAFT POSITION SENSOR “A” CIRCUIT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0336	Crankshaft position sensor “A” circuit range/performance	<Ref. to EN(H6DO)-220, DTC P0336 — CRANKSHAFT POSITION SENSOR “A” CIRCUIT RANGE/PERFORMANCE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0340	Camshaft position sensor “A” circuit (Bank 1 or Single Sensor)	<Ref. to EN(H6DO)-222, DTC P0340 — CAMSHAFT POSITION SENSOR “A” CIRCUIT (BANK 1 OR SINGLE SENSOR) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0341	Camshaft position sensor “A” circuit range/performance (Bank 1 or Single Sensor)	<Ref. to EN(H6DO)-224, DTC P0341 — CAMSHAFT POSITION SENSOR “A” CIRCUIT RANGE/PERFORMANCE (BANK 1 OR SINGLE SENSOR) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0400	Exhaust gas recirculation flow	<Ref. to EN(H6DO)-226, DTC P0400 — EXHAUST GAS RECIRCULATION FLOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0420	Catalyst System Efficiency Below Threshold (Bank 1)	<Ref. to EN(H6DO)-230, DTC P0420 — CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0458	Evaporative emission control system purge control valve circuit low	<Ref. to EN(H6DO)-232, DTC P0458 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0459	Evaporative emission control system purge control valve circuit high	<Ref. to EN(H6DO)-236, DTC P0459 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0461	Fuel level sensor circuit range/performance	<Ref. to EN(H6DO)-238, DTC P0461 — FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0462	Fuel level sensor circuit low input	<Ref. to EN(H6DO)-240, DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0463	Fuel level sensor circuit high input	<Ref. to EN(H6DO)-244, DTC P0463 — FUEL LEVEL SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0483	Cooling fan rationality check	<Ref. to EN(H6DO)-248, DTC P0483 — COOLING FAN RATIONALITY CHECK —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0502	Vehicle speed sensor circuit low input	<Ref. to EN(H6DO)-251, DTC P0502 — VEHICLE SPEED SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0503	Vehicle speed sensor intermittent/erratic/high	<Ref. to EN(H6DO)-252, DTC P0503 — VEHICLE SPEED SENSOR INTERMITTENT/ERRATIC/HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0506	Idle control system RPM lower than expected	<Ref. to EN(H6DO)-254, DTC P0506 — IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0507	Idle control system RPM higher than expected	<Ref. to EN(H6DO)-256, DTC P0507 — IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0508	Idle control system circuit low	<Ref. to EN(H6DO)-258, DTC P0508 — IDLE CONTROL SYSTEM CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0509	Idle control system circuit high	<Ref. to EN(H6DO)-260, DTC P0509 — IDLE CONTROL SYSTEM CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0512	Starter request circuit	<Ref. to EN(H6DO)-262, DTC P0512 — STARTER REQUEST CIRCUIT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0519	Idle air control circuit system performance	<Ref. to EN(H6DO)-266, DTC P0519 — IDLE AIR CONTROL CIRCUIT SYSTEM PERFORMANCE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0558	Alternator circuit low input	<Ref. to EN(H6DO)-268, DTC P0558 — ALTERNATOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0559	Alternator circuit high input	<Ref. to EN(H6DO)-268, DTC P0559 — ALTERNATOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0565	Cruise control on signal	<Ref. to EN(H6DO)-270, DTC P0565 — CRUISE CONTROL ON SIGNAL —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0604	Internal control module random access memory (RAM) error	<Ref. to EN(H6DO)-272, DTC P0604 — INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0661	Intake manifold tuning valve control circuit low -bank 1	<Ref. to EN(H6DO)-274, DTC P0661 — INTAKE MANIFOLD TUNING VALVE CONTROL CIRCUIT LOW - BANK 1 —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0662	Intake manifold tuning valve control circuit high -bank 2	<Ref. to EN(H6DO)-278, DTC P0662 — INTAKE MANIFOLD TUNING VALVE CONTROL CIRCUIT HIGH - BANK 1 —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0691	Cooling fan 1 control circuit low	<Ref. to EN(H6DO)-280, DTC P0691 — COOLING FAN 1 CONTROL CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0692	Cooling fan 1 control circuit high	<Ref. to EN(H6DO)-284, DTC P0692 — COOLING FAN 1 CONTROL CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0703	Torque converter/brake switch "B" circuit	<Ref. to EN(H6DO)-288, DTC P0703 — TORQUE CONVERTER/BRAKE SWITCH "B" CIRCUIT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0705	Transmission range sensor circuit (PRNDL input)	<Ref. to AT-132, CHECK INHIBITOR SWITCH., Diagnostic Procedure for No-diagnostic Trouble Code (DTC).>
P0710	Transmission fluid temperature sensor circuit	<Ref. to AT-48, DTC 27 ATF TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0716	Input/turbine speed sensor circuit range/performance	<Ref. to AT-64, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0720	Output speed sensor circuit	<Ref. to AT-58, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0726	Engine speed input circuit range/performance	<Ref. to AT-42, DTC 11 ENGINE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0731	Gear 1 incorrect ratio	<Ref. to EN(H6DO)-290, DTC P0731 — GEAR 1 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0732	Gear 2 incorrect ratio	<Ref. to EN(H6DO)-290, DTC P0732 — GEAR 2 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0733	Gear 3 incorrect ratio	<Ref. to EN(H6DO)-290, DTC P0733 — GEAR 3 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0734	Gear 4 incorrect ratio	<Ref. to EN(H6DO)-291, DTC P0734 — GEAR 4 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0741	Torque converter clutch circuit performance or stuck off	<Ref. to EN(H6DO)-292, DTC P0741 — TORQUE CONVERTER CLUTCH CIRCUIT PERFORMANCE OR STUCK OFF —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0743	Torque converter clutch circuit electrical	<Ref. to AT-96, DTC 77 LOCK-UP DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0748	Pressure control solenoid "A" electrical	<Ref. to AT-88, DTC 75 LINE PRESSURE DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0753	Shift solenoid "A" electrical	<Ref. to AT-72, DTC 71 SHIFT SOLENOID 1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0758	Shift solenoid "B" electrical	<Ref. to AT-76, DTC 72 SHIFT SOLENOID 2, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0771	Shift solenoid "E" performance or stuck off	<Ref. to AT-80, DTC 73 LOW CLUTCH TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0778	Pressure control solenoid "B" electrical	<Ref. to AT-92, DTC 76 2-4 BRAKE DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0785	Shift/timing solenoid	<Ref. to AT-84, DTC 74 2-4 BRAKE TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0851	Neutral switch input circuit low	<Ref. to EN(H6DO)-294, DTC P0851 — NEUTRAL SWITCH INPUT CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0852	Neutral switch input circuit high	<Ref. to EN(H6DO)-296, DTC P0852 — NEUTRAL SWITCH INPUT CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0864	TCM communication circuit range/performance	<Ref. to EN(H6DO)-300, DTC P0864 — TCM COMMUNICATION CIRCUIT RANGE/PERFORMANCE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0865	TCM communication circuit low	<Ref. to EN(H6DO)-302, DTC P0865 — TCM COMMUNICATION CIRCUIT LOW —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0866	TCM communication circuit high	<Ref. to EN(H6DO)-304, DTC P0866 — TCM COMMUNICATION CIRCUIT HIGH —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1110	Atmospheric pressure sensor circuit malfunction (low input)	<Ref. to EN(H6DO)-306, DTC P1110 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1111	Atmospheric pressure sensor circuit malfunction (high input)	<Ref. to EN(H6DO)-307, DTC P1111 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1134	A/F sensor micro-computer problem	<Ref. to EN(H6DO)-308, DTC P1134 — A/F SENSOR MICRO-COMPUTER PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1152	O2 sensor circuit range/performance (low) (Bank 1 Sensor 1)	<Ref. to EN(H6DO)-310, DTC P1152 — O2 SENSOR CIRCUIT RANGE/PERFORMANCE (LOW) (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1153	O2 sensor circuit range/performance (high) (Bank 1 Sensor 1)	<Ref. to EN(H6DO)-310, DTC P1153 — O2 SENSOR CIRCUIT RANGE/PERFORMANCE (HIGH) (BANK 1 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1154	O2 sensor circuit range/performance (low) (Bank 2 Sensor 1)	<Ref. to EN(H6DO)-314, DTC P1154 — O2 SENSOR CIRCUIT RANGE/PERFORMANCE (LOW) (BANK 2 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1155	O2 sensor circuit range/performance (high) (Bank 2 Sensor 1)	<Ref. to EN(H6DO)-314, DTC P1155 — O2 SENSOR CIRCUIT RANGE/PERFORMANCE (HIGH) (BANK 2 SENSOR 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1518	Starter switch circuit low input	<Ref. to EN(H6DO)-318, DTC P1518 — STARTER SWITCH CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1560	Back-up voltage circuit malfunction	<Ref. to EN(H6DO)-322, DTC P1560 — BACK-UP VOLTAGE CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1698	Engine torque control cut signal circuit malfunction (low input)	<Ref. to EN(H6DO)-324, DTC P1698 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1699	Engine torque control cut signal circuit malfunction (high input)	<Ref. to EN(H6DO)-326, DTC P1699 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P1700	Throttle position sensor circuit malfunction for AT	<Ref. to AT-52, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1711	Engine torque control signal #1 circuit malfunction	<Ref. to EN(H6DO)-328, DTC P1711 — ENGINE TORQUE CONTROL SIGNAL #1 CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1712	Engine torque control signal #2 circuit malfunction	<Ref. to EN(H6DO)-330, DTC P1712 — ENGINE TORQUE CONTROL SIGNAL #2 CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

MEMO: