

ENGINE SECTION 3

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

FUEL INJECTION (FUEL SYSTEMS) FU(H4DOSTC)

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES) EC(H4DOSTC)

INTAKE (INDUCTION) IN(H4DOSTC)

MECHANICAL ME(H4DOSTC)

EXHAUST EX(H4DOSTC)

COOLING CO(H4DOSTC)

LUBRICATION LU(H4DOSTC)

SPEED CONTROL SYSTEMS SP(H4DOSTC)

IGNITION IG(H4DOSTC)

STARTING/CHARGING SYSTEMS SC(H4DOSTC)

ENGINE (DIAGNOSTICS) EN(H4DOSTC)

MECHANICAL

ME(H4DOSTC)

	Page
1. General Description	2
2. Compression	21
3. Idle Speed	22
4. Ignition Timing	23
5. Intake Manifold Vacuum	24
6. Engine Oil Pressure	25
7. Fuel Pressure	26
8. Valve Clearance	27
9. Engine Assembly	31
10. Engine Mounting	40
11. Preparation for Overhaul	41
12. V-belt	42
13. Crankshaft Pulley	44
14. Belt Cover	46
15. Timing Belt Assembly	47
16. Camshaft Sprocket	55
17. Crankshaft Sprocket	56
18. Camshaft	57
19. Cylinder Head Assembly	62
20. Cylinder Block	70
21. Engine Trouble in General	90
22. Engine Noise	95

GENERAL DESCRIPTION

MECHANICAL

1. General Description

A: SPECIFICATIONS

Engine	Type		Horizontally opposed, liquid cooled, 4-cylinder, 4-stroke gasoline engine		
	Valve arrangement		Belt driven, single over-head camshaft, 4-valve/cylinder		
	Bore x Stroke		mm (in)	92 x 75 (3.62 x 2.95)	
	Piston displacement		cm ³ (cu in)	1,994 (121.67)	
	Compression ratio		9.0		
	Compression pressure (at 200 — 300 rpm)		kPa (kg/cm ² , psi)	1,079 — 1,275 (11 — 13, 155 — 183)	
	Number of piston rings		Pressure ring: 2, Oil ring: 1		
	Intake valve timing	Opening		9° BTDC	
		Closing		51° ABDC	
	Exhaust valve timing	Opening		53° BBDC	
		Closing		7° ATDC	
	Valve clearance	Intake	mm (in)	0.20±0.02 (0.0079±0.0008)	
		Exhaust	mm (in)	0.25±0.02 (0.0098±0.0008)	
	Idling speed [At neutral position]		rpm	MT	700±100 (No load) 800±150 (A/C switch ON)
				AT	650±100 (No load) 850±150 (A/C switch ON)
Firing order		1 → 3 → 2 → 4			
Ignition timing		BTDC/rpm	MT	14°±10°/700 rpm	
			AT	14°±10°/650 rpm	

NOTE:

STD: Standard I.D.: Inner Diameter O.D.: Outer Diameter OS: Oversize US: Undersize

Belt tension adjuster	Protrusion of adjuster rod		5.2 — 6.2 mm (0.205 — 0.244 in)	
Belt tensioner	Spacer O.D.		17.955 — 17.975 mm (0.7069 — 0.7077 in)	
	Tensioner bus I.D.		18.0 — 18.08 mm (0.7087 — 0.7118 in)	
	Clearance between spacer and bush	STD	0.025 — 0.125 mm (0.0010 — 0.0049 in)	
		Limit	0.175 mm (0.0069 in)	
Side clearance of spacer	STD	0.2 — 0.55 mm (0.0079 — 0.0217 in)		
	Limit	0.81 mm (0.0319 in)		
Camshaft	Bend limit		0.020 mm (0.0079 in)	
	Thrust clearance		STD	0.015 — 0.070 mm (0.0006 — 0.0028 in)
			Limit	0.10 mm (0.0039 in)
	Cam lobe height	Intake	STD	46.25 — 46.35 mm (1.821 — 1.825 in)
			Limit	46.15 mm (1.817 in)
		Exhaust	STD	46.15 — 46.25 mm (1.817 — 1.821 in)
			Limit	46.65 mm (1.813 in)
	Journal O.D.	STD	Front	37.946 — 37.963 mm (1.4939 — 1.4946 in)
Center rear			29.946 — 29.963 mm (1.1790 — 1.1796 in)	
Oil clearance		STD	0.037 — 0.072 mm (0.0015 — 0.0028 in)	
		Limit	0.10 mm (0.0039 in)	
Cylinder head	Surface warpage limit		0.05 mm (0.0020 in)	
	Surface grinding limit		0.3 mm (0.012 in)	
	Standard height		127.5 mm (5.02 in)	

GENERAL DESCRIPTION

MECHANICAL

Valve seat	Refacing angle			90°	
	Contacting width	Intake	STD	1.0 mm (0.039 in)	
			Limit	1.7 mm (0.067 in)	
		Exhaust	STD	1.5 mm (0.059 in)	
Limit			2.2 mm (0.087 in)		
Valve guide	Inner diameter			6.000 — 6.012 mm (0.2362 — 0.2367 in)	
	Protrusion above head			15.8 — 16.2 mm (0.622 — 0.638 in)	
Valve	Head edge thickness	Intake	STD	1.2 mm (0.047 in)	
			Limit	0.8 mm (0.031 in)	
		Exhaust	STD	1.5 mm (0.059 in)	
			Limit	0.8 mm (0.031 in)	
	Stem diameter		Intake	5.955 — 5.970 mm (0.2344 — 0.2350 in)	
			Exhaust	5.945 — 5.960 mm (0.2341 — 0.2346 in)	
	Stem oil clearance		STD	Intake 0.030 — 0.057 mm (0.0012 — 0.0022 in) Exhaust 0.040 — 0.067 mm (0.0016 — 0.0026 in)	
			Limit	— 0.15 mm (0.0059 in)	
Overall length		Intake	104.4 mm (4.110 in)		
		Exhaust	104.7 mm (4.122 in)		
Valve spring	Free length			44.67 mm (1.7587 in)	
	Squareness			2.5°, 2.0 mm (0.079 in)	
	Tension/spring height			206 — 236 N (21.0 — 24.1 kgf, 46.2 — 53.0 lb)/ 36.0 mm (1.417 in) 485 — 537 N (49.5 — 54.8 kgf, 109.2 — 120.6 lb)/ 26.6 mm (1.047 in)	
Cylinder block	Surface warpage limit (mating with cylinder head)			0.05 mm (0.0020 in)	
	Surface grinding limit			0.1 mm (0.004 in)	
	Cylinder bore	STD	A	92.005 — 92.015 mm (3.6222 — 3.6226 in)	
			B	91.995 — 92.005 mm (3.6218 — 3.6222 in)	
	Taper		STD	0.015 mm (0.0006 in)	
			Limit	0.050 mm (0.0020 in)	
	Out-of-roundness		STD	0.010 mm (0.0004 in)	
			Limit	0.050 mm (0.0020 in)	
Piston clearance		STD	0.010 — 0.030 mm (0.0004 — 0.0012 in)		
		Limit	0.050 mm (0.0020 in)		
Enlarging (boring) limit			0.5 mm (0.020 in)		
Piston	Outer diameter	STD	A	91.985 — 91.995 mm (3.6214 — 3.6218 in)	
			B	91.975 — 91.985 mm (3.6211 — 3.6214 in)	
		0.25 mm (0.0098 in) OS			92.225 — 92.235 mm (3.6309 — 3.6313 in)
		0.50 mm (0.0197 in) OS			92.475 — 92.485 mm (3.6407 — 3.6411 in)
Piston pin	Standard clearance between piston pin and hole in piston		STD	0.004 — 0.008 mm (0.0002 — 0.0003 in)	
			Limit	0.020 mm (0.0008 in)	
		Degree of fit			Piston pin must be fitted into position with thumb at 20°C (68°F).
Piston ring	Piston ring gap	Top ring	STD	0.20 — 0.25 mm (0.0079 — 0.0098 in)	
			Limit	1.0 mm (0.039 in)	
		Second ring	STD	0.35 — 0.50 mm (0.0138 — 0.0197 in)	
			Limit	1.0 mm (0.039 in)	
	Oil ring		STD	0.20 — 0.50 mm (0.0079 — 0.0197 in)	
			Limit	1.5 mm (0.059 in)	
	Clearance between piston ring and piston ring groove		Top ring	STD	0.055 — 0.090 mm (0.0022 — 0.0035 in)
				Limit	0.15 mm (0.0059 in)
Second ring			STD	0.030 — 0.070 mm (0.0012 — 0.0028 in)	
			Limit	0.15 mm (0.0059 in)	

ME(H4DOSTC)-3


GENERAL DESCRIPTION

MECHANICAL

Connecting rod	Bend twist per 100 mm (3.94 in) in length		Limit	0.10 mm (0.0039 in)	
	Side clearance		STD	0.070 — 0.330 mm (0.0028 — 0.0130 in)	
			Limit	0.4 mm (0.016 in)	
Connecting rod bearing	Oil clearance		STD	0.020 — 0.046 mm (0.0008 — 0.0018 in)	
				Limit	0.05 mm (0.0020 in)
	Thickness at center portion		STD	1.486 — 1.498 mm (0.0585 — 0.0590 in)	
			0.03 mm (0.0012 in) US	1.504 — 1.512 mm (0.0592 — 0.0595 in)	
			0.05 mm (0.0020 in) US	1.514 — 1.522 mm (0.0596 — 0.0599 in)	
0.25 mm (0.0098 in) US			1.614 — 1.622 mm (0.0635 — 0.0639 in)		
Connecting rod bushing	Clearance between piston pin and bushing		STD	0 — 0.022 mm (0 — 0.0009 in)	
				Limit	0.030 mm (0.0012 in)
Crankshaft	Bend limit			0.035 mm (0.0014 in)	
	Crank pin and crank journal	Out-of-roundness		0.020 mm (0.0008 in) or less	
		Grinding limit			0.25 mm (0.0098 in)
	Crank pin outer diameter		STD	51.984 — 52.000 mm (2.0466 — 2.0472 in)	
			0.03 mm (0.0012 in) US	51.954 — 51.970 mm (2.0454 — 2.0461 in)	
			0.05 mm (0.0020 in) US	51.934 — 51.950 mm (2.0447 — 2.0453 in)	
			0.25 mm (0.0098 in) US	51.734 — 51.750 mm (2.0368 — 2.0374 in)	
	Crank journal outer diameter	#1, #3, #5	STD	59.992 — 60.008 mm (2.3619 — 2.3625 in)	
			0.03 mm (0.0012 in) US	59.962 — 59.978 mm (2.3607 — 2.3613 in)	
			0.05 mm (0.0020 in) US	59.942 — 59.958 mm (2.3599 — 2.3605 in)	
			0.25 mm (0.0098 in) US	59.742 — 59.758 mm (2.3520 — 2.3527 in)	
		#2, #4	STD	59.992 — 60.008 mm (2.3619 — 2.3625 in)	
			0.03 mm (0.0012 in) US	59.962 — 59.978 mm (2.3607 — 2.3613 in)	
			0.05 mm (0.0020 in) US	59.942 — 59.958 mm (2.3599 — 2.3605 in)	
			0.25 mm (0.0098 in) US	59.742 — 59.758 mm (2.3520 — 2.3527 in)	
	Thrust clearance		STD	0.030 — 0.115 mm (0.0012 — 0.0045 in)	
			Limit	0.25 mm (0.0098 in)	
	Oil clearance	#1	STD	0.003 — 0.030 mm (0.0001 — 0.0012 in)	
			Limit	0.040 mm (0.0016 in)	
		#2	STD	0.012 — 0.033 mm (0.0005 — 0.0013 in)	
			Limit	0.045 mm (0.0018 in)	
		#3	STD	0.003 — 0.030 mm (0.0001 — 0.0012 in)	
			Limit	0.040 mm (0.0016 in)	
#4		STD	0.012 — 0.033 mm (0.0005 — 0.0013 in)		
		Limit	0.045 mm (0.0018 in)		
#5		STD	0.010 — 0.031 mm (0.0004 — 0.0012 in)		
		Limit	0.040 mm (0.0016 in)		
Crankshaft bearing	#1, #3	STD	1.998 — 2.011 mm (0.0787 — 0.0792 in)		
		0.03 mm (0.0012 in) US	2.017 — 2.020 mm (0.0794 — 0.0795 in)		
		0.05 mm (0.0020 in) US	2.027 — 2.030 mm (0.0798 — 0.0799 in)		
		0.25 mm (0.0098 in) US	2.127 — 2.130 mm (0.0837 — 0.0839 in)		
	#2, #4, #5	STD	2.000 — 2.013 mm (0.0787 — 0.0793 in)		
		0.03 mm (0.0012 in) US	2.019 — 2.022 mm (0.0795 — 0.0796 in)		
		0.05 mm (0.0020 in) US	2.029 — 2.032 mm (0.0799 — 0.0800 in)		
		0.25 mm (0.0098 in) US	2.129 — 2.132 mm (0.0838 — 0.0839 in)		

B: COMPONENT

1. TIMING BELT



ME-00696

- | | |
|--|--------------------------------------|
| (1) Belt cover No. 2 (RH) | (10) Intake camshaft sprocket (LH) |
| (2) Timing belt guide (MT vehicles only) | (11) Exhaust camshaft sprocket (LH) |
| (3) Crankshaft sprocket | (12) Timing belt |
| (4) Belt cover No. 2 (LH) | (13) Belt idler No. 2 |
| (5) Tensioner bracket | (14) Belt cover |
| (6) Automatic belt tension adjuster ASSY | (15) Belt cover (LH) |
| (7) Belt idler | (16) Front belt cover |
| (8) Exhaust camshaft sprocket (RH) | (17) Belt cover (RH) |
| (9) Intake camshaft sprocket (RH) | (18) Crankshaft pulley (AT vehicles) |
| | (19) Crankshaft pulley (MT vehicles) |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 5 (0.5, 3.6)

T2: 6.4 (0.65, 4.7)

T3: 25 (2.5, 18.1)

T4: 39 (4.0, 28.9)

T5: 98 (10, 72.4)


T6: <Ref. to ME(H4DOSTC)-44, INSTALLATION, CRANKSHAFT PULLEY.>

T7: 10 (1.0, 7.2)

GENERAL DESCRIPTION

MECHANICAL

2. CYLINDER HEAD AND CAMSHAFT



ME(H4DOSTC)-6

GENERAL DESCRIPTION

MECHANICAL

- | | | |
|---------------------------------------|---------------------------------------|------------------------|
| (1) Rocker cover (RH) | (14) Oil seal | (27) Rocker cover (LH) |
| (2) Rocker cover gasket (RH) | (15) Cylinder head (RH) | (28) Oil filler cap |
| (3) Oil separator cover | (16) Cylinder head gasket (RH) | (29) Gasket |
| (4) Gasket | (17) Cylinder head (LH) | (30) Oil filler duct |
| (5) Intake camshaft cap (Front RH) | (18) Intake camshaft (LH) | (31) O-ring |
| (6) Intake camshaft cap (Center RH) | (19) Exhaust camshaft (LH) | (32) Stud bolt |
| (7) Intake camshaft cap (Rear RH) | (20) Intake camshaft cap (Front LH) | |
| (8) Intake camshaft cap (RH) | (21) Intake camshaft cap (Center LH) | |
| (9) Exhaust camshaft cap (Front RH) | (22) Intake camshaft cap (Rear LH) | |
| (10) Exhaust camshaft cap (Center RH) | (23) Exhaust camshaft cap (Front LH) | |
| (11) Exhaust camshaft cap (Rear RH) | (24) Exhaust camshaft cap (Center LH) | |
| (12) Exhaust camshaft (RH) | (25) Exhaust camshaft cap (Rear LH) | |
| (13) Cylinder head bolt | (26) Rocker cover gasket (LH) | |

Tightening torque: N·m (kgf-m, ft-lb)

T1: <Ref. to ME(H4DOSTC)-62, INSTALLATION, CYLINDER HEAD ASSEMBLY.>

T2: 5 (0.5, 3.6)

T3: 20 (2.0, 14.5)


T4: 6.4 (0.65, 4.7)

T5: 10 (1.0, 7.2)

GENERAL DESCRIPTION

MECHANICAL

3. CYLINDER HEAD AND VALVE ASSEMBLY



- | | | |
|-----------------------|---------------------------|-----------------------------|
| (1) Exhaust valve | (5) Intake valve oil seal | (9) Valve lifter |
| (2) Intake valve | (6) Valve spring | (10) Exhaust valve oil seal |
| (3) Cylinder head | (7) Retainer | (11) Intake valve guide |
| (4) Valve spring seat | (8) Retainer key | (12) Exhaust valve guide |

ME(H4DOSTC)-8

GENERAL DESCRIPTION

MECHANICAL


MEMO:

ME(H4DOSTC)-9

GENERAL DESCRIPTION

MECHANICAL

4. CYLINDER BLOCK



ME-00623

ME(H4DOSTC)-10

GENERAL DESCRIPTION


MECHANICAL

(1) Oil pressure switch	(15) Oil cooler (MT vehicles)	Tightening torque: N-m (kgf-m, ft-lb)
(2) Cylinder block (RH)	(16) Waster by-pass pipe (AT vehicles)	T1: 5 (0.5, 3.6)
(3) Service hole plug	(17) Connector	T2: 6.4 (0.65, 4.7)
(4) Gasket	(18) Oil strainer	T3: 10 (1.0, 7.2)
(5) Oil separator cover	(19) Gasket	T4: 25 (2.5, 18.1)
(6) Water by-pass pipe	(20) Oil pan	T5: <Ref. to ME(H4DOSTC)-74, INSTALLATION, CYLINDER BLOCK.>
(7) Oil pump	(21) Drain plug	T6: 70 (7.1, 50.6)
(8) Front oil seal	(22) Metal gasket	T7: First 12 (1.2, 8.7) Second 12 (1.2, 8.7)
(9) Rear oil seal	(23) Oil level gauge guide	T8: 16 (1.6, 11.6)
(10) O-ring	(24) Oil filter	T9: 44 (4.5, 33)
(11) Service hole cover	(25) Gasket	T10: 25 (2.5, 18.1)
(12) Cylinder block (LH)	(26) Water pump hose	T11: 54 (5.5, 40)
(13) Water pump	(27) Plug	
(14) Baffle plate		

GENERAL DESCRIPTION

MECHANICAL

5. CRANKSHAFT AND PISTON



ME-00005


- | | | |
|--------------------------------------|-----------------------------|--------------------------------|
| (1) Flywheel (MT vehicles only) | (9) Piston pin | (17) Crankshaft bearing #1, #3 |
| (2) Ball bearing (MT vehicles only) | (10) Circlip | (18) Crankshaft bearing #2, #4 |
| (3) Reinforcement (AT vehicles only) | (11) Connecting rod bolt | (19) Crankshaft bearing #5 |
| (4) Drive plate (AT vehicles only) | (12) Connecting rod | |
| (5) Top ring | (13) Connecting rod bearing | |
| (6) Second ring | (14) Connecting rod cap | |
| (7) Oil ring | (15) Crankshaft | |
| (8) Piston | (16) Woodruff key | |

Tightening torque: N-m (kgf-m, ft-lb)

T1: 45 (4.6, 33.3)

T2: 72 (7.3, 52.8)

6. ENGINE MOUNTING



ME-00407

(1) Front cushion rubber

Tightening torque: N·m (kgf-m, ft-lb)

T1: 35 (3.5, 25.3)

T2: 85 (8.7, 62.7)

GENERAL DESCRIPTION

MECHANICAL



C: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part in the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Before disconnecting electrical connectors of sensors or units, be sure to disconnect the ground cable from battery.
- All parts should be thoroughly cleaned, paying special attention to the engine oil passages, pistons and bearings.

- Rotating parts and sliding parts such as piston, bearing and gear should be coated with oil prior to assembly.
- Be careful not to let oil, grease or coolant contact the timing belt, clutch disc and flywheel.
- All removed parts, if to be reused, should be re-installed in the original positions and directions.
- Bolts, nuts and washers should be replaced with new ones as required.
- Even if necessary inspections have been made in advance, proceed with assembly work while making rechecks.
- Remove or install the engine in an area where chain hoists, lifting devices, etc. are available for ready use.
- Be sure not to damage coated surfaces of body panels with tools or stain seats and windows with coolant or oil. Place a cover over fenders, as required, for protection.
- Prior to starting work, prepare the following:
Service tools, clean cloth, containers to catch coolant and oil, wire ropes, chain hoist, transmission jacks, etc.
- Lift-up or lower the vehicle when necessary. Make sure to support the correct positions.






D: PREPARATION TOOL

1. SPECIAL TOOLS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-498267600</p>	498267600	CYLINDER HEAD TABLE	<ul style="list-style-type: none"> • Used for replacing valve guides. • Used for removing and installing valve springs.
 <p>ST-498457000</p>	498457000	ENGINE STAND ADAPTER RH	Used with ENGINE STAND (499817000).





GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-498457100</p>	498457100	ENGINE STAND ADAPTER LH	Used with ENGINE STAND (499817000).
 <p style="text-align: center;">ST-498497100</p>	498497100	CRANKSHAFT STOPPER	Used for stopping rotation of flywheel when loosening and tightening crankshaft pulley bolt, etc.
 <p style="text-align: center;">ST-398744300</p>	398744300	PISTON GUIDE	Used for installing piston in cylinder for 2000 cc engine.
 <p style="text-align: center;">ST-498857100</p>	498857100	VALVE OIL SEAL GUIDE	Used for press-fitting of intake and exhaust valve guide oil seals.
 <p style="text-align: center;">ST-499017100</p>	499017100	PISTON PIN GUIDE	Used for installing piston pin, piston and connecting rod.






GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-499037100</p>	<p style="text-align: center;">499037100</p>	<p>CONNECTING ROD BUSHING REMOVER & INSTALLER</p>	<p>Used for removing and installing connecting rod bushing.</p>
 <p style="text-align: center;">ST-499097600</p>	<p style="text-align: center;">499097600 (MT vehicles)</p>	<p>PISTON PIN REMOVER ASSY</p>	<p>Used for removing piston pin.</p>
 <p style="text-align: center;">ST-499097700</p>	<p style="text-align: center;">499097700 (AT vehicles)</p>	<p>PISTON PIN REMOVER ASSY</p>	<p>Used for removing piston pin.</p>
 <p style="text-align: center;">ST-499207400</p>	<p style="text-align: center;">499207400</p>	<p>CAMSHAFT SPROCKET WRENCH</p>	<p>Used for removing and installing exhaust camshaft sprocket.</p>






GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST18231AA010</p>	<p style="text-align: center;">18231AA010 (Newly adopted tool)</p>	<p style="text-align: center;">CAMSHAFT SPROCKET WRENCH</p>	<p>Used for removing and installing intake camshaft sprocket. (Intake camshaft sprocket LH)</p>
 <p style="text-align: center;">ST-499587200</p>	<p style="text-align: center;">499587200</p>	<p style="text-align: center;">CRANKSHAFT OIL SEAL INSTALLER</p>	<ul style="list-style-type: none"> • Used for installing crankshaft oil seal. • Used with CRANKSHAFT OIL SEAL GUIDE (499597100).
 <p style="text-align: center;">ST-499597100</p>	<p style="text-align: center;">499597100</p>	<p style="text-align: center;">CRANKSHAFT OIL SEAL GUIDE</p>	<ul style="list-style-type: none"> • Used for installing crankshaft oil seal. • Used with CRANKSHAFT OIL SEAL INSTALLER (499587200).
 <p style="text-align: center;">ST-499718000</p>	<p style="text-align: center;">499718000</p>	<p style="text-align: center;">VALVE SPRING REMOVER</p>	<p>Used for removing and installing valve spring.</p>
 <p style="text-align: center;">ST18251AA020</p>	<p style="text-align: center;">18251AA020</p>	<p style="text-align: center;">VALVE GUIDE ADJUSTER</p>	<p>Used for installing intake and exhaust valve guides.</p>






GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-499767200</p>	499767200	VALVE GUIDE REMOVER	Used for removing valve guides.
 <p style="text-align: center;">ST-499767400</p>	499767400	VALVE GUIDE REAMER	Used for reaming valve guides.
 <p style="text-align: center;">ST-499817100</p>	499817000	ENGINE STAND	<ul style="list-style-type: none"> • Stand used for engine disassembly and assembly. • Used with ENGINE STAND ADAPTER RH (498457000) & LH (498457100).
 <p style="text-align: center;">ST-499977400</p>	499977400	CRANK PULLEY WRENCH (AT vehicles)	Used for stopping rotation of crankshaft pulley when loosening and tightening crankshaft pulley bolts.
 <p style="text-align: center;">ST-499977100</p>	499977100	CRANK PULLEY WRENCH (MT vehicles)	Used for stopping rotation of crankshaft pulley when loosening and tightening crankshaft pulley bolts.




GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-499987500</p>	499987500	CRANKSHAFT SOCKET	Used for rotating crankshaft.
 <p style="text-align: center;">ST-498547000</p>	498547000	OIL FILTER WRENCH	Used for removing and installing the oil filter.
 <p style="text-align: center;">ST-499587100</p>	499587100	OIL SEAL INSTALLER	Used for installing oil pump oil seal.
 <p style="text-align: center;">ST-499587600</p>	499587600	OIL SEAL INSTALLER	Used for installing camshaft oil seal for DOHC engine.
 <p style="text-align: center;">ST-499597200</p>	499597200	OIL SEAL GUIDE	<ul style="list-style-type: none"> • Used for installing camshaft oil seal for DOHC engine. • Used with OIL SEAL GUIDE (499587600).

GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-498277200</p>	498277200	STOPPER SET	Used for installing automatic transmission assembly to engine.
 <p style="text-align: center;">ST24082AA210</p>	24082AA210 (Newly adopted tool)	CARTRIDGE	Troubleshooting for electrical systems.
 <p style="text-align: center;">ST22771AA030</p>	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems. <ul style="list-style-type: none"> • English: 22771AA030 (Without printer) • German: 22771AA070 (Without printer) • French: 22771AA080 (Without printer) • Spanish: 22771AA090 (Without printer)

2. GENERAL PURPOSE TOOLS

TOOL NAME	REMARKS
Compression Gauge	Used for measuring compression.

E: PROCEDURE

It is possible to conduct the following service procedures with engine on the vehicle, however, the procedures described in this section are based on the condition that the engine is removed from the vehicle.

- V-belt
- Timing Belt
- Camshaft
- Cylinder Head

2. Compression

A: INSPECTION

CAUTION:


After warming-up, engine becomes very hot. Be careful not to burn yourself during measurement.

- 1) After warming-up the engine, turn the ignition switch to OFF.
- 2) Make sure that the battery is fully charged.
- 3) Release the fuel pressure. <Ref. to FU(H4DOSTC)-44, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 4) Remove all the spark plugs. <Ref. to IG(H4DOSTC)-5, REMOVAL, Spark Plug.>
- 5) Fully open the throttle valve.
- 6) Check the starter motor for satisfactory performance and operation.
- 7) Hold the compression gauge tight against spark plug hole.

NOTE:

When using a screw-in type compression gauge, the screw (put into cylinder head spark plug hole) should be less than 18 mm (0.71 in) long.

- 8) Crank the engine by means of starter motor, and then read the maximum value on the gauge when the pointer is steady.



- 9) Perform at least two measurements per cylinder, and make sure that the values are correct.

Compression (350 rpm and fully open throttle):

Standard;7

1,079 — 1,275 kPa (11 — 13 kg/cm², 155 — 183 psi)

Limit;

951 kPa (10 kg/cm², 138 psi)

Difference between cylinders;

49 kPa (0.5 kg/cm², 7 psi)

3. Idle Speed

A: INSPECTION

1. USING SUBARU SELECT MONITOR

1) Before checking the idle speed, check the following:

(1) Ensure the air cleaner element is free from clogging, ignition timing is correct, spark plugs are in good condition, and that the hoses are connected properly.

(2) Ensure the malfunction indicator light (CHECK ENGINE light) does not illuminate.

2) Warm-up the engine.

3) Stop the engine, and then turn the ignition switch to OFF.

4) Insert the cartridge to SUBARU SELECT MONITOR.

5) Connect the SUBARU SELECT MONITOR to data link connector.

6) Turn the ignition switch to ON, and SUBARU SELECT MONITOR switch to ON.

7) Select the {2. Each System Check} in Main Menu.

8) Select the {Engine Control System} in Selection Menu.

9) Select the {1. Current Data Display & Save} in Engine Control System Diagnosis.

10) Select the {1.12 Data Display} in Data Display Menu.

11) Start the engine, and then read the engine idle speed.

12) Check the idle speed when unloaded. (With headlights, heater fan, rear defroster, radiator fan, air conditioning, etc. OFF)

Idle speed [No load and gears in neutral]:

700 ±100 rpm (MT vehicles)

650 ±100 rpm (AT vehicles)

13) Check the idle speed when loaded. (Turn the air conditioning switch to "ON" and operate the compressor for at least 1 minute before measurement.)

Idle speed [A/C "ON", no load and gears in neutral]:

800 ±150 rpm (MT vehicles)

850 ±150 rpm (AT vehicles)

NOTE:

As idle speed is controlled by the automatic adjustment type, it can not be adjusted manually. If the idle speed is out of specifications, refer to General On-board Diagnosis Table under "Engine Control System". <Ref. to EN(H4DOSTC)-2, Basic Diagnostic Procedure.>

4. Ignition Timing

A: INSPECTION

1. USING SUBARU SELECT MONITOR

1) Before checking the ignition timing speed, check the following:

(1) Ensure the air cleaner element is free from clogging, spark plugs are in good condition, and that hoses are connected properly.

(2) Ensure the malfunction indicator light (CHECK ENGINE light) does not illuminate.

2) Warm-up the engine.

3) Stop the engine, and then turn the ignition switch to OFF.

4) Insert the cartridge to SUBARU SELECT MONITOR.

5) Connect the SUBARU SELECT MONITOR to data link connector.

6) Turn the ignition switch to ON, and SUBARU SELECT MONITOR switch to ON.

7) Select the {2. Each System Check} in Main Menu.

8) Select the {Engine Control System} in Selection Menu.

9) Select the {1. Current Data Display & Save} in Engine Control System Diagnosis.

10) Select the {1.12 Data Display} in Data Display Menu.

11) Start the engine, at idle speed and check the ignition timing.

Ignition timing [BTDC/rpm]:

14±10°/700

If the timing is not correct, check the ignition control system. Refer to Engine Control System. <Ref. to EN(H4DOSTC)-2, Basic Diagnostic Procedure.>

INTAKE MANIFOLD VACUUM


MECHANICAL

5. Intake Manifold Vacuum

A: INSPECTION

- 1) Warm-up the engine.
- 2) Disconnect the brake vacuum hose, and then install the vacuum gauge to hose fitting on manifold.
- 3) Keep the engine at the idle speed, and then read the vacuum gauge indication.

By observing the gauge needle movement, the internal condition of the engine can be diagnosed as described below.




Vacuum pressure (at idling, A/C "OFF"):
Less than -64.0 kPa (-480 mmHg, -18.90 inHg)

Diagnosis of engine condition by measurement of manifold vacuum	
Vacuum gauge indication	Possible engine condition
1. Needle is steady but lower than normal position. This tendency becomes more evident as engine temperature rises.	Leakage around intake manifold gasket or disconnection or damaged vacuum hose
2. When engine speed is reduced slowly from higher speed, needle stops temporarily when it is lowering or becomes steady above normal position.	Back pressure too high, or exhaust system clogged
3. Needle intermittently drops to position lower than normal position.	Leakage around cylinder
4. Needle drops suddenly and intermittently from normal position.	Sticky valves
5. When engine speed is gradually increased, needle begins to vibrate rapidly at certain speed, and then vibration increases as engine speed increases.	Weak or broken valve springs
6. Needle vibrates above and below normal position in narrow range.	Defective ignition system or throttle chamber idle adjustment.


6. Engine Oil Pressure

A: INSPECTION

- 1) Remove the oil pressure switch from engine cylinder block. <Ref. to LU(H4DOSTC)-18, REMOVAL, Oil Pressure Switch.>
- 2) Connect the oil pressure gauge hose to cylinder block.
- 3) Connect the battery ground cable to battery.



- 4) Start the engine, and then measure the oil pressure.



Oil pressure:

98 kPa (1.0 kg/cm², 14 psi) or more at 800 rpm

294 kPa (3.0 kg/cm², 43 psi) or more at 5,000 rpm

- If the oil pressure is out of specification, check oil pump, oil filter and lubrication line. <Ref. to LU(H4DOSTC)-22, INSPECTION, Engine Lubrication System Trouble in General.>
- If the oil pressure warning light is turned ON and oil pressure is in specification, replace the oil pressure switch. <Ref. to LU(H4DOSTC)-22, INSPECTION, Engine Lubrication System Trouble in General.>

NOTE:

The specified data is based on an engine oil temperature of 80°C (176°F).

- 5) After measuring the oil pressure, install the oil pressure switch. <Ref. to ME(H4DOSTC)-42, INSTALLATION, V-belt.>

Tightening torque:

25 N·m (2.5 kgf-m, 18.1 ft-lb)

FUEL PRESSURE

MECHANICAL

7. Fuel Pressure

A: INSPECTION

CAUTION:

Before removing the fuel pressure gauge, release the fuel pressure.


NOTE:

If out of specification, check or replace the pressure regulator and pressure regulator vacuum hose.


1) Release the fuel pressure. <Ref. to FU(H4DOSTC)-44, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>

2) Open the fuel flap lid, and then remove the fuel filler cap.

3) Disconnect the fuel delivery hoses from fuel filter, and then connect the fuel pressure gauge.



4) Connect the connector of fuel pump relay (A).




5) Start the engine.

6) Measure the fuel pressure while disconnecting the pressure regulator vacuum hose from intake manifold.

Fuel pressure:


Standard; 284 — 314 kPa (2.9 — 3.2 kg/cm², 41 — 46 psi)



7) After connecting the pressure regulator vacuum hose, measure the fuel pressure.

Fuel pressure:

Standard; 230 — 260 kPa (2.35 — 2.65 kg/cm², 33 — 38 psi)



NOTE:


The fuel pressure gauge registers 10 to 20 kPa (0.1 to 0.2 kgf/cm², 1 to 3 psi) higher than standard values during high-altitude operations.

8. Valve Clearance


A: INSPECTION

Inspection and adjustment of the valve clearance should be performed while engine is cold.

- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from battery.




- 3) Remove the air intake duct. <Ref. to IN(H4DOSTC)-11, REMOVAL, Air Intake Duct.>
- 4) Remove the bolt which secures belt cover (RH).
- 5) Lift-up the vehicle.
- 6) Remove the under cover.
- 7) Loosen the remaining bolts which secure belt cover (RH), and then remove the belt cover.
- 8) Lower the vehicle.
- 9) When inspecting the #1 and #3 cylinders:
 - (1) Pull out the engine harness connector with bracket from air cleaner upper cover.




- (2) Remove the air cleaner case. <Ref. to IN(H4DOSTC)-10, REMOVAL, Air Cleaner.>
- (3) Disconnect the ignition coil connector.
- (4) Remove the ignition coil.
- (5) Place a suitable container under the vehicle.
- (6) Disconnect the PCV hose from rocker cover (RH).
- (7) Remove the bolts, and then remove the rocker cover (RH).
- 10) When inspecting the #2 and #4 cylinders:


- (1) Disconnect the battery cable, and then remove the battery and battery carrier.




- (2) Remove the bolt which secures engine harness bracket onto body.



- (3) Disconnect the washer motor connectors.




- (4) Remove the washer tank mounting bolts.



VALVE CLEARANCE

MECHANICAL

- (5) Move the washer tank upward.




- (6) Disconnect the ignition coil connector.
(7) Remove the ignition coil.
(8) Place a suitable container under the vehicle.
(9) Disconnect the PCV hose from rocker cover (LH).
(10) Remove the bolts, and then remove the rocker cover (LH).

- 11) Turn the crankshaft pulley clockwise until arrow mark on the camshaft sprocket is set to position shown in the figure.

NOTE:

Turn the crankshaft using socket wrench.



- 12) Measure the #1 cylinder intake valve and #3 cylinder exhaust valve clearance by using thickness gauge (A).

NOTE:

- Insert the thickness gauge in as horizontal a direction as possible with respect to the shim.
- Measure the exhaust valve clearances while lifting-up the vehicle.


Valve clearance:

Intake: 0.20 ± 0.02 mm (0.0079 ± 0.0008 in)

Exhaust: 0.25 ± 0.02 mm (0.0098 ± 0.0008 in)

NOTE:


If the measured value is not within specification, take notes of the value in order to adjust the valve clearance later on.




- 13) If necessary, adjust the valve clearance. <Ref. to ME(H4DOSTC)-29, ADJUSTMENT, Valve Clearance.>

- 14) Further turn the crankshaft pulley clockwise. Using the same procedures described previously, and then measure the valve clearances again.


- (1) Set the arrow mark on camshaft sprocket to position shown in the figure, and then measure the #2 cylinder exhaust valve and #3 cylinder intake valve clearances.



- (2) Set the arrow mark on camshaft sprocket to position shown in the figure, and then measure the #2 cylinder intake valve and #4 cylinder exhaust valve clearances.




(3) Set the arrow mark on camshaft sprocket to position shown in the figure, and then measure the #1 cylinder exhaust valve and #4 cylinder intake valve clearances.



15) After inspection, install the related parts in the reverse order of removal.

Tightening torque:

32 N·m (3.3 kgf·m, 24 ft·lb)



B: ADJUSTMENT


CAUTION:

Adjustment of the valve clearance should be performed while engine is cold.

1) Measure all valve clearances. <Ref. to ME(H4DOSTC)-27, INSPECTION, Valve Clearance.>

NOTE:


Record each valve clearance after it has been measured.



2) Remove the camshaft. <Ref. to ME(H4DOSTC)-57, REMOVAL, Camshaft.>

3) Remove the valve lifter.

4) Measure the thickness of valve lifter with a micrometer.



5) Select a shim of suitable thickness using measured valve clearance and valve lifter thickness, by referring to the following table.

6) Set the suitable shim selected in step 4) to valve lifter.

Unit: mm	
Intake valve:	$S = (V + T) - 0.20$
Exhaust valve:	$S = (V + T) - 0.25$
S:	Valve lifter thickness to be used
V:	Measured valve clearance
T:	Shim thickness required

Part No.	Thickness mm (in)
13228 AB101	4.68 (0.1843)
13228 AB111	4.69 (0.1846)
13228 AB121	4.70 (0.1850)
13228 AB131	4.71 (0.1854)
13228 AB141	4.72 (0.1858)
13228 AB151	4.73 (0.1862)
13228 AB161	4.74 (0.1866)
13228 AB171	4.75 (0.1870)
13228 AB181	4.76 (0.1874)
13228 AB191	4.77 (0.1878)
13228 AB201	4.78 (0.1882)
13228 AB211	4.79 (0.1886)
13228 AB221	4.80 (0.1890)
13228 AB231	4.81 (0.1894)
13228 AB241	4.82 (0.1898)
13228 AB251	4.83 (0.1902)
13228 AB261	4.84 (0.1906)
13228 AB271	4.85 (0.1909)
13228 AB281	4.86 (0.1913)
13228 AB291	4.87 (0.1917)
13228 AB301	4.88 (0.1921)
13228 AB311	4.89 (0.1925)
13228 AB321	4.90 (0.1929)
13228 AB331	4.91 (0.1933)
13228 AB341	4.92 (0.1937)
13228 AB351	4.93 (0.1941)

VALVE CLEARANCE

MECHANICAL

Part No.	Thickness mm (in)
13228 AB361	4.94 (0.1945)
13228 AB371	4.95 (0.1949)
13228 AB381	4.96 (0.1953)
13228 AB391	4.97 (0.1957)
13228 AB401	4.98 (0.1961)
13228 AB411	4.99 (0.1965)
13228 AB421	5.00 (0.1969)
13228 AB431	5.01 (0.1972)
13228 AB441	5.02 (0.1976)
13228 AB451	5.03 (0.1980)
13228 AB461	5.04 (0.1984)
13228 AB471	5.05 (0.1988)
13228 AB481	5.06 (0.1992)
13228 AB491	5.07 (0.1996)
13228 AB501	5.08 (0.2000)
13228 AB511	5.09 (0.2004)
13228 AB521	5.10 (0.2008)
13228 AB531	5.11 (0.2012)
13228 AB541	5.12 (0.2016)
13228 AB551	5.13 (0.2020)
13228 AB561	5.14 (0.2024)
13228 AB571	5.15 (0.2028)
13228 AB581	5.16 (0.2031)
13228 AB591	5.17 (0.2035)
13228 AB601	5.18 (0.2039)
13228 AB611	5.19 (0.2043)
13228 AB621	5.20 (0.2047)
13228 AB631	5.21 (0.2051)
13228 AB641	5.22 (0.2055)
13228 AB651	5.23 (0.2059)
13228 AB661	5.24 (0.2063)
13228 AB671	5.25 (0.2067)
13228 AB681	5.26 (0.2071)
13228 AB691	5.27 (0.2075)
13228 AB701	4.38 (0.1724)
13228 AB711	4.40 (0.1732)
13228 AB721	4.42 (0.1740)
13228 AB731	4.44 (0.1748)
13228 AB741	4.46 (0.1756)
13228 AB751	4.48 (0.1764)
13228 AB761	4.50 (0.1771)
13228 AB771	4.52 (0.1780)
13228 AB781	4.54 (0.1787)
13228 AB791	4.56 (0.1795)
13228 AB801	4.58 (0.1803)
13228 AB811	4.60 (0.1811)
13228 AB821	4.62 (0.1819)
13228 AB831	4.64 (0.1827)
13228 AB841	4.66 (0.1835)
13228 AB851	5.29 (0.2083)
13228 AB861	5.31 (0.2091)

Part No.	Thickness mm (in)
13228 AB871	5.33 (0.2098)
13228 AB881	5.35 (0.2106)
13228 AB891	5.37 (0.2114)
13228 AB901	5.39 (0.2122)
13228 AB911	5.41 (0.2123)
13228 AB921	5.43 (0.2138)
13228 AB931	5.45 (0.2146)
13228 AB941	5.47 (0.2154)
13228 AB951	5.49 (0.2161)
13228 AB961	5.51 (0.2169)
13228 AB971	5.53 (0.2177)
13228 AB981	5.55 (0.2185)
13228 AB991	5.57 (0.2193)
13228 AC001	5.59 (0.2201)
13228 AC011	5.61 (0.2209)
13228 AC021	5.63 (0.2217)
13228 AC031	5.65 (0.2224)


7) Inspect all valves for clearance again at this stage. If the valve clearance is not correct, repeat the procedure over again from the first step.

8) After inspection, install the related parts in the reverse order of removal.


9. Engine Assembly

A: REMOVAL

- 1) Set the vehicle on lift arms.
- 2) Open the front hood fully, and then support with the hood stay.
- 3) Collect the refrigerant from A/C system. <Ref. to AC-23, Refrigerant Recovery Procedure.>
- 4) Release the fuel pressure.
 - (1) Disconnect the fuel pump relay (A) connector.




- (2) Start the engine, and run until stalls.
- (3) After the engine stalls, crank it for 5 seconds more.
- (4) Turn the ignition switch to OFF.
- 5) Remove the filler cap.
- 6) Disconnect the ground cable from battery.




- 7) Remove the radiator from vehicle. <Ref. to CO(H4DOSTC)-23, REMOVAL, Radiator.>
- 8) Remove the coolant filler tank. <Ref. to CO(H4DOSTC)-33, REMOVAL, Coolant Filler Tank.>


- 9) Disconnect the A/C pressure hoses from A/C compressor.




- 10) Remove the intercooler. <Ref. to IN(H4DOSTC)-13, REMOVAL, Intercooler.>
- 11) Disconnect the following connectors and cable.
 - (1) Engine harness connector



- (2) Engine ground terminal




- (3) Engine harness connector



ENGINE ASSEMBLY


MECHANICAL

- (4) Generator connector, terminal and A/C compressor connectors




- (A) A/C compressor connector
(B) Generator connector and terminal

- (5) Accelerator cable (MT vehicles)




- (6) Clutch release spring (MT vehicles)




- 12) Disconnect the following hoses.

- (1) Brake booster vacuum hose




- (2) Heater inlet outlet hose




- 13) Remove the power steering pump from bracket.

- (1) Loosen the lock bolt and slider bolt, and then remove the front side V-belt. <Ref. to ME(H4DOSTC)-42, REMOVAL, V-belt.>


- (2) Disconnect the power steering switch connector.




- (3) Remove the pipe with bracket from intake manifold.




(4) Remove the power steering pump from engine.



(5) Remove the power steering tank from bracket by pulling it upward.



(6) Place the power steering pump on right side wheel apron.




14) Lift-up the vehicle.


15) Remove the ATF cooler pipe from frame. (AT vehicles)

16) Remove the center exhaust pipe. <Ref. to EX(H4DOSTC)-7, REMOVAL, Center Exhaust Pipe.>

17) Remove the nuts which hold lower side of transmission to engine.



18) Remove the nuts which install front cushion rubber onto front crossmember.




19) Lower the vehicle.

20) Separate the clutch release fork from release bearing. (MT vehicles)

(1) Remove the clutch operating cylinder from transmission.


(2) Remove the plug using a 10 mm hexagon wrench.



ENGINE ASSEMBLY

MECHANICAL

(3) Screw the 6 mm dia. bolt into release fork shaft, and remove it.



- (A) Shaft
- (B) Bolt


(4) Raise the release fork, and then unfasten the release bearing tabs to free release fork.

NOTE:


Step (4) is required to prevent interference with engine when removing the engine from transmission.

21) Separate the torque converter clutch from drive plate. (AT vehicles)

- (1) Lower the vehicle.
- (2) Remove the service hole plug.
- (3) Remove the bolts which hold torque converter clutch to drive plate.
- (4) Remove the other bolts while rotating the engine using socket wrench.




22) Remove the pitching stopper.




23) Disconnect the fuel delivery hose, return hose and evaporation hose.

NOTE:

- Catch fuel from the hose into container.
- Disconnect the hose with its end wrapped with cloth to prevent fuel from splashing.




24) Support the engine with a lifting device and wire ropes.



25) Support the transmission with a garage jack.

NOTE:


Before moving the engine away from transmission, check to be sure no work has been overlooked. Doing this is very important in order to facilitate reinstallation and because transmission lowers under its own weight.




26) Separation of the engine and transmission.

- (1) Remove the starter. <Ref. to SC(H4DOSTC)-6, REMOVAL, Starter.>
- (2) Install the ST to torque converter clutch case. (AT vehicles)

ST 498277200 STOPPER SET



(3) Remove the bolts which hold right upper side of transmission to engine.



27) Remove the engine from vehicle.

- (1) Slightly raise the engine.
- (2) Raise the transmission with garage jack.
- (3) Move the engine horizontally until the main-shaft is withdrawn from clutch cover.
- (4) Slowly move the engine away from engine compartment.

NOTE:


Be careful not to damage adjacent parts or body panels with crank pulley, oil pressure gauge, etc.

28) Remove the front cushion rubbers.


B: INSTALLATION

1) Install the clutch release fork and bearing onto transmission. (MT vehicles)

- (1) Remove the release bearing from clutch cover with flat type screw driver.



- (2) Install the release bearing on transmission.
- (3) Install the release fork into release bearing tab.




- (A) Release fork
- (B) Release bearing

ENGINE ASSEMBLY

MECHANICAL

- (4) Apply grease to the specified points.
- Spline FX2200
 - Shaft SUNLIGHT 2




- (A) Spline (FX2200)
(B) Shaft (SUNLIGHT 2)

- (5) Insert the release fork shaft into release fork.

NOTE:

Make sure the cutout portion of release fork shaft contacts spring pin.




- (A) Release fork
(B) Release shaft
(C) Spring pin

- (6) Tighten the plug.

Tightening torque:

44 N·m (4.5 kgf-m, 32.5 ft-lb)



- 2) Install the front cushion rubbers to engine.

Tightening torque:

34 N·m (3.5 kgf-m, 25.3 ft-lb)

- 3) Install the engine onto transmission.

- (1) Position the engine in engine compartment, and then align it with the transmission.

NOTE:


Be careful not to damage the adjacent parts or body panels with crank pulley, oil pressure gauge, etc.

- (2) Apply a small amount of grease to the splines of mainshaft. (MT vehicles)

- 4) Tighten the bolts which hold right upper side of transmission to engine.


Tightening torque:

50 N·m (5.1 kgf-m, 36.9 ft-lb)



- 5) Remove the lifting device and wire ropes.

6) Remove the garage jack.




7) Install the pitching stopper.

Tightening torque:

T1: 50 N·m (5.1 kgf-m, 37 ft-lb)

T2: 58 N·m (5.9 kgf-m, 43 ft-lb)



8) Remove the ST from torque converter clutch case. (AT vehicles)

NOTE:

Be careful not to drop the ST into torque converter clutch case when removing ST.

ST 498277200 STOPPER SET

9) Install the starter. <Ref. to SC(H4DOSTC)-6, INSTALLATION, Starter.>

10) Install the torque converter clutch onto drive plate. (AT vehicles)

(1) Tighten the bolts which hold torque converter clutch to drive plate.

(2) Tighten other bolts while rotating the engine by using ST.


NOTE:

Be careful not to drop bolts into the torque converter clutch housing.

ST 499977300 CRANK PULLEY WRENCH


Tightening torque:

25 N·m (2.5 kgf-m, 18.1 ft-lb)




(3) Clog the service hole with plug.

11) Install the fuel filter and bracket.



12) Install the power steering pump on bracket.


(1) Install the power steering tank on bracket.



(2) Install the power steering pump.

Tightening torque:


20.1 N·m (2.05 kgf-m, 14.8 ft-lb)




ENGINE ASSEMBLY

MECHANICAL

- (3) Install the power steering pipe bracket on right side intake manifold.



- (4) Connect the power steering switch connector.




- (5) Install the front side V-belt, and adjust it.
<Ref. to ME(H4DOSTC)-42, INSTALLATION, V-belt.>

- 13) Lift-up the vehicle.

- 14) Tighten the nuts which hold lower side of transmission to engine.

Tightening torque:

50 N·m (5.1 kgf·m, 36.9 ft·lb)




- 15) Tighten the nuts which install front cushion rubber onto crossmember.

Tightening torque:

83 N·m (8.5 kgf·m, 61 ft·lb)

NOTE:

Make sure the front cushion rubber mounting bolts (A) and locator (B) are securely installed.



- 16) Install the ATF cooler pipe to frame. (AT vehicles)

- 17) Install the center exhaust pipe.

<Ref. to EX(H4DOSTC)-8, INSTALLATION, Center Exhaust Pipe.>

- 18) Lower the vehicle.

- 19) Connect the following hoses:

- (1) Fuel delivery hose, return hose and evaporation hose
- (2) Heater inlet and outlet hoses
- (3) Brake booster vacuum hose

- 20) Connect the following connectors and terminals:

- (1) Engine ground terminal
- (2) Engine harness connectors
- (3) Generator connector and terminal
- (4) A/C compressor connectors

- 21) Connect the following cables:

- (1) Accelerator cable
- (2) Clutch release spring

- 22) After connecting each cable, adjust them.

- 23) Install the air intake system.

- (1) Install the intercooler. <Ref. to IN(H4DOSTC)-14, INSTALLATION, Intercooler.>
- (2) Install the air cleaner element and air cleaner upper cover.
- (3) Install the engine harness connector bracket.
- (4) Install the filler hose to air cleaner case.


24) Install the A/C pressure hoses.

NOTE:

Use new O-rings.

Tightening torque:

25 N·m (2.5 kgf-m, 18.1 ft-lb)



25) Install the radiator. <Ref. to CO(H4DOSTC)-24, INSTALLATION, Radiator.>

26) Install the coolant filler tank. <Ref. to CO(H4DOSTC)-33, INSTALLATION, Coolant Filler Tank.>

27) Install the window washer tank.

28) Install the battery in the vehicle, and connect cables.

29) Fill coolant. <Ref. to CO(H4DOSTC)-15, FILLING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>

30) Charge the A/C system with refrigerant. <Ref. to AC-24, OPERATION, Refrigerant Charging Procedure.>

31) Remove the front hood stay, and close the front hood.

32) Take off the vehicle from lift arms.

10.Engine Mounting

A: REMOVAL

1) Remove the engine assembly. <Ref. to ME(H4DOSTC)-31, REMOVAL, Engine Assembly.>

2) Remove the engine mounting from engine assembly.

B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

Engine mounting;

34 N·m (3.5 kgf-m, 25.3 ft-lb)

C: INSPECTION


Make sure there are no cracks or other damage.

11.Preparation for Overhaul

A: PROCEDURE

1) After removing the engine from body, secure it in the ST shown below.

ST1	498457000	ENGINE STAND ADAPTER RH
ST2	498457100	ENGINE STAND ADAPTER LH
ST3	499817000	ENGINE STAND



2) In this section the procedures described under each index are all connected and stated in order. It will be the complete procedure for overhauling of the engine itself when you go through all steps in the process.

Therefore, in this section, to conduct the particular procedure within the flow of a section, you need to go back and conduct the procedure described previously in order to do that particular procedure.

12.V-belt


A: REMOVAL

1. FRONT SIDE BELT

NOTE:


Perform the following procedures 1) to 4) with the engine installed to the body.

- 1) Remove the V-belt cover.
- 2) Loosen the lock bolt (A).
- 3) Loosen the slider bolt (B).
- 4) Remove the front side belt (C).




2. REAR SIDE BELT

- 1) Loosen the lock nut (A).
- 2) Loosen the slider bolt (B).



- 3) Remove the A/C belt.
- 4) Remove the A/C belt tensioner.



B: INSTALLATION

1. FRONT SIDE BELT

CAUTION:

Wipe off any oil or water on the belt and pulley.

- 1) Install the belt (C), and tighten the slider bolt so as to obtain the specified belt tension. <Ref. to ME(H4DOSTC)-43, INSPECTION, V-belt.>
- 2) Tighten the lock bolt (A).
- 3) Tighten the slider bolt (B).


Tightening torque:

Lock bolt through bolt:

25 N·m (2.5 kgf-m, 18.1 ft-lb)

Slider bolt:

8 N·m (0.8 kgf-m, 5.5 ft-lb)




2. REAR SIDE BELT

- 1) Install the belt, and tighten the slider bolt (B) so as to obtain the specified belt tension. <Ref. to ME(H4DOSTC)-43, INSPECTION, V-belt.>
- 2) Tighten the lock nut (A).

Tightening torque:


Lock nut (A);

22.6 N·m (2.3 kgf-m, 16.6 ft-lb)



C: INSPECTION

- 1) Replace the belts, if cracks, fraying or wear is found.
- 2) Check the drive belt tension and adjust it if necessary by changing generator installing position and/or idler pulley installing position.

Belt tension**(A)****replaced: 7 — 9 mm (0.276 — 0.354 in)****reused: 9 — 11 mm (0.354 — 0.433 in)****(B)*****replaced: 7.5 — 8.5 mm (0.295 — 0.335 in)****reused: 9.0 — 10.0 mm (0.354 — 0.394 in)*****: with air conditioner**

C/P Crankshaft pulley

GEN Generator

P/S Power steering oil pump pulley

A/C Air conditioning compressor pulley

I/P Idler pulley

CRANKSHAFT PULLEY

MECHANICAL

13. Crankshaft Pulley


A: REMOVAL

1) Remove the V-belt. <Ref. to ME(H4DOSTC)-42, REMOVAL, V-belt.>

2) Remove the crankshaft pulley bolt. To lock the crankshaft, use ST.

ST 499977100 CRANKSHAFT PULLEY WRENCH (MT vehicles)

ST 499977400 CRANKSHAFT PULLEY WRENCH (AT vehicles)



3) Remove the crankshaft pulley.

B: INSTALLATION

1. MT MODEL

1) Install the crankshaft pulley.

2) Install the pulley bolt.

To lock the crankshaft, use ST.

ST 499977100 CRANKSHAFT PULLEY WRENCH

(1) Clean the crankshaft pulley thread using an air gun.


(2) Apply engine oil to the crankshaft pulley bolt seat and thread.

(3) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf-m, 33 ft-lb).

(4) Tighten the crankshaft pulley bolts.

Tightening torque:

177 N·m (18.0 kgf-m, 130.2 ft-lb)



3) Confirm that the tightening angle of crankshaft pulley bolt is 65 degrees or more. If not, conduct the following procedures (1) through (4).

(1) Replace the crankshaft pulley bolts.

Crankshaft pulley bolt:

12369AA011

(2) Clean the crankshaft thread using an air gun.


(3) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf-m, 33 ft-lb).

(4) Tighten the crankshaft pulley bolts keeping them in an angle between 65 degrees and 75 degrees.

NOTE:

Conduct the tightening procedures by confirming the turning angle of the crankshaft pulley bolt referring to the gauge indicated on the belt cover.

4) Install the A/C belt tensioner.



5) Install the V-belt. <Ref. to ME(H4DOSTC)-42, INSTALLATION, V-belt.>

2. AT MODEL

1) Install the crankshaft pulley.

2) Install the pulley bolt.

To lock the crankshaft, use ST.

ST 499977400 CRANKSHAFT PULLEY WRENCH

(1) Clean the crankshaft pulley thread using an air gun.


(2) Apply engine oil to the crankshaft pulley bolt seat and thread.

(3) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf-m, 33 ft-lb).

(4) Tighten the crankshaft pulley bolts.

Tightening torque:

127 N·m (13 kgf-m, 94.0 ft-lb)



3) Confirm that the tightening angle of crankshaft pulley bolt is 45 degrees or more. If the confirmed value is less than 45 degrees, conduct the following procedures (1) through (4).

- (1) Replace the crankshaft pulley bolts.

Crankshaft pulley bolt:


12369AA011

- (2) Clean the crankshaft thread using an air gun.
- (3) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf-m, 33 ft-lb).
- (4) Tighten the crankshaft pulley bolts keeping them in an angle between 45 degrees and 60 degrees.

NOTE:

Conduct the tightening procedures by confirming the turning angle of the crankshaft pulley bolt referring to the gauge indicated on the belt cover.

- 4) Install the A/C belt tensioner.



5) Install the V-belt. <Ref. to ME(H4DOSTC)-42, INSTALLATION, V-belt.>


C: INSPECTION

- 1) Make sure the V-belt is not worn or otherwise damaged.
- 2) Check the tension of the belt. <Ref. to ME(H4DOSTC)-43, INSPECTION, V-belt.>

14. Belt Cover

A: REMOVAL

- 1) Remove the V-belt. <Ref. to ME(H4DOSTC)-42, REMOVAL, V-belt.>
- 2) Remove the crankshaft pulley. <Ref. to ME(H4DOSTC)-44, REMOVAL, Crankshaft Pulley.>
- 3) Remove the belt cover (LH) (A).
- 4) Remove the belt cover (RH) (B).
- 5) Remove the front belt cover (C).



B: INSTALLATION

- 1) Install the front belt cover (C).

Tightening torque:

5 N·m (0.5 kgf·m, 3.6 ft·lb)

- 2) Install the belt cover (RH) (B).


Tightening torque:

5 N·m (0.5 kgf·m, 3.6 ft·lb)

- 3) Install the belt cover (LH) (A).

Tightening torque:

5 N·m (0.5 kgf·m, 3.6 ft·lb)



- 4) Install the crankshaft pulley. <Ref. to ME(H4DOSTC)-44, INSTALLATION, Crankshaft Pulley.>
- 5) Install the V-belt. <Ref. to ME(H4DOSTC)-42, INSTALLATION, V-belt.>

C: INSPECTION





Make sure the cover is not damaged.

15. Timing Belt Assembly

A: REMOVAL

1. TIMING BELT


- 1) Remove the V-belt.
<Ref. to ME(H4DOSTC)-42, REMOVAL, V-belt.>
- 2) Remove the crankshaft pulley.
<Ref. to ME(H4DOSTC)-44, REMOVAL, Crankshaft Pulley.>
- 3) Remove the belt cover.
<Ref. to ME(H4DOSTC)-46, REMOVAL, Belt Cover.>
- 4) Remove the timing belt guide. (MT vehicles)




5) If the alignment mark and/or arrow mark (which indicates rotation direction) on timing belt fade away, put new marks before removing the timing belt as follows:

- (1) Turn the crankshaft using ST, and align the alignment marks on crankshaft sprocket, intake camshaft sprocket (LH), exhaust camshaft sprocket (LH), intake camshaft sprocket (RH) and exhaust camshaft sprocket (RH) with notches of belt cover and cylinder block.

ST 499987500 CRANKSHAFT SOCKET




- (2) Using white paint, put alignment and/or arrow marks on the timing belts in relation to the sprockets.




TIMING BELT ASSEMBLY


MECHANICAL



Z₁: 54.5 tooth length
Z₂: 51 tooth length
Z₃: 28 tooth length



6) Remove the belt idler (A).




7) Remove the timing belt.

CAUTION:


After the timing belt has been removed, never rotate the intake and exhaust, camshaft sprocket. If the camshaft sprocket is rotated, the intake and exhaust valve heads strike together and valve stems are bent.

2. BELT IDLER AND AUTOMATIC BELT TENSION ADJUSTER ASSEMBLY


1) Remove the belt idler (B) and (C).



2) Remove the belt idler No. 2.



3) Remove the automatic belt tension adjuster assembly.



B: INSTALLATION

1. BELT IDLER AND AUTOMATIC BELT TENSION ADJUSTER ASSEMBLY


1) Preparation for installation of automatic belt tension adjuster assembly;

NOTE:


- Always use a vertical type pressing tool to move the adjuster rod down.
- Do not use a lateral type vise.
- Push the adjuster rod vertically.
- Be sure to slowly move the adjuster rod down applying a pressure of 294 N (30 kgf, 66 lb).
- Press-in the push adjuster rod gradually taking more than 3 minutes.
- Do not allow press pressure to exceed 9,807 N (1,000 kgf, 2,205 lb).
- Press the adjuster rod as far as the end surface of the cylinder. Do not press the adjuster rod into the cylinder. Doing so may damage the cylinder.
- Do not release press pressure until stopper pin is completely inserted.

(1) Attach the automatic belt tension adjuster assembly to the vertical pressing tool.

(2) Slowly move the adjuster rod down with a pressure of 294 N (30 kgf, 66 lb) until the adjuster rod is aligned with the stopper pin hole in the cylinder.




(3) With a 2 mm (0.08 in) dia. stopper pin or a 2 mm (0.08 in) (nominal) dia. hex bar wrench inserted into the stopper pin hole in the cylinder, secure the adjuster rod.



2) Install automatic belt tension adjuster assembly.

Tightening torque:


39 N·m (4.0 kgf·m, 28.9 ft·lb)



3) Install belt idler No. 2.

Tightening torque:


39 N·m (4.0 kgf·m, 28.9 ft·lb)



4) Install the belt idler.

Tightening torque:

39 N·m (4.0 kgf·m, 28.9 ft·lb)



2. TIMING BELT


1) Preparation for installation of automatic belt tension adjuster assembly. <Ref. to ME(H4DOSTC)-49, TIMING BELT, INSTALLATION, Timing Belt Assembly.>

2) Crankshaft and camshaft sprocket alignment.


TIMING BELT ASSEMBLY

MECHANICAL


(1) Align mark (A) on the crankshaft sprocket with mark on the oil pump cover at cylinder block.




(2) Align single line mark (A) on the exhaust camshaft sprocket (RH) with notch (B) on belt cover.



(3) Align single line mark (A) on the intake camshaft sprocket (RH) with notch (B) on belt cover. (Make sure double lines (C) on intake camshaft and exhaust camshaft sprockets are aligned.)




(4) Align single line mark (A) on exhaust camshaft sprocket (LH) with notch (B) on belt cover by turning the sprocket counterclockwise (as viewed from front of engine).



(5) Align the single line mark (A) on intake camshaft sprocket (LH) with notch (B) on belt cover by turning the sprocket clockwise (as viewed from front of engine).

Ensure the double lines (C) on intake and exhaust camshaft sprockets are aligned.




(6) Ensure the camshaft and crankshaft sprockets are positioned properly.

CAUTION:

- Intake and exhaust camshafts for this DOHC engine can be independently rotated with the timing belts removed. As can be seen from the figure, if the intake and exhaust valves are lifted


simultaneously, their heads will interfere with each other, resulting in bent valves.



(A) Intake camshaft
(B) Exhaust camshaft


- When the timing belts are not installed, four camshafts are held at the “zero-lift” position, where all cams on camshafts do not push the intake and exhaust valves down. (Under this condition, all valves remain unlifted.)
- When the camshafts are rotated to install the timing belts, #2 intake and #4 exhaust cam of left-hand camshafts are held to push their corresponding valves down. (Under this condition, these valves are held lifted.) Right-side camshafts are held so that their cams do not push valves down.
- Left-hand camshafts must be rotated from the “zero-lift” position to the position where the timing belt is to be installed at as small an angle as possible, in order to prevent mutual interference of intake and exhaust valve heads.
- Do not allow the camshafts to rotate in the direction shown in the figure as this causes both

intake and exhaust valves to lift simultaneously, resulting in interference with their heads.



(A) Rotating direction
(B) Timing belt installation position

3) Installation of timing belt:



Align the alignment mark on timing belt with marks on sprockets in alphabetical order shown in the figure.


While aligning marks, position the timing belt properly.

CAUTION:

- Disengagement of more than three timing belt teeth may result in interference between the valve and piston.
- Ensure the belt's rotating direction is correct.

TIMING BELT ASSEMBLY

MECHANICAL



- (1) Arrow mark
- (2) Timing belt
- (3) 28 tooth length
- (4) 54.5 tooth length
- (5) 51 tooth length
- (6) 28 tooth length
- (7) Install it in the end


4) Install the belt idlers.

Tightening torque:

39 N·m (4.0 kgf-m, 28.9 ft-lb)

NOTE:

Make sure that the marks on the timing belt and sprockets are aligned.



5) After ensuring that the marks on the timing belt and sprockets are aligned, remove the stopper pin from tensioner adjuster.





TIMING BELT ASSEMBLY

MECHANICAL

- 6) Install the timing belt guide. (MT vehicles)
(1) Temporarily tighten the bolts.
(2) Check and adjust the clearance between timing belt and timing belt guide.

Clearance:


1.0 ± 0.5 mm (0.039 ± 0.020 in)



- (3) Tighten the bolts.


Tightening torque:

10 N·m (1.0 kgf·m, 7.2 ft·lb)




Tightening torque:

6.4 N·m (0.7 kgf·m, 5.1 ft·lb)




Tightening torque:

6.4 N·m (0.7 kgf·m, 5.1 ft·lb)



Tightening torque:

6.4 N·m (0.7 kgf·m, 5.1 ft·lb)



TIMING BELT ASSEMBLY

MECHANICAL

7) Install the belt cover.

<Ref. to ME(H4DOSTC)-46, INSTALLATION, Belt Cover.>

8) Install the crankshaft pulley.

<Ref. to ME(H4DOSTC)-44, INSTALLATION, Crankshaft Pulley.>

9) Install the V-belt.

<Ref. to ME(H4DOSTC)-42, INSTALLATION, V-belt.>

C: INSPECTION

1. TIMING BELT

1) Check the timing belt teeth for breaks, cracks, and wear. If any fault is found, replace the belt.


2) Check the condition of back side of belt; if any crack is found, replace the belt.

NOTE:

- Be careful not to let oil, grease or coolant contact the belt. Remove quickly and thoroughly if this happens.
- Do not bend the belt sharply.

Bending radius: h

60 mm (2.36 in) or more



2. AUTOMATIC BELT TENSION ADJUST-ER

1) Visually check the oil seals for leaks, and rod ends for abnormal wear or scratches. If necessary, replace the automatic belt tension adjuster assembly.

NOTE:

Slight traces of oil at rod's oil seal does not indicate a problem.

2) Check that the adjuster rod does not move when a pressure of 294 N (30 kgf, 66 lb) is applied to it. This is to check adjuster rod stiffness.

3) If the adjuster rod is not stiff and moves freely when applying 294 N (30 kgf, 66 lb), check it using the following procedures:

(1) Slowly press the adjuster rod down to the end surface of the cylinder. Repeat this motion 2 or 3 times.

(2) With the adjuster rod moved all the way up, apply a pressure of 294 N (30 kgf, 66 lb) to it. Check the adjuster rod stiffness.


(3) If the the adjuster rod is not stiff and moves down, replace the automatic belt tension adjuster assembly with a new one.

NOTE:

- Always use a vertical type pressing tool to move the adjuster rod down.
 - Do not use a lateral type vise.
 - Push the adjuster rod vertically.
 - Press-in the push adjuster rod gradually taking more than 3 minutes.
 - Do not allow press pressure to exceed 9,807 N (1,000 kgf, 2,205 lb).
 - Press the adjuster rod as far as the end surface of the cylinder. Do not press the adjuster rod into the cylinder. Doing so may damage the cylinder.
- 4) Measure the extension of rod beyond the body. If it is not within specifications, replace with a new one.

Rod extension: H

5.7±0.5 mm (0.224±0.020 in)



3. BELT TENSION PULLEY

1) Check the mating surfaces of timing belt and contact point of adjuster rod for abnormal wear or scratches. Replace the belt tension pulley if faulty.

2) Check the belt tension pulley for smooth rotation. Replace if noise or excessive play is noted.

3) Check the belt tension pulley for grease leakage.

4. BELT IDLER

1) Check the idler for smooth rotation. Replace if noise or excessive play is noted.

2) Check the outer contacting surfaces of idler pulley for abnormal wear and scratches.

3) Check the idler for grease leakage.