

**ENGINE SECTION 1**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

|   |                                |
|---|--------------------------------|
| <b>FUEL INJECTION (FUEL SYSTEMS)</b>                    | <b>FU(H4SO 2.0)</b>            |
| <b>EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)</b> | <b>EC(H4SO 2.0)</b>            |
| <b>INTAKE (INDUCTION)</b>                               | <b>IN(H4SO 2.0)</b>            |
| <b>MECHANICAL</b>                                       | <b>ME(H4SO 2.0)</b>            |
| <b>EXHAUST</b>  | <b>EX(H4SO 2.0)</b>            |
| <b>COOLING</b>  | <b>CO(H4SO 2.0)</b>            |
| <b>LUBRICATION</b>                                      | <b>LU(H4SO 2.0)</b>            |
| <b>SPEED CONTROL SYSTEMS</b>                            | <b>SP(H4SO 2.0)</b>            |
| <b>IGNITION</b>   | <b>IG(H4SO 2.0)</b>            |
| <b>STARTING/CHARGING SYSTEMS</b>                        | <b>SC(H4SO 2.0)</b>            |
| <b>ENGINE (DIAGNOSTICS)</b>                             | <b>EN(H4SO 2.0)<br/>(diag)</b> |
| <b>FUEL INJECTION (FUEL SYSTEMS)</b>                    | <b>FU(H4SO 2.5)</b>            |
| <b>EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)</b> | <b>EC(H4SO 2.5)</b>            |
| <b>INTAKE (INDUCTION)</b>                               | <b>IN(H4SO 2.5)</b>            |
| <b>MECHANICAL</b>                                       | <b>ME(H4SO 2.5)</b>            |
| <b>EXHAUST</b>  | <b>EX(H4SO 2.5)</b>            |
| <b>COOLING</b>  | <b>CO(H4SO 2.5)</b>            |

ENGINE SECTION 1

LUBRICATION

LU(H4SO 2.5)

SPEED CONTROL SYSTEMS

SP(H4SO 2.5)

IGNITION

IG(H4SO 2.5)

STARTING/CHARGING SYSTEMS

SC(H4SO 2.5)

ENGINE (DIAGNOSTICS)

EN(H4SO 2.5)  
(diag)

# ENGINE (DIAGNOSTICS)

# *EN(H4SO 2.5)(diag)*

---

|   | Page |
|---|------|
| 1. Basic Diagnostic Procedure .....                               | 2    |
| 2. Check List for Interview .....                                 | 3    |
| 3. General Description .....                                      | 5    |
| 4. Electrical Component Location .....                            | 8    |
| 5. Engine Control Module (ECM) I/O Signal .....                   | 17   |
| 6. Engine Condition Data .....                                    | 21   |
| 7. Data Link Connector .....                                      | 22   |
| 8. OBD-II General Scan Tool .....                                 | 23   |
| 9. Subaru Select Monitor .....                                    | 26   |
| 10. Read Diagnostic Trouble Code (DTC) .....                      | 33   |
| 11. Inspection Mode .....   | 34   |
| 12. Drive Cycle .....   | 39   |
| 13. Clear Memory Mode .....                                       | 41   |
| 14. Compulsory Valve Operation Check Mode .....                   | 42   |
| 15. Malfunction Indicator Light .....                             | 44   |
| 16. Diagnostics for Engine Starting Failure .....                 | 54   |
| 17. List of Diagnostic Trouble Code (DTC) .....                   | 70   |
| 18. Diagnostic Procedure with Diagnostic Trouble Code (DTC) ..... | 80   |
| 19. General Diagnostic Table .....                                | 261  |

# Basic Diagnostic Procedure

ENGINE (DIAGNOSTICS)

## 1. Basic Diagnostic Procedure

### A: PROCEDURE

#### 1. ENGINE

| Step   | Check  | Yes  | No  |
|--|--|--|---|
| <b>1 CHECK ENGINE START FAILURE.</b><br>1) Ask the customer when and how the trouble occurred using the interview check list. <Ref. to EN(H4SO 2.5)(diag)-3, CHECK, Check List for Interview.><br>2) Start the engine.   | Does the engine start?                           | Go to step 2.  | Inspection using "Diagnostics for Engine Starting Failure". <Ref. to EN(H4SO 2.5)(diag)-54, Diagnostics for Engine Starting Failure.>   |
| <b>2 CHECK ILLUMINATION OF MALFUNCTION INDICATOR LIGHT.</b>  | Does the malfunction indicator light illuminate? | Go to step 3.  | Inspection using "General Diagnostic Table". <Ref. to EN(H4SO 2.5)(diag)-261, INSPECTION, General Diagnostic Table.>  |
| <b>3 CHECK INDICATION OF DTC ON DISPLAY.</b><br>1) Turn the ignition switch to OFF.<br>2) Connect the Subaru Select Monitor to data link connector.<br>3) Turn the ignition switch to ON, and the Subaru Select Monitor switch to ON.<br>4) Read DTC on Subaru Select Monitor. | Is DTC displayed on the Subaru Select Monitor?   | Record the DTC. Repair the trouble cause. <Ref. to EN(H4SO 2.5)(diag)-70, List of Diagnostic Trouble Code (DTC).><br>Go to step 4.                       | Repair the related parts.<br><b>NOTE:</b><br>If DTC is not shown on display although the engine warning light illuminates, perform the diagnostics of malfunction indicator light circuit or combination meter. <Ref. to EN(H4SO 2.5)(diag)-44, Malfunction Indicator Light.> |
| <b>4 PERFORM DIAGNOSIS.</b><br>1) Perform the clear memory mode. <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.><br>2) Perform the inspection mode. <Ref. to EN(H4SO 2.5)(diag)-34, Inspection Mode.>  | Is DTC displayed on the Subaru Select Monitor?   | Check on "Diagnostic Chart with Diagnostic Trouble Code (DTC)" <Ref. to EN(H4SO 2.5)(diag)-80, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Finish the diagnosis.   |

# Check List for Interview

ENGINE (DIAGNOSTICS)

## 2. Check List for Interview

### A: CHECK

#### 1. CHECK LIST No. 1

Check the following items when problem has occurred.

NOTE:

Use copies of this page for interviewing customers.

|                         |   |                  |  |
|-------------------------|---|------------------|--|
| Customer's name         |   | Engine No.       |  |
| Date of sale            |   | Fuel brand       |  |
| Date of repair          |   | Odometer reading | km   |
| V.I.N.                  |   |                  | miles  |
| Weather                 | <input type="checkbox"/> Fine<br><input type="checkbox"/> Cloudy<br><input type="checkbox"/> Rainy<br><input type="checkbox"/> Snowy<br><input type="checkbox"/> Various/Others:  |                  |  |
| Ambient air temperature | °C (°F)   |                  |  |
|                         | <input type="checkbox"/> Hot<br><input type="checkbox"/> Warm<br><input type="checkbox"/> Cool<br><input type="checkbox"/> Cold   |                  |  |
| Place                   | <input type="checkbox"/> Highway<br><input type="checkbox"/> Suburbs<br><input type="checkbox"/> Inner city<br><input type="checkbox"/> Uphill<br><input type="checkbox"/> Downhill<br><input type="checkbox"/> Rough road<br><input type="checkbox"/> Others:  |                  |  |
| Engine temperature      | <input type="checkbox"/> Cold<br><input type="checkbox"/> Warming-up<br><input type="checkbox"/> After warming-up<br><input type="checkbox"/> Any temperature<br><input type="checkbox"/> Others:   |                  |  |
| Engine speed            | rpm   |                  |  |
| Vehicle speed           | km/h (MPH)  |                  |  |
| Driving conditions      | <input type="checkbox"/> Not affected<br><input type="checkbox"/> At starting<br><input type="checkbox"/> While idling<br><input type="checkbox"/> At racing<br><input type="checkbox"/> While accelerating<br><input type="checkbox"/> While cruising<br><input type="checkbox"/> While decelerating<br><input type="checkbox"/> While turning (RH/LH) |                  |  |
| Headlight               | <input type="checkbox"/> ON / <input type="checkbox"/> OFF  | Rear defogger    | <input type="checkbox"/> ON / <input type="checkbox"/> OFF |
| Blower                  | <input type="checkbox"/> ON / <input type="checkbox"/> OFF  | Audio            | <input type="checkbox"/> ON / <input type="checkbox"/> OFF |
| A/C compressor          | <input type="checkbox"/> ON / <input type="checkbox"/> OFF  | Car phone        | <input type="checkbox"/> ON / <input type="checkbox"/> OFF |
| Radiator fan            | <input type="checkbox"/> ON / <input type="checkbox"/> OFF  |                  |  |
| Front wiper             | <input type="checkbox"/> ON / <input type="checkbox"/> OFF  |                  |  |
| Rear wiper              | <input type="checkbox"/> ON / <input type="checkbox"/> OFF  |                  |  |

# Check List for Interview

## ENGINE (DIAGNOSTICS)

### 2. CHECK LIST No. 2

Check the following items about the vehicle's state when malfunction indicator light turns on.

**NOTE:**

Use copies of this page for interviewing customers.

|   |
|---|
| a) Other warning lights or indicators turn on. <input type="checkbox"/> Yes / <input type="checkbox"/> No   |
| <input type="checkbox"/> Low fuel warning light<br><input type="checkbox"/> Charge indicator light<br><input type="checkbox"/> AT diagnostic indicator light<br><input type="checkbox"/> ABS warning light<br><input type="checkbox"/> Oil pressure indicator light   |
| b) Fuel level   |
| <ul style="list-style-type: none"><li>• Lack of gasoline: <input type="checkbox"/> Yes / <input type="checkbox"/> No</li><li>• Indicator position of fuel gauge:</li><li>• Experienced running out of fuel: <input type="checkbox"/> Yes / <input type="checkbox"/> No</li></ul>  |
| c) Intentional connecting or disconnecting of harness connectors or spark plug cords: <input type="checkbox"/> Yes / <input type="checkbox"/> No  |
| <ul style="list-style-type: none"><li>• What:</li></ul>   |
| d) Intentional connecting or disconnecting of hoses: <input type="checkbox"/> Yes / <input type="checkbox"/> No   |
| <ul style="list-style-type: none"><li>• What:</li></ul>   |
| e) Installing of other parts except for genuine parts: <input type="checkbox"/> Yes / <input type="checkbox"/> No   |
| <ul style="list-style-type: none"><li>• What:</li><li>• Where:</li></ul>  |
| f) Occurrence of noise: <input type="checkbox"/> Yes / <input type="checkbox"/> No  |
| <ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>  |
| g) Occurrence of smell: <input type="checkbox"/> Yes / <input type="checkbox"/> No  |
| <ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>  |
| h) Intrusion of water into engine compartment or passenger compartment: <input type="checkbox"/> Yes / <input type="checkbox"/> No  |
| i) Troubles occurred  |
| <input type="checkbox"/> Engine does not start.<br><input type="checkbox"/> Engine stalls during idling.<br><input type="checkbox"/> Engine stalls while driving.<br><input type="checkbox"/> Engine speed decreases.<br><input type="checkbox"/> Engine speed does not decrease.<br><input type="checkbox"/> Rough idling<br><input type="checkbox"/> Poor acceleration<br><input type="checkbox"/> Back fire<br><input type="checkbox"/> After fire<br><input type="checkbox"/> Does not shift.<br><input type="checkbox"/> Excessive shift shock |

## 3. General Description

### A: CAUTION

1) Airbag system wiring harness is routed near the ECM, main relay and fuel pump relay.

#### CAUTION:

- All airbag system wiring harnesses and connectors are colored yellow. Do not use electrical test equipment on these circuits.
- Be careful not to damage the airbag system wiring harness when servicing the ECM, TCM, main relay and fuel pump relay.

2) Never connect the battery in reverse polarity.

- The ECM will be destroyed instantly.
- The fuel injector and other parts will be damaged.

3) Do not disconnect the battery terminals while the engine is running.

A large counter electromotive force will be generated in the generator, and this voltage may damage electronic parts such as ECM, etc.

4) Before disconnecting the connectors of each sensor and ECM, be sure to turn the ignition switch to OFF. Perform the inspection mode after connecting the connectors.

5) Poor contact has been identified as a primary cause of this problem. Measure the voltage or resistance of individual sensor or all electrical control modules using a tapered pin with a diameter of less than 0.64 mm (0.025 in). Do not insert the pin more than 5 mm (0.20 in) into the part.

6) Remove the ECM from the located position after disconnecting two cables on battery.

Otherwise, the ECM may be damaged.

#### CAUTION:


**When replacing the ECM, be careful not to use the wrong spec. ECM to avoid any damage on the fuel injection system.**

#### NOTE:

Immobilizer system must be registered when installing the ECM of the model with immobilizer. For doing so, all ignition keys and ID cards should be prepared. Refer to "REGISTRATION MANUAL FOR IMMOBILIZER".


7) Connectors of each sensor in the engine compartment and the harness connectors on the engine side and body side are all designed to be waterproof. However, it is still necessary to take care not to allow water to get into the connectors when washing the vehicle, or when servicing the vehicle on a rainy day.

8) Use ECM mounting stud bolts as the grounding point to chassis when measuring voltage and resistance inside the passenger compartment.




(A) Stud bolt

9) Use engine grounding terminal or engine as the grounding point to the chassis when measuring voltage and resistance in the engine compartment.



10) Use TCM mounting stud bolts as the grounding point to chassis when measuring voltage and resistance inside the passenger compartment.



(A) Stud bolt

11) Every MFI-related part is a precision part. Do not drop them.

12) Observe the following cautions when installing a radio in MFI equipped models.

#### CAUTION:

- The antenna must be kept as far apart as possible from the control unit. (The ECM is located under the steering column, inside of instrument panel lower trim panel.)

# General Description

## ENGINE (DIAGNOSTICS)

- The antenna feeder must be placed as far apart as possible from the ECM and MFI harness.
- Carefully adjust the antenna for correct matching.
- When mounting a large power type radio, pay special attention to the three items mentioned above.
- Incorrect installation of the radio may affect the operation of ECM.

13) Before disconnecting the fuel hose, disconnect the fuel pump connector and crank the engine for more than five seconds to release pressure in the fuel system. If engine starts during this operation, run it until it stops.

14) Problems in the electronic-controlled automatic transmission may be caused by failure of the engine, the electronic control system, the transmission proper, or by a combination of these. These three causes must be distinguished clearly when performing diagnostics.

15) Diagnostics should be conducted by rotating with simple, easy operations and proceeding to complicated, difficult operations. The most important thing in diagnostics is to understand the customer's complaint, and distinguish between the three causes.

16) For AT models, do not hold the stall for more than five seconds. (from closed throttle, fully open throttle to stall engine speed.)

17) On the model with ABS, when performing driving test in jacked-up or lifted-up position, sometimes the warning light may be lit, but this is not a malfunction of the system. The reason for this is the speed difference between the front and rear wheels. After diagnosis of engine control system, perform the ABS memory clear procedure of self-diagnosis function.

## B: INSPECTION

Before performing diagnostics, check the following items which might affect engine problems.

### 1. BATTERY

1) Measure battery voltage and specific gravity of electrolyte.


**Standard voltage: 12 V**

**Specific gravity: Above 1.260**

2) Check the condition of the main and other fuses, and harnesses and connectors. Also check for proper grounding.

### 2. ENGINE GROUND

Make sure the engine grounding terminal is properly connected to engine.



### 3. SELF-DIAGNOSIS FUNCTION

When detecting a malfunction by self-diagnosis function on ECM, malfunction indicator light illuminates and malfunction occurrence is displayed.



Calling the self-diagnosis result is performed by the Subaru Select Monitor.



# General Description

ENGINE (DIAGNOSTICS)

## C: PREPARATION TOOL

| ILLUSTRATION  | TOOL NUMBER | DESCRIPTION               | REMARKS  |
|---|-------------|---------------------------|--|
| <br>ST24082AA230 | 24082AA230  | CARTRIDGE                 | Troubleshooting for electrical system.   |
| <br>ST22771AA030 | 22771AA030  | SUBARU SELECT MONITOR KIT | Troubleshooting for electrical system. <ul style="list-style-type: none"><li>• English: 22771AA030 (Without printer)</li><li>• German: 22771AA070 (Without printer)</li><li>• French: 22771AA080 (Without printer)</li><li>• Spanish: 22771AA090 (Without printer)</li></ul> |

# Electrical Component Location


ENGINE (DIAGNOSTICS)

## 4. Electrical Component Location


### A: LOCATION

#### 1. ENGINE

- Control module
  - LHD model



- RHD model




(1) Engine control module (ECM)  
(2) Malfunction indicator light

(3) Test mode connector

(4) Data link connector

# Electrical Component Location


ENGINE (DIAGNOSTICS)



# Electrical Component Location

## ENGINE (DIAGNOSTICS)

- Sensor











EN-02530

- |   |  |   |
|---|--|---|
| (1) Mass air flow and intake air temperature sensor (EC, EK and K4 model) | (4) Electronic throttle control            | (9) Intake air temperature sensor (KA and KS model) |
| (2) Manifold absolute pressure sensor                                     | (5) Knock sensor                           |   |
| (3) Engine coolant temperature sensor                                     | (6) Camshaft position sensor               |   |
|   | (7) Crankshaft position sensor             |   |
|   | (8) Tumble generator valve position sensor |   |


# Electrical Component Location

ENGINE (DIAGNOSTICS)




# Electrical Component Location

ENGINE (DIAGNOSTICS)




SUBARU.

EN-02547




EN-01973

- (1) Front oxygen (A/F) sensor
- (2) Rear oxygen sensor
- (3) Front catalytic converter
- (4) Rear catalytic converter



EN-02091




EN-02092

# Electrical Component Location

ENGINE (DIAGNOSTICS)

- Solenoid valve, actuator, emission control system parts and ignition system parts




EN-02452


- |                                     |                                     |                   |
|-------------------------------------|-------------------------------------|-------------------|
| (1) Purge control solenoid valve    | (3) Tumble generator valve actuator | (5) Fuel injector |
| (2) EGR Valve (EC, EK and K4 model) | (4) Ignition coil & ignitor ASSY    |                   |

# Electrical Component Location


ENGINE (DIAGNOSTICS)




EN-01975




EN-01976



EN-01977



EN-01978



EN-02453


**SUBARU.**



# Electrical Component Location


ENGINE (DIAGNOSTICS)

- LHD model



EN-02423

- RHD model








EN-01979

- |                      |                                       |                               |
|----------------------|---------------------------------------|-------------------------------|
| (1) Inhibitor switch | (4) Fuel pump relay                   | (7) Radiator sub fan relay    |
| (2) Fuel pump        | (5) Electronic throttle control relay | (8) Radiator main fan relay 2 |
| (3) Main relay       | (6) Radiator main fan relay 1         | (9) Starter                   |


# Electrical Component Location

## ENGINE (DIAGNOSTICS)



## 5. Engine Control Module (ECM) I/O Signal

### A: ELECTRICAL SPECIFICATION



EN-01982

| DESCRIPTION                                    |              | Connector No. | Terminal No. | Signal (V)                          |   | NOTE                                     |
|--|--------------|---------------|--------------|-------------------------------------|---|--|
|  |              |               |              | Ignition SW ON (engine OFF)         | Engine ON (idling)                          |  |
| Crankshaft position sensor                     | Signal (+)   | B135          | 10           | 0                                   | -7 — +7                                     | Sensor output waveform                   |
|  | Signal (-)   | B135          | 22           | 0                                   | 0   | —  |
|  | Shield       | B135          | 31           | 0                                   | 0   | —  |
| Camshaft position sensor                       | Signal (+)   | B135          | 11           | 0                                   | -7 — +7                                     | Sensor output waveform                   |
|  | Signal (-)   | B135          | 23           | 0                                   | 0   | —  |
|  | Shield       | B135          | 31           | 0                                   | 0   | —  |
| Electronic throttle control                    | Main         | B136          | 18           | 0.64 — 0.72<br>Fully opens: 3.96    | 0.64 — 0.72<br>(After engine is warmed-up.) | Fully closed: 0.6<br>Fully open: 3.96    |
|  | Sub          | B136          | 29           | 1.51 — 1.58<br>Fully opens: 4.17    | 1.51 — 1.58<br>(After engine is warmed-up.) | Fully closed: 1.48<br>Fully open: 4.17   |
| Electronic throttle control motor (+)          |              | B137          | 5            | Duty waveform                       | Duty waveform                               | Drive frequency: 500 Hz                  |
| Electronic throttle control motor (-)          |              | B137          | 4            | Duty waveform                       | Duty waveform                               | Drive frequency: 500 Hz                  |
| Electronic throttle control motor power supply |              | B137          | 6            | 10 — 13                             | 13 — 14                                     | —  |
| Electronic throttle control motor relay        |              | B135          | 35           | ON: 0<br>OFF: 10 — 13               | ON: 0<br>OFF: 13 — 14                       | When ignition switch is turned to ON: ON |
| Accelerator position sensor                    | Main         | B136          | 17           | Fully closed: 1<br>Fully opens: 3.3 | Fully closed: 1<br>Fully opens: 3.3         | —  |
|  | Power supply | B136          | 15           | 5                                   | 5   | —  |
|  | Ground       | B136          | 34           | 0                                   | 0   | —  |
|  | Sub          | B136          | 28           | Fully closed: 1<br>Fully opens: 3.3 | Fully closed: 1<br>Fully opens: 3.3         | —  |
| Rear oxygen sensor                             | Signal       | B137          | 24           | 0                                   | 0 — 0.9                                     | —  |
|  | Shield       | B137          | 31           | 0                                   | 0   | —  |

## Engine Control Module (ECM) I/O Signal

### ENGINE (DIAGNOSTICS)

| DESCRIPTION                                      |          | Connector No. | Terminal No. | Signal (V)                                       |                       | NOTE  |
|--|----------|---------------|--------------|--|-----------------------|---|
|  |          |               |              | Ignition SW ON (engine OFF)                      | Engine ON (idling)    |   |
| Front oxygen (A/F) sensor heater                 | Signal 1 | B134          | 3            | 0 — 1.0  | 0 — 1.0               | —   |
|  | Signal 2 | B134          | 2            | 0 — 1.0  | 0 — 1.0               | —   |
| Rear oxygen sensor heater signal                 |          | B135          | 2            | 0 — 1.0  | 0 — 1.0               | —   |
| Engine coolant temperature sensor                |          | B136          | 14           | 1.0 — 1.4  | 1.0 — 1.4             | After engine is warmed-up.  |
| Tumble generator valve RH (open)                 |          | B134          | 19           | 0 or 10 — 13                                     | 0 or 13 — 14          | Sensor output waveform  |
| Tumble generator valve RH (close)                |          | B134          | 18           | 0 or 10 — 13                                     | 0 or 13 — 14          | Sensor output waveform  |
| Tumble generator valve LH (open)                 |          | B134          | 29           | 0 or 10 — 13                                     | 0 or 13 — 14          | Sensor output waveform  |
| Tumble generator valve LH (close)                |          | B134          | 28           | 0 or 10 — 13                                     | 0 or 13 — 14          | Sensor output waveform  |
| Tumble generator valve position sensor RH        |          | B136          | 27           | Fully open: 0.2 — 1.0<br>Fully closed: 4.2 — 4.7 |                       | —   |
| Tumble generator valve position sensor LH        |          | B136          | 26           | Fully open: 0.2 — 1.0<br>Fully closed: 4.2 — 4.7 |                       | —   |
| Starter switch                                   |          | B137          | 8            | 0  | 0                     | Cranking: 8 — 14  |
| Starter relay                                    |          | B135          | 32           | ON: 0<br>OFF: 10 — 13                            | ON: 0<br>OFF: 13 — 14 | —   |
| A/C switch (Model with immobilizer)              |          | B137          | 17           | ON: 10 — 13<br>OFF: 0                            | ON: 13 — 14<br>OFF: 0 | —   |
| A/C switch (Model without immobilizer)           |          | B137          | 16           | ON: 10 — 13<br>OFF: 0                            | ON: 13 — 14<br>OFF: 0 | —   |
| Ignition switch (Model with immobilizer)         |          | B137          | 14           | 10 — 13  | 13 — 14               | —   |
| Ignition switch (Model without immobilizer)      |          | B137          | 15           | 10 — 13  | 13 — 14               | —   |
| Neutral position switch                          |          | B137          | 9            | ON: 0<br>OFF: 12±0.5                             |                       | Switch is ON when select or shift lever is shifted into "P" or "N" range. |
| Test mode connector (Model with immobilizer)     |          | B137          | 15           | 5  | 5                     | When connected: 0   |
| Test mode connector (Model without immobilizer)  |          | B137          | 14           | 5  | 5                     | When connected: 0   |
| Knock sensor                                     | Signal   | B136          | 25           | 2.8  | 2.8                   | —   |
|  | Shield   | B136          | 33           | 0  | 0                     | —   |
| Back-up power supply                             |          | B135          | 19           | 10 — 13  | 13 — 14               | Ignition switch "OFF": 10 — 13  |
| Control module power supply                      |          | B135          | 6            | 10 — 13  | 13 — 14               | —   |
|  |          | B135          | 5            | 10 — 13  | 13 — 14               | —   |
| Sensor power supply                              | 1        | B136          | 16           | 5  | 5                     | —   |
|  | 2        | B136          | 15           | 5  | 5                     | —   |
| Ignition control                                 | 1        | B135          | 18           | 0  | 1 — 3.4               | Waveform  |
|  | 2        | B135          | 17           | 0  | 1 — 3.4               | Waveform  |
| Fuel injector                                    | #1       | B136          | 6            | 10 — 13  | 1 — 14                | Waveform  |
|  | #2       | B136          | 5            | 10 — 13  | 1 — 14                | Waveform  |
|  | #3       | B136          | 4            | 10 — 13  | 1 — 14                | Waveform  |
|  | #4       | B136          | 3            | 10 — 13  | 1 — 14                | Waveform  |
| Fuel pump relay control (Model with immobilizer) |          | B135          | 27           | ON: 0.5 or less<br>OFF: 10 — 13                  | 0.5 or less           | —   |

# Engine Control Module (ECM) I/O Signal

ENGINE (DIAGNOSTICS)

| DESCRIPTION   | Connector No. | Terminal No. | Signal (V)                      |                                 | NOTE  |   |
|---|---------------|--------------|---------------------------------|---------------------------------|---|---|
|   |               |              | Ignition SW ON (engine OFF)     | Engine ON (idling)              |   |   |
| Fuel pump relay control (Model without immobilizer) | B135          | 26           | ON: 0.5 or less<br>OFF: 10 — 13 | 0.5 or less                     | —   |   |
| A/C relay control                                   | B135          | 33           | ON: 0.5 or less<br>OFF: 10 — 13 | ON: 0.5 or less<br>OFF: 13 — 14 | —   |   |
| Radiator fan relay 1 control                        | B134          | 31           | ON: 0.5 or less<br>OFF: 10 — 13 | ON: 0.5 or less<br>OFF: 13 — 14 | —   |   |
| Radiator fan relay 2 control                        | B135          | 34           | ON: 0.5 or less<br>OFF: 10 — 13 | ON: 0.5 or less<br>OFF: 13 — 14 | —   |   |
| Self-shutoff control (Model with immobilizer)       | B137          | 16           | 10 — 13                         | 13 — 14                         | —   |   |
| Self-shutoff control (Model without immobilizer)    | B137          | 17           | 10 — 13                         | 13 — 14                         | —   |   |
| Malfunction indicator light                         | B134          | 17           | —                               | —                               | Light "ON": 1 or less<br>Light "OFF": 10 — 14 |   |
| Engine speed output                                 | B134          | 23           | —                               | 0 — 13 or more                  | Waveform                                      |   |
| Purge control solenoid valve                        | B134          | 14           | ON: 1 or less<br>OFF: 10 — 13   | ON: 1 or less<br>OFF: 13 — 14   | —   |   |
| EGR solenoid valve                                  | Signal A+     | B134         | 11                              | 0 or 10 — 13                    | 0 or 10 — 13                                  | — |
|   | Signal A-     | B134         | 10                              | 0 or 10 — 13                    | 0 or 10 — 13                                  | — |
|   | Signal B+     | B134         | 9                               | 0 or 10 — 13                    | 0 or 10 — 13                                  | — |
|   | Signal B-     | B134         | 8                               | 0 or 10 — 13                    | 0 or 10 — 13                                  | — |
| Power steering switch                               | B137          | 10           | ON: 1 or less<br>OFF: 10 — 13   | ON: 1 or less<br>OFF: 13 — 14   | —   |   |
| Blower fan switch                                   | B137          | 13           | ON: 0<br>OFF: 10 — 13           | ON: 0<br>OFF: 13 — 14           | —   |   |
| Front oxygen (A/F) sensor signal 1                  | B134          | 33           | —                               | 2.05 — 2.25                     | —   |   |
| Front oxygen (A/F) sensor signal 2                  | B134          | 26           | —                               | 1.75 — 1.95                     | —   |   |
| Front oxygen (A/F) sensor shield                    | B134          | 25           | 0                               | 0                               | —   |   |
| Manifold absolute pressure sensor                   | B136          | 22           | 4.0 — 4.8                       | 1.1 — 1.9                       | —   |   |
| Air flow sensor                                     | Signal        | B136         | 23                              | —                               | 0.3 — 4.5                                     | — |
|   | Shield        | B136         | 32                              | 0                               | 0   | — |
|   | Ground        | B136         | 31                              | 0                               | 0   | — |
| Intake air temperature sensor                       | B136          | 13           | 3.15 — 3.33                     | 3.15 — 3.33                     | intake air temperature:<br>25°C (75°F)        |   |
| Generator control                                   | B134          | 22           | 0 — 6.5                         | 0 — 6.5                         | —   |   |
| SSM communication line                              | B137          | 20           | Less than 1 ← → More than 4     | Less than 1 ← → More than 4     | —   |   |
| GND (sensor)  | 1             | B136         | 35                              | 0                               | 0   | — |
|   | 2             | B136         | 34                              | 0                               | 0   | — |
| GND (injector)                                      | B137          | 7            | 0                               | 0                               | —   |   |
| GND (ignition system)                               | B135          | 12           | 0                               | 0                               | —   |   |
| GND (power supply)                                  | B135          | 4            | 0                               | 0                               | —   |   |
|   | B135          | 1            | 0                               | 0                               | —   |   |
| GND (control system)                                | B137          | 2            | 0                               | 0                               | —   |   |
|   | B137          | 1            | 0                               | 0                               | —   |   |
| GND (oxygen sensor heater 1)                        | B134          | 7            | 0                               | 0                               | —   |   |

## Engine Control Module (ECM) I/O Signal

### ENGINE (DIAGNOSTICS)

| DESCRIPTION                       | Connector No. | Terminal No. | Signal (V)  |   | NOTE |
|-----------------------------------|---------------|--------------|---|---|------|
|                                   |               |              | Ignition SW ON (engine OFF)   | Engine ON (idling)  |      |
| GND (oxygen sensor heater 2)      | B134          | 6            | 0   | 0   | —    |
| GND (Electronic throttle control) | B137          | 3            | 0   | 0   | —    |
| Main switch                       | B137          | 14           | ON: 0<br>OFF: 10 — 13   | ON: 0<br>OFF: 13 — 14   | —    |
| Clutch switch                     | B137          | 22           | When clutch pedal is depressed: 0<br>When clutch pedal is released: 10 — 13   | When clutch pedal is depressed: 0<br>When clutch pedal is released: 13 — 14   | —    |
| Brake switch 1                    | B137          | 12           | When brake pedal is depressed: 0<br>When brake pedal is released: 10 — 13   | When brake pedal is depressed: 0<br>When brake pedal is released: 13 — 14   | —    |
| Brake switch 2                    | B137          | 13           | When brake pedal is depressed: 10 — 13<br>When brake pedal is released: 0   | When brake pedal is depressed: 13 — 14<br>When brake pedal is released: 0   | —    |
| Cruise control command switch     | B136          | 21           | When operating nothing: 3.5 — 4.5<br>When operating RES/ACC: 2.5 — 3.5<br>When operating SET/COAST: 0.5 — 1.5<br>When operating CANCEL: 0 — 0.5 | When operating nothing: 3.5 — 4.5<br>When operating RES/ACC: 2.5 — 3.5<br>When operating SET/COAST: 0.5 — 1.5<br>When operating CANCEL: 0 — 0.5 | —    |

## 6. Engine Condition Data

### A: ELECTRICAL SPECIFICATION

| Remarks     | SPECIFICATION                    |
|-------------|----------------------------------|
| Engine load | 1.6 — 2.9 (%): Idling            |
|             | 6.4 — 12.8 (%): 2,500 rpm Racing |

Measuring condition:

- After engine is warmed-up.
- Gear position is in "N" or "P" range.
- A/C is turned OFF.
- All accessory switches are turned OFF.

# Data Link Connector

ENGINE (DIAGNOSTICS)


## 7. Data Link Connector

### A: NOTE

This connector is used for Subaru Select Monitor.

### CAUTION:

Do not connect any scan tools except for Subaru Select Monitor or OBD-II general scan tool, because the circuit for Subaru Select Monitor may be damaged.



| Terminal No. | Remarks      | Terminal No. | Remarks                      |
|--------------|--------------|--------------|------------------------------|
| 1            | Power supply | 9            | Empty                        |
| 2            | Empty        | 10           | Subaru Select Monitor signal |
| 3            | Empty        | 11           | Empty                        |
| 4            | Empty        | 12           | Ground                       |
| 5            | Empty        | 13           | Ground                       |
| 6            | Empty        | 14           | Empty                        |
| 7            | Empty        | 15           | Empty                        |
| 8            | Empty        | 16           | Empty                        |




## 8. OBD-II General Scan Tool

### A: OPERATION

#### 1. HOW TO USE OBD-II GENERAL SCAN TOOL

- 1) Prepare a general scan tool (OBD-II general scan tool) required by SAE J1978.
- 2) Open the cover and connect the OBD-II general scan tool to data link connector located in the lower portion of instrument panel (on the driver's side).



- 3) Using the OBD-II general scan tool, call up DTC and freeze frame data.

#### 2. MODE \$01 (CURRENT POWERTRAIN DIAGNOSTIC DATA)

Refer to data denoting the current operating condition of analog input/output, digital input/output and/or the powertrain system.

A list of the support data and PID (Parameter Identification) codes are shown in the following table.

| PID | Data   | Unit of measure |
|-----|--|-----------------|
| 01  | Number of emission-related powertrain DTC and malfunction indicator light status and diagnosis support information | —               |
| 03  | Fuel system control status   | —               |
| 04  | Calculated engine load value   | %               |
| 05  | Engine coolant temperature   | °C              |
| 06  | Short term fuel trim   | %               |
| 07  | Long term fuel trim  | %               |
| 0B  | Intake manifold absolute pressure  | kPa             |
| 0C  | Engine revolution  | rpm             |
| 0D  | Vehicle speed  | km/h            |
| 0E  | Ignition timing advance  | °               |
| 0F  | Intake air temperature   | °C              |
| 10  | Air flow rate from mass air flow sensor  | g/sec           |
| 11  | Throttle valve absolute opening angle  | %               |
| 13  | Check whether oxygen sensor is installed.  | —               |
| 15  | Oxygen sensor output voltage and short term fuel trim associated with oxygen sensor                                | V and %         |
| 1C  | Supporting OBD system  | —               |
| 21  | Driving distance after MIL illuminates   | km              |
| 24  | A/F value and A/F sensor output voltage  | — and V         |

**NOTE:**

Refer to OBD-II general scan tool manufacturer's instruction manual to access generic OBD-II PIDs (MODE \$01).

OBD-II general scan tool functions consist of:

- (1) MODE \$01: Current powertrain diagnostic data
- (2) MODE \$02: Powertrain freeze frame data
- (3) MODE \$03: Emission-related powertrain DTC
- (4) MODE \$04: Clear/Reset emission-related diagnostic information
- (5) MODE \$06: Request on-board monitoring test results for non-continuously monitored systems
- (6) MODE \$07: Request on-board monitoring test results for continuously monitored systems
- (7) MODE \$09: Request vehicle information

Read out the data according to repair procedures. (For detailed operation procedures, refer to the operation manual of OBD-II general scan tool.)

**NOTE:**

For details concerning DTC, refer to "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4SO 2.5)(diag)-70, List of Diagnostic Trouble Code (DTC).>

# OBD-II General Scan Tool

## ENGINE (DIAGNOSTICS)

### 3. MODE \$02 (POWERTRAIN FREEZE FRAME DATA)

Refer to data denoting the operating condition when trouble is detected by the on-board diagnosis system. A list of the support data and PID (Parameter Identification) codes are shown in the following table.

| PID | Data  | Unit of measure |
|-----|---|-----------------|
| 02  | DTC that caused CARB required freeze frame data storage | —               |
| 03  | Fuel system control status                              | —               |
| 04  | Calculated engine load value                            | %               |
| 05  | Engine coolant temperature                              | °C              |
| 06  | Short term fuel trim                                    | %               |
| 07  | Long term fuel trim                                     | %               |
| 0B  | Intake manifold absolute pressure                       | kPa             |
| 0C  | Engine speed  | rpm             |
| 0D  | Vehicle speed   | km/h            |
| 0E  | Ignition timing advance                                 | °               |
| 0F  | Intake air temperature                                  | °C              |
| 10  | Air flow rate from mass air flow sensor                 | g/sec           |
| 11  | Throttle valve opening angle                            | %               |

**NOTE:**

Refer to OBD-II general scan tool manufacturer's operation manual to access freeze frame data (MODE \$02).

### 4. MODE \$03 (EMISSION-RELATED POWERTRAIN DIAGNOSTIC TROUBLE CODE (DTC))

Refer to "Read Diagnostic Trouble Code (DTC)" for information about data denoting emission-related powertrain DTC. <Ref. to EN(H4SO 2.5)(diag)-33, Read Diagnostic Trouble Code (DTC).>

### 5. MODE \$04 (CLEAR/RESET EMISSION-RELATED DIAGNOSTIC INFORMATION)

Refer to the mode used to clear or reset emission-related diagnostic information (OBD-II trouble diagnostic information).

**NOTE:**

Refer to OBD-II general scan tool manufacturer's operation manual to clear or reset emission-related diagnostic information (MODE \$04).

### 6. MODE \$06

Refer to test value of troubleshooting and data of test limit on support data bit sequence table. List of support data is shown in the following table.

| TID  | CID  | Test value & Test limit  | Unit        |
|------|------|--|-------------|
| \$01 | \$01 | Catalyst system efficiency below threshold   | —           |
| \$02 | \$81 | Exhaust gas recirculation control circuit range/performance                        | mmHg        |
|      | \$02 |  |             |
| \$03 | \$81 | Evaporative emission control system (CPC open malfunction)                         | —           |
|      | \$02 | Evaporative emission control system small leak                                     | pa          |
|      | \$03 | Evaporative emission control system small leak (Immediate normality judgment)      | pa          |
|      | \$04 | Evaporative emission control system large leak                                     | pa          |
|      | \$05 | Evaporative emission control system very small leak (Immediate normality judgment) | pa          |
|      | \$06 | Evaporative emission control system very small leak                                | pa          |
| \$05 | \$01 | O <sub>2</sub> sensor circuit slow response (Bank 1 Sensor 1) Lean → Rich          | millisecond |
|      | \$02 | O <sub>2</sub> sensor circuit slow response (Bank 1 Sensor 1) Rich → Lean          |             |
| \$06 | \$81 | O <sub>2</sub> sensor circuit (Bank 1 Sensor 2) <\$81 or \$02>                     | V           |
|      | \$02 |  |             |
| \$07 | \$01 | O <sub>2</sub> sensor circuit slow response (Bank 1 Sensor 2)                      | second      |

# OBD-II General Scan Tool

ENGINE (DIAGNOSTICS)

| TID  | CID  | Test value & Test limit  | Unit |
|------|------|--|------|
| \$0B | \$81 | O <sub>2</sub> sensor heater circuit (Bank 1 Sensor 2) <\$81 or \$02>            | W    |
|      | \$02 |  |      |
| \$0C | \$01 | Coolant thermostat (Coolant temperature below thermostat regulating temperature) | °C   |
| \$0D | \$01 | Evaporative emission control system vent control circuit range/performance       | Pa   |
|      | \$82 |  |      |

## 7. MODE \$07

Refer to the data of DTC (pending code) for troubleshooting result about emission in first time.

## 8. MODE \$09

Refer to the data of vehicle specification (VIN, calibration ID, etc.).

# Subaru Select Monitor


ENGINE (DIAGNOSTICS)

## 9. Subaru Select Monitor

### A: OPERATION


#### 1. HOW TO USE SUBARU SELECT MONITOR

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4SO 2.5)(diag)-7, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.

3) Insert the cartridge to Subaru Select Monitor. <Ref. to EN(H4SO 2.5)(diag)-7, PREPARATION TOOL, General Description.>




4) Connect the Subaru Select Monitor to data link connector.

(1) Data link connector is located in the lower portion of instrument panel (on the driver's side).



(2) Connect the diagnosis cable to data link connector.

5) Turn ignition switch to ON (engine OFF) and turn Subaru Select Monitor switch to ON.



(A) Power switch

6) Using the Subaru Select Monitor, call up DTC and data, then record them.

#### 2. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE (NORMAL MODE)

Refer to "Read Diagnostic Trouble Code (DTC)" for information about how to indicate DTCs. <Ref. to EN(H4SO 2.5)(diag)-33, Read Diagnostic Trouble Code (DTC).>

#### 3. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE (OBD MODE)

Refer to "Read Diagnostic Trouble Code (DTC)" for information about how to indicate DTCs. <Ref. to EN(H4SO 2.5)(diag)-33, Read Diagnostic Trouble Code (DTC).>

### CAUTION:

Do not connect the scan tools except for Subaru Select Monitor or OBD-II general scan tool.

**4. READ CURRENT DATA FOR ENGINE. (NORMAL MODE)**

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
  - 3) Press the [YES] key after the information of engine type has been displayed.
  - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display/Save}, and then press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
  - 6) Using the scroll key, scroll the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

| Remarks                           | Display                  | Unit of measure | Note (at idling)                                     |
|-----------------------------------|--------------------------|-----------------|--|
| Engine load                       | Engine Load              | %               | 3.5%   |
| Engine coolant temperature signal | Coolant Temp.            | °C              | ≥ 75 °C  |
| A/F correction 1                  | A/F Correction #1        | %               | -10 — +10%   |
| A/F learning 1                    | A/F Learning #1          | %               | -15 — +15%   |
| Intake manifold absolute pressure | Mani. Absolute Pressure  | mmHg            | 200 — 300 mmHg                                       |
| Engine speed signal               | Engine Speed             | rpm             | 600 — 800 rpm (Agree with the tachometer indication) |
| Vehicle speed signal              | Vehicle Speed            | km/h            | 0 km/h (at parking)                                  |
| Ignition timing signal            | Ignition Timing          | deg             | 12.5 — 13.5 deg                                      |
| Intake air temperature signal     | Intake Air Temp.         | °C              | (Ambient air temperature)                            |
| Amount of intake air              | Mass Air Flow            | g/s             | 2.8 — 3.2 g/s  |
| Throttle opening angle signal     | Throttle Opening Angle   | %               | 1.2 — 1.6%   |
| Rear oxygen sensor voltage        | Rear O2 Sensor           | V               | 0.6 — 0.85 V   |
| Battery voltage                   | Battery Voltage          | V               | 12 — 14 V  |
| Mass air flow voltage             | Air Flow Sensor Voltage  | V               | 1.1 — 1.2 V  |
| Injection 1 pulse width           | Fuel Injection #1 Pulse  | ms              | 2.56 — 3.3 ms  |
| Knock sensor correction           | Knocking Correction      | deg             | 0.0 deg  |
| Atmospheric pressure signal       | Atmosphere Pressure      | mmHg            | (Atmosphere pressure)                                |
| Intake manifold relative pressure | Mani. Relative Pressure  | mmHg            | (Mani. Absolute Pressure – Atmosphere pressure)      |
| Acceleration opening angle signal | Accel. Opening Angle     | %               | 0.0%   |
| Purge control solenoid duty ratio | CPC Valve Duty Ratio     | %               | 0 — 3%   |
| EGR steps                         | No. of EGR Steps         | STEP            | 0  |
| Generator duty ratio              | ALT Duty                 | %               | 0%   |
| A/F sensor current value 1        | A/F Sensor #1 Current    | mA              | -0.2 — 0.2 mA  |
| A/F sensor resistance value 1     | A/F Sensor #1 Resistance | ohm             | 28 — 31 mA   |
| A/F sensor output lambda 1        | A/F Sensor #1            | —               | 0.85 — 1.05  |
| A/F correction 3                  | A/F Correction #3        | %               | 5.08%  |
| A/F learning 3                    | A/F Learning #3          | %               | 0%   |
| Throttle motor duty               | Throttle Motor Duty      | %               | -12 — -20%   |
| Throttle power supply voltage     | Throttle Motor Voltage   | V               | (Battery voltage)                                    |
| Sub throttle sensor voltage       | Sub-throttle Sensor      | V               | 1.48 — 1.50 V  |
| Main throttle sensor voltage      | Main-throttle Sensor     | V               | 0.62 V   |
| Sub acceleration sensor voltage   | Sub-accelerator Sensor   | V               | 1.12 V   |
| Main acceleration sensor voltage  | Main-accelerator Sensor  | V               | 0.98 — 1.0 V   |
| Memory vehicle speed              | Memorized Cruise Speed   | km/h            | 0 km/h   |
| AT/MT identification terminal     | AT Vehicle ID Signal     | —               | ON/OFF   |
| TGV position sensor voltage RH    | TGV Position Sensor R    | V               | 0 — 12   |
| TGV position sensor voltage LH    | TGV Position Sensor L    | V               | 0 — 12   |

## Subaru Select Monitor

### ENGINE (DIAGNOSTICS)

| Remarks  | Display                  | Unit of measure | Note (at idling) |
|--|--------------------------|-----------------|------------------|
| Fuel level sensor resistance                   | Fuel Level Resistance    | Ω               | 4 — 100 Ω        |
| Test mode terminal                             | Test Mode Signal         | —               | OFF              |
| Neutral position switch signal                 | Neutral Position Switch  | —               | ON               |
| Soft idle switch signal                        | Idle Switch Signal       | —               | ON               |
| Ignition switch signal                         | Ignition Switch          | —               | ON               |
| Power steering switch input signal             | P/S Switch               | —               | OFF (At OFF)     |
| Air conditioning switch signal                 | A/C Switch               | —               | OFF (At OFF)     |
| Handle switch signal                           | Handle Switch            | —               | RHD/LHD          |
| Starter switch signal                          | Starter Switch           | —               | OFF              |
| Rear O <sub>2</sub> monitor                    | Rear O2 Rich Signal      | —               | OFF              |
| Knocking signal                                | Knocking Signal          | —               | OFF              |
| Crankshaft position sensor signal              | Crankshaft Position Sig. | —               | OFF              |
| Camshaft position sensor signal                | Camshaft Position Sig.   | —               | OFF              |
| Rear defogger switch signal                    | Rear Defogger SW         | —               | OFF (At OFF)     |
| Blower fan switch signal                       | Blower Fan SW            | —               | OFF (At OFF)     |
| Light switch signal                            | Light Switch             | —               | OFF (At OFF)     |
| Wiper switch signal                            | Wiper Switch             | —               | OFF (At OFF)     |
| A/C middle pressure switch signal              | A/C Mid Pressure Switch  | —               | OFF (At OFF)     |
| Air conditioner compressor relay output signal | A/C Compressor Signal    | —               | OFF (At OFF)     |
| Radiator fan relay 1 signal                    | Radiator Fan Relay #1    | —               | OFF (At OFF)     |
| Radiator fan relay 2 signal                    | Radiator Fan Relay #2    | —               | OFF (At OFF)     |
| Fuel pump relay signal                         | Fuel Pump Relay          | —               | ON               |
| Tumble generator valve output signal           | TGV Output               | —               | OFF              |
| Tumble generated valve drive signal            | TGV Drive                | —               | Open             |
| AT coordinate retard angle demand signal       | Retard Signal from AT    | —               | OFF              |
| AT coordinate fuel cut demand signal           | Fuel Cut Signal from AT  | —               | OFF              |
| AT coordinate permission demand                | Torque Permission Signal | —               | ON               |
| ETC motor relay signal                         | ETC Motor Relay          | —               | ON               |
| Ban of torque down signal                      | Ban of Torque Down       | —               | ON/OFF           |
| Request torque down signal                     | Request Torque Down      | —               | ON/OFF           |
| Clutch switch signal                           | Clutch Switch            | —               | OFF (At OFF)     |
| Stop light switch signal                       | Stop Light Switch        | —               | OFF (At OFF)     |
| SET/COAST switch signal                        | SET/COAST Switch         | —               | OFF (At OFF)     |
| RES/ACC switch signal                          | RESUME/ACCEL Switch      | —               | OFF (At OFF)     |
| Brake switch signal                            | Brake Switch             | —               | OFF (At OFF)     |
| Main switch signal                             | Main Switch              | —               | OFF (At OFF)     |
| Cancel switch signal                           | Cancel Switch            | —               | OFF (At OFF)     |
| Integrated unit data reception                 | Body Int. Unit Data      | —               | ON               |
| Integrated unit data update                    | Body Int. Unit Count     | —               | ON               |

**NOTE:**

For detailed operation procedure, refer to the “SUBARU SELECT MONITOR OPERATION MANUAL”.

## 5. READ CURRENT DATA FOR ENGINE (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
  - 3) Press the [YES] key after the information of engine type has been displayed.
  - 4) On the «Engine Diagnosis» display screen, select the {OBD system} and press the [YES] key.
  - 5) On the «OBD Menu» display screen, select the {Current Data Display/Save}, and press the [YES] key.
  - 6) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
  - 7) Using the scroll key, scroll the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

| DESCRIPTION                                       | Display                  | Unit of measure |
|---|--------------------------|-----------------|
| Number of diagnosis code                          | Number of Diag. Code:    | 0               |
| Condition of malfunction indicator light          | MI (MIL)                 | OFF             |
| Monitoring test of misfire                        | Misfire monitoring       | no support      |
| Monitoring test of fuel system                    | Fuel system monitoring   | complete        |
| Monitoring test of comprehensive component        | Component monitoring     | complete        |
| Test of catalyst                                  | Catalyst Diagnosis       | no support      |
| Test of heating-type catalyst                     | Heated catalyst          | no support      |
| Test of evaporative emission purge control system | Evaporative purge system | no support      |
| Test of secondary air system                      | Secondary air system     | no support      |
| Test of air conditioning system refrigerant       | A/C system refrigerant   | no support      |
| Test of oxygen sensor                             | Oxygen sensor            | complete        |
| Test of oxygen sensor heater                      | O2 Heater Diagnosis      | complete        |
| Test of EGR system                                | EGR system               | incomplete      |

**NOTE:**

For detailed operation procedure, refer to “SUBARU SELECT MONITOR OPERATION MANUAL”.

# Subaru Select Monitor

## ENGINE (DIAGNOSTICS)

### 6. READ FREEZE FRAME DATA FOR ENGINE (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
  - 3) Press the [YES] key after the information of engine type has been displayed.
  - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
  - 5) On the «OBD Menu» display screen, select the {Freeze Frame Data} and press the [YES] key.
- A list of support data is shown in the following table.

| Contents  | Display                 | Unit of measure        |
|---|-------------------------|------------------------|
| DTC for freeze frame data                         | Freeze frame data       | DTC                    |
| Air fuel ratio control system for bank 1          | Fuel system for Bank1   | ON or OFF              |
| Engine load data                                  | Engine Load             | %                      |
| Engine coolant temperature signal                 | Coolant Temp.           | °C or °F               |
| Short term fuel trim by front oxygen (A/F) sensor | Short term fuel trim B1 | %                      |
| Long term fuel trim by front oxygen (A/F) sensor  | Long term fuel trim B1  | %                      |
| Intake manifold absolute pressure signal          | Mani. Absolute Pressure | mmHg, kPa, inHg or psi |
| Engine speed signal                               | Engine Speed            | rpm                    |
| Vehicle speed signal                              | Vehicle Speed           | km/h or MPH            |
| Ignition timing signal                            | Ignition Timing         | °                      |
| Intake air volume                                 | Mass Air Flow           | g/sec                  |
| Intake air temperature signal                     | Intake Air Temp         | °C                     |
| Throttle position signal                          | Throttle Opening Angle  | %                      |

#### NOTE:

For detailed operation procedure, refer to SUBARU SELECT MONITOR OPERATION MANUAL.



## 7. LED OPERATION MODE FOR ENGINE

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
  - 3) Press the [YES] key after the information of engine type has been displayed.
  - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display/Save}, and then press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data & LED Display} and press the [YES] key.
  - 6) Using the scroll key, scroll the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

| Remarks                              | Display                    | Message    | LED "ON" requirements                            |
|--------------------------------------|----------------------------|------------|--|
| AT/MT identification signal          | AT Vehicle ID Signal       | ON or OFF  | Illuminate (AT model)                            |
| Test mode signal                     | Test Mode Signal           | ON or OFF  | D check  |
| Clear memory signal                  | Clear Memory Terminal      | ON or OFF  | When clear memory connector is connected.        |
| Neutral position switch signal       | Neutral Position Switch    | ON or OFF  | When neutral position signal is entered.         |
| Idle switch signal                   | Idle Switch Signal         | ON or OFF  | When idle switch signal is entered.              |
| Ignition switch signal               | Ignition Switch            | ON or OFF  | When ignition switch is turned to ON.            |
| Power steering switch signal         | P/S Switch                 | ON or OFF  | When power steering switch is entered.           |
| Air conditioning switch signal       | A/C Switch                 | ON or OFF  | When air conditioning switch is input.           |
| Handle switch signal                 | Handle SW                  | RHD or LHD | When handle switch signal is input.              |
| Starter switch signal                | Starter Switch             | ON or OFF  | When starter switch is input.                    |
| Rear oxygen sensor rich signal       | Rear O2 Rich Signal        | ON or OFF  | When rear oxygen sensor mixture ratio is rich.   |
| Knocking signal                      | Knocking Signal            | ON or OFF  | When knocking signal is input.                   |
| Crankshaft position sensor signal    | Crankshaft Position Signal | ON or OFF  | When crankshaft position sensor signal is input. |
| Camshaft position sensor signal      | Camshaft Position Signal   | ON or OFF  | When camshaft position sensor signal is entered. |
| Rear defogger switch signal          | Rear Defogger Switch       | ON or OFF  | When rear defogger switch is turned to ON.       |
| Blower fan switch signal             | Blower Fan Switch          | ON or OFF  | When blower fan switch is turned to ON.          |
| Light switch signal                  | Light Switch               | ON or OFF  | When light switch is turned to ON.               |
| Small light switch signal            | Light Switch               | ON or OFF  | When small light switch is turned to ON.         |
| Windshield wiper switch signal       | Wiper SW                   | ON or OFF  | When windshield wiper switch is turned to ON.    |
| A/C middle pressure switch signal    | A/C Mid Pressure Switch    | ON or OFF  | When A/C middle pressure switch is turned to ON. |
| Air conditioning relay signal        | A/C Compressor Signal      | ON or OFF  | When air conditioning relay is in function.      |
| Radiator fan relay 1 signal          | Radiator Fan Relay #1      | ON or OFF  | When radiator fan relay 1 is in function.        |
| Radiator fan relay 2 signal          | Radiator Fan Relay #2      | ON or OFF  | When radiator fan relay 2 is in function.        |
| Fuel pump relay signal               | Fuel Pump Relay            | ON or OFF  | ON output  |
| Tumble generator valve output signal | TGV Output                 | ON or OFF  | Yes  |

## Subaru Select Monitor

### ENGINE (DIAGNOSTICS)

| Remarks  | Display                   | Message       | LED "ON" requirements  |
|--|---------------------------|---------------|--|
| Tumble generated valve drive signal            | TGV Drive                 | Open or Close | Opening direction  |
| AT retard angle demand signal                  | Retard Signal             | ON or OFF     | When AT retard angle demand signal is input.                 |
| AT fuel cut signal                             | Fuel Cut                  | ON or OFF     | When AT fuel cut signal is input.                            |
| AT coordinate permission signal                | Torque Control Permission | ON or OFF     | When AT coordinate permission signal is input.               |
| Clutch switch signal                           | Clutch Switch             | ON or OFF     | When clutch switch is turned to ON.                          |
| Stop light switch signal                       | Stop Light Switch         | ON or OFF     | When stop switch is turned to ON.                            |
| SET/COAST switch signal                        | SET/COAST Switch          | ON or OFF     | When SET/COAST switch is turned to ON.                       |
| RES/ACC switch signal                          | RESUME/ACCEL Switch       | ON or OFF     | When RES/ACC switch is turned to ON.                         |
| Brake switch signal                            | Brake Switch              | ON or OFF     | When brake switch is turned to ON.                           |
| Main switch signal                             | Main Switch               | ON or OFF     | When main switch is turned to ON.                            |
| Cancel switch signal                           | Cancel Switch             | ON or OFF     | When cancel switch is turned to ON.                          |
| Electronic throttle control motor relay signal | ETC Motor Relay           | ON or OFF     | When electronic throttle control motor relay is in function. |
| Data reception signal                          | Body Int. Unit Data       | ON or OFF     | When data reception signal is entered.                       |
| Counter update signal                          | Body Int. Unit Count      | ON or OFF     | When counter update signal is entered.                       |

**NOTE:**

For detailed operation procedure, refer to "SUBARU SELECT MONITOR OPERATION MANUAL".

## 10. Read Diagnostic Trouble Code (DTC)

### A: OPERATION

#### 1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type has been displayed.
- 4) On the «Engine Diagnosis» screen, select the {DTC Display}, and then press the [YES] key.
- 5) On the «Diagnostic Code(s) Display» screen, select the {Current Diagnostic Code(s)} or {History Diagnostic Code(s)}, and then press the [YES] key.

#### NOTE:

- For detailed operation procedure, refer to “SUBARU SELECT MONITOR OPERATION MANUAL”.
- For details concerning DTC, refer to “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(H4SO 2.5)(diag)-70, List of Diagnostic Trouble Code (DTC).>

#### 2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type has been displayed.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {DTC Display} and press the [YES] key.
- 6) Make sure DTC is shown on the screen.

#### NOTE:

- For detailed operation procedure, refer to “SUBARU SELECT MONITOR OPERATION MANUAL”.
- For details concerning DTC, refer to “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(H4SO 2.5)(diag)-70, List of Diagnostic Trouble Code (DTC).>

## Inspection Mode

ENGINE (DIAGNOSTICS)

### 11. Inspection Mode

#### A: PROCEDURE

Carry out trouble diagnosis shown in the following DTC table.

When performing trouble diagnosis which is not shown in the DTC table, refer to the next item Drive cycle.

<Ref. to EN(H4SO 2.5)(diag)-39, Drive Cycle.>

| DTC   | Item   | Condition |
|-------|--|-----------|
| P0031 | HO2S Heater Control Circuit Low (Bank 1 Sensor 1)                    | —         |
| P0032 | HO2S Heater Control Circuit High (Bank 1 Sensor 1)                   | —         |
| P0037 | HO2S Heater Control Circuit Low (Bank 1 Sensor 2)                    | —         |
| P0038 | HO2S Heater Control Circuit High (Bank 1 Sensor 2)                   | —         |
| P0102 | Mass or Volume Air Flow Circuit Low Input                            | —         |
| P0103 | Mass or Volume Air Flow Circuit High Input                           | —         |
| P0107 | Manifold Absolute Pressure/Barometric Pressure Circuit Low Input     | —         |
| P0108 | Manifold Absolute Pressure/Barometric Pressure Circuit High Input    | —         |
| P0112 | Intake Air Temperature Circuit Low Input                             | —         |
| P0113 | Intake Air Temperature Circuit High Input                            | —         |
| P0117 | Engine Coolant Temperature Circuit Low Input                         | —         |
| P0118 | Engine Coolant Temperature Circuit High Input                        | —         |
| P0122 | Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input          | —         |
| P0123 | Throttle/Pedal Position Sensor/Switch "A" Circuit High Input         | —         |
| P0131 | O <sub>2</sub> Sensor Circuit Low Voltage (Bank 1 Sensor 1)          | —         |
| P0132 | O <sub>2</sub> Sensor Circuit High Voltage (Bank 1 Sensor 1)         | —         |
| P0134 | O <sub>2</sub> Sensor Circuit No Activity Detected (Bank 1 Sensor 1) | —         |
| P0137 | O <sub>2</sub> Sensor Circuit Low Voltage (Bank 1 Sensor 2)          | —         |
| P0138 | O <sub>2</sub> Sensor Circuit High Voltage (Bank 1 Sensor 2)         | —         |
| P0171 | System too Lean (Bank 1)   | —         |
| P0172 | System too Rich (Bank 1)   | —         |
| P0222 | Throttle/Pedal Position Sensor/Switch "B" Circuit Low Input          | —         |
| P0223 | Throttle/Pedal Position Sensor/Switch "B" Circuit High Input         | —         |
| P0327 | Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)           | —         |
| P0328 | Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)          | —         |
| P0335 | Crankshaft Position Sensor "A" Circuit                               | —         |
| P0340 | Camshaft Position Sensor "A" Circuit (Bank 1 or Single Sensor)       | —         |
| P0400 | Exhaust Gas Recirculation Flow                                       | —         |
| P0458 | Evaporative Emission Control System Purge Control Valve Circuit Low  | —         |
| P0462 | Fuel Level Sensor Circuit Low Input                                  | —         |
| P0463 | Fuel Level Sensor Circuit High Input                                 | —         |
| P0500 | Vehicle Speed Sensor   | —         |
| P0512 | Starter Request Circuit  | —         |
| P0513 | Incorrect Immobilizer Key  | —         |
| P0519 | Idle Control System Malfunction (Fail-Safe)                          | —         |
| P0558 | Generator Circuit Low Input  | —         |
| P0600 | Serial Communication Link  | —         |
| P0604 | Internal Control Module Random Access Memory (RAM) Error             | —         |
| P0605 | Internal Control Module Read Only Memory (ROM) Error                 | —         |
| P0607 | Control Module Performance   | —         |
| P0638 | Throttle Actuator Control Range/Performance (Bank 1)                 | —         |
| P0691 | Cooling Fan 1 Control Circuit Low                                    | —         |
| P0692 | Cooling Fan 1 Control Circuit High                                   | —         |
| P0851 | Neutral Switch Input Circuit Low                                     | —         |

# Inspection Mode

ENGINE (DIAGNOSTICS)

| DTC   | Item   | Condition  |
|-------|--|--|
| P0852 | Neutral Switch Input Circuit High                                      | —  |
| P1086 | Tumble Generated Valve Position Sensor 2 Circuit Low                   | —  |
| P1087 | Tumble Generated Valve Position Sensor 2 Circuit High                  | —  |
| P1088 | Tumble Generated Valve Position Sensor 1 Circuit Low                   | —  |
| P1089 | Tumble Generated Valve Position Sensor 1 Circuit High                  | —  |
| P1090 | Tumble Generated Valve System 1 (Valve Open)                           | Engine coolant temperature is $-5 \text{ — } 5^{\circ}\text{C}$ ( $-41 \text{ — } 41^{\circ}\text{F}$ ) at engine start. |
| P1091 | Tumble Generated Valve System 1 (Valve Close)                          | —  |
| P1092 | Tumble Generated Valve System 2 (Valve Open)                           | Engine coolant temperature is $-5 \text{ — } 5^{\circ}\text{C}$ ( $-41 \text{ — } 41^{\circ}\text{F}$ ) at engine start. |
| P1093 | Tumble Generated Valve System 2 (Valve Close)                          | —  |
| P1094 | Tumble Generated Valve Signal 1 Circuit Malfunction (Open)             | —  |
| P1095 | Tumble Generated Valve Signal 1 Circuit Malfunction (Short)            | —  |
| P1096 | Tumble Generated Valve Signal 2 Circuit Malfunction (Open)             | —  |
| P1097 | Tumble Generated Valve Signal 2 Circuit Malfunction (Short)            | —  |
| P1110 | Atmospheric Pressure sensor circuit malfunction (Low input)            | —  |
| P1111 | Atmospheric Pressure sensor circuit malfunction (High input)           | —  |
| P1152 | O <sub>2</sub> Sensor Circuit Range/Performance (Low) (Bank1 Sensor1)  | —  |
| P1153 | O <sub>2</sub> Sensor Circuit Range/Performance (High) (Bank1 Sensor1) | —  |
| P1160 | Return Spring Failure  | —  |
| P1492 | EGR Solenoid Valve Signal #1 Circuit Malfunction (Low Input)           | —  |
| P1493 | EGR Solenoid Valve Signal #1 Circuit Malfunction (High Input)          | —  |
| P1494 | EGR Solenoid Valve Signal #2 Circuit Malfunction (Low Input)           | —  |
| P1495 | EGR Solenoid Valve Signal #2 Circuit Malfunction (High Input)          | —  |
| P1496 | EGR Solenoid Valve Signal #3 Circuit Malfunction (Low Input)           | —  |
| P1497 | EGR Solenoid Valve Signal #3 Circuit Malfunction (High Input)          | —  |
| P1498 | EGR Solenoid Valve Signal #4 Circuit Malfunction (Low Input)           | —  |
| P1499 | EGR Solenoid Valve Signal #4 Circuit Malfunction (High Input)          | —  |
| P1518 | Starter Switch Circuit Low Input                                       | —  |
| P1560 | Back-up Voltage Circuit Malfunction                                    | —  |
| P1570 | Antenna  | —  |
| P1571 | Reference Code Incompatibility   | —  |
| P1572 | IMM Circuit Failure (Except Antenna Circuit)                           | —  |
| P1574 | Key Communication Failure  | —  |
| P1576 | EGI Control Module EEPROM  | —  |
| P1577 | IMM Control Module EEPROM  | —  |
| P1578 | Meter Failure  | —  |
| P2101 | Throttle Actuator Control Motor Circuit Range/Performance              | —  |
| P2102 | Throttle Actuator Control Motor Circuit Low                            | —  |
| P2103 | Throttle Actuator Control Motor Circuit High                           | —  |
| P2109 | Throttle/Pedal Position Sensor A Minimum Stop Performance              | —  |
| P2122 | Throttle/Pedal Position Sensor/Switch "D" Circuit Low Input            | —  |
| P2123 | Throttle/Pedal Position Sensor/Switch "D" Circuit High Input           | —  |
| P2127 | Throttle/Pedal Position Sensor/Switch "E" Circuit Low Input            | —  |
| P2128 | Throttle/Pedal Position Sensor/Switch "E" Circuit High Input           | —  |
| P2135 | Throttle/Pedal Position Sensor/Switch "A"/"B" Voltage Rationality      | —  |
| P2138 | Throttle/Pedal Position Sensor/Switch "D"/"E" Voltage Rationality      | —  |

# Inspection Mode


## ENGINE (DIAGNOSTICS)

### 1. PREPARATION FOR THE INSPECTION MODE

- 1) Check if the battery voltage is more than 12 V and fuel remains half [20 — 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)].
- 2) Lift-up the vehicle using a garage jack and place it on rigid racks, or drive the vehicle onto free rollers.

#### WARNING:


- Before lifting-up the vehicle, ensure parking brakes are applied.
- Do not use a pantograph jack in place of a rigid rack.
- Secure a rope or wire to the front or rear towing hooks to prevent the lateral runout of front wheels.
- Do not abruptly depress/release clutch pedal or accelerator pedal during works even when the engine is operating at low speeds since this may cause vehicle to jump off free rollers.
- In order to prevent the vehicle from slipping due to vibration, do not place any wooden blocks or similar items between the rigid racks and vehicle.
- Since the rear wheels will also rotate, do not place anything near them. Also, make sure that nobody goes in front of the vehicle.




- (A) Rigid rack  
(B) Free rollers

### 2. SUBARU SELECT MONITOR


- 1) After clearing the memory, check for any remaining unresolved trouble data. <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.>
- 2) Idle the engine.
- 3) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4SO 2.5)(diag)-7, PREPARATION TOOL, General Description.>




- 4) Connect the diagnosis cable to Subaru Select Monitor.
- 5) Insert the cartridge to Subaru Select Monitor. <Ref. to EN(H4SO 2.5)(diag)-7, PREPARATION TOOL, General Description.>



- 6) Connect the test mode connector (A) located at the lower portion of glove box.




7) Connect the Subaru Select Monitor to data link connector located in the lower portion of the instrument panel (on the driver's side).



**CAUTION:**

**Do not connect the scan tools except for Subaru Select Monitor or OBD-II general scan tool.**

8) Turn the ignition switch to ON (engine OFF) and turn Subaru Select Monitor switch to ON.



(A) Power switch

9) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.

10) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.

11) Press the [YES] key after the information of engine type has been displayed.

12) On the «Engine Diagnosis» screen, select the {D Check} and press the [YES] key.

13) When the “Perform D Check?” is shown on the screen, press the [YES] key.

14) Perform subsequent procedures as instructed on the display screen.

- If trouble still remains in the memory, the corresponding DTC appears on the display screen.

**NOTE:**

- For detailed operation procedure, refer to “SUBARU SELECT MONITOR OPERATION MANUAL”.

- For the details concerning DTCs, refer to “List of Diagnostic Trouble Code (DTC)”.

<Ref. to EN(H4SO 2.5)(diag)-70, List of Diagnostic Trouble Code (DTC).>

- Release the parking brake.


- The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunctions. When engine control diagnosis is finished, perform the ABS memory clear procedure of self-diagnosis function.

### 3. OBD-II GENERAL SCAN TOOL

1) After performing the diagnostics and clearing memory, check for any remaining unresolved trouble data: <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.>

2) Warm up the engine.


3) Connect the test mode connector (A) at the lower side of globe box.



4) Connect the OBD-II general scan tool to its data link connector in the lower portion of instrument panel (on the driver's side).

**CAUTION:**

**Do not connect the scan tools except for Subaru Select Monitor or OBD-II general scan tool.**



5) Start the engine.

**NOTE:**

- Ensure the select lever is placed in “P” range before starting. (AT model)

- Depress the clutch pedal when starting engine. (MT model)

6) Using the select lever or shift lever, turn the “P” position switch and “N” position switch to ON.

7) Depress the brake pedal to turn brake switch ON. (AT model)

8) Keep the engine speed in 2,500 — 3,000 rpm range for 40 seconds.

### ENGINE (DIAGNOSTICS)

---

9) Place the select lever or shift lever in “D” range (AT model) or “1st” gear (MT model) and drive the vehicle at 5 to 10 km/h (3 to 6 MPH).

NOTE:

- On AWD model, release the parking brake.
- The speed difference between front and rear wheels may light ABS warning light, but this indicates no malfunctions. When the engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

10) Using the OBD-II general scan tool, check for DTC and record the result(s).

NOTE:

- For detailed operation procedures, refer to the operation manual of OBD-II general scan tool.
- For detailed concerning DTC, refer to “List of Diagnostic Trouble Code (DTC)”.

**<Ref. to EN(H4SO 2.5)(diag)-70, List of Diagnostic Trouble Code (DTC).>**



## 12. Drive Cycle

### A: PROCEDURE

There are three drive patterns for the trouble diagnosis. Driving in the specified pattern allows to diagnose malfunctioning items listed below. After the malfunctioning items listed below are repaired, always check whether they correctly resume their functions by driving in the required drive pattern.

#### 1. PREPARATION FOR THE DRIVE CYCLE

- 1) Make sure that the fuel remains approx. half amount [20 — 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)], and battery voltage is 12 V or more.
- 2) After performing the diagnostics and cleaning memory, check for any remaining unresolved trouble data. <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.>
- 3) Separate the test mode connector.

**NOTE:**

- Except for the engine coolant temperature specified items at starting, the diagnosis is carried out after engine warm up.
- Carry out the diagnosis which is marked \* on DTC twice, then, after finishing first diagnosis, stop the engine and do second time at the same condition.

#### 2. AFTER RUNNING 20 MINUTES AT 80 KM/H (50 MPH), IDLE ENGINE FOR 1 MINUTE.

| DTC    | Item   | Condition  |
|--------|--|--|
| *P0125 | Insufficient Coolant Temperature for Closed Loop Fuel Control        | Engine coolant temperature is less than 20°C (68°F) at engine start. |
| *P0133 | O <sub>2</sub> Sensor Circuit Slow Response (Bank 1 Sensor 1)        | —  |
| *P0420 | Catalyst System Efficiency Below Threshold (Bank 1)                  | —  |
| P0459  | Evaporative Emission Control System Purge Control Valve Circuit High | —  |

#### 3. IDLE FOR 10 MINUTES

**NOTE:**


Before the diagnosis, drive the vehicle at 10 km/h (6 MPH) or more.

| DTC   | Item   | Condition |
|-------|--|-----------|
| P0030 | O <sub>2</sub> Sensor Heater Circuit Range/Performance (Bank 1 Sensor 1) | —         |

# Drive Cycle

## ENGINE (DIAGNOSTICS)

### 4. DRIVE ACCORDING TO THE FOLLOWING DRIVE PATTERN



- |   |  |  |
|---|--|--|
| (A) Idle engine for 10 seconds or more.               | (D) Decelerate with throttle fully closed to 64 km/h (40 MPH). | (G) Stop vehicle with throttle fully closed. |
| (B) Accelerate to 97 km/h (60 MPH) within 20 seconds. | (E) Drive vehicle at 64 km/h (40 MPH) for 20 seconds.          | (H) Vehicle speed km/h (MPH)                 |
| (C) Drive vehicle at 97 km/h (60 MPH) for 20 seconds. | (F) Accelerate to 97 km/h (60 MPH) within 10 seconds.          | (I) Seconds                                  |

| DTC    | Item  | Condition                                      |
|--------|---|--|
| *P0139 | O <sub>2</sub> Sensor Circuit Slow Response (Bank 1 Sensor 2) | —  |
| *P0301 | Cylinder 1 Misfire Detected                                   | In some cases, diagnosis may complete at once. |
| *P0302 | Cylinder 2 Misfire Detected                                   | In some cases, diagnosis may complete at once. |
| *P0303 | Cylinder 3 Misfire Detected                                   | In some cases, diagnosis may complete at once. |
| *P0304 | Cylinder 4 Misfire Detected                                   | In some cases, diagnosis may complete at once. |
| P0559  | Generator circuit high input                                  | —  |
| P0700  | Transmission Control System (MIL request)                     | —  |

## 13. Clear Memory Mode

### A: OPERATION

#### 1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type has been displayed.
- 4) On the «Engine Diagnosis» display screen, select the {Memory Clear} and press the [YES] key.
- 5) When the “Done” and “Turn Ignition Switch OFF” are shown on the display screen, turn the ignition switch to OFF and then Subaru Select Monitor switch to OFF.

#### NOTE:

- Initial diagnosis of electronic control throttle is performed after memory clearance. For this reason, start the engine after 10 seconds or more have elapsed since the ignition switch was turned to ON.
- For detailed operation procedure, refer to “SUBARU SELECT MONITOR OPERATION MANUAL”.

#### 2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type has been displayed.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {DTC Clear} and press the [YES] key.
- 6) When the “Perform Diagnostic Code(s) Clear?” is shown on the screen, press the [YES] key.
- 7) Turn the ignition switch to OFF and then turn the Subaru Select Monitor switch to OFF.

#### NOTE:

- Initial diagnosis of electronic control throttle is performed after memory clearance. For this reason, start the engine after 10 seconds or more have elapsed since the ignition switch was turned to ON.
- For detailed operation procedure, refer to “SUBARU SELECT MONITOR OPERATION MANUAL”.


# Compulsory Valve Operation Check Mode

ENGINE (DIAGNOSTICS)

## 14. Compulsory Valve Operation Check Mode


### A: OPERATION

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4SO 2.5)(diag)-7, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.


3) Insert the cartridge to Subaru Select Monitor. <Ref. to EN(H4SO 2.5)(diag)-7, PREPARATION TOOL, General Description.>



4) Connect the test mode connector (A) located at the lower portion of glove box.




5) Connect the Subaru Select Monitor to data link connector located in the lower portion of instrument panel (on the driver's side).



### CAUTION:

**Do not connect the scan tools except for Subaru Select Monitor or OBD-II general scan tool.**

6) Turn the ignition switch to ON (engine OFF) and turn Subaru Select Monitor switch to ON.



(A) Power switch

7) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.

8) On the «System Selection Menu» display screen, select the {Engine} and press the [YES] key.

9) Press the [YES] key after the information of engine type has been displayed.

10) On the «Engine Diagnosis» display screen, select the {System Operation Check Mode} and press the [YES] key.

11) On the «System Operation Check Mode» display screen, select the {Actuator ON/OFF Operation} and press the [YES] key.

12) Select the desired compulsory actuator on the «Actuator ON/OFF Operation» display screen and press the [YES] key.

13) Pressing the [NO] key completes the compulsory valve operation check mode. The display will then return to the «Actuator ON/OFF Operation» screen.

# Compulsory Valve Operation Check Mode

ENGINE (DIAGNOSTICS)

- A list of the support data is shown in the following table.

| DESCRIPTION   | Display              |
|---|----------------------|
| Compulsory fuel pump relay operation check              | Fuel Pump            |
| Compulsory radiator fan relay operation check           | Radiator Fan Relay   |
| Compulsory air conditioning relay operation check       | A/C Compressor Relay |
| Compulsory purge control solenoid valve operation check | CPC Solenoid         |

## NOTE:

- The following parts will be displayed but not functional.

| Display                        |
|--------------------------------|
| EGR Solenoid                   |
| ASV Solenoid                   |
| FICD Solenoid                  |
| Pressure switching solenoid 1  |
| Pressure switching solenoid 2  |
| Wastegate control solenoid     |
| PCV Solenoid                   |
| Vent Control Solenoid          |
| AAI Solenoid                   |
| Fuel Tank Sensor Control Valve |

- For detailed operation procedure, refer to "SUBARU SELECT MONITOR OPERATION MANUAL".

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## 15. Malfunction Indicator Light

### A: PROCEDURE


|  |
|--|
| 1. Activation of malfunction indicator light. <Ref. to EN(H4SO 2.5)(diag)-45, ACTIVATION OF MALFUNCTION INDICATOR LIGHT, Malfunction Indicator Light.>                       |
| ↓  |
| 2. Check that the malfunction indicator light does not come on. <Ref. to EN(H4SO 2.5)(diag)-46, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>  |
| ↓  |
| 3. Check that the malfunction indicator light does not go off. <Ref. to EN(H4SO 2.5)(diag)-48, MALFUNCTION INDICATOR LIGHT DOES NOT GO OFF., Malfunction Indicator Light.>   |
| ↓  |
| 4. Check that the malfunction indicator light does not blink. <Ref. to EN(H4SO 2.5)(diag)-50, MALFUNCTION INDICATOR LIGHT DOES NOT BLINK., Malfunction Indicator Light.>     |
| ↓  |
| 5. Check that the malfunction indicator light remains blinking. <Ref. to EN(H4SO 2.5)(diag)-52, MALFUNCTION INDICATOR LIGHT REMAINS BLINKING., Malfunction Indicator Light.> |

## B: ACTIVATION OF MALFUNCTION INDICATOR LIGHT


1) When the ignition switch is turned to ON (engine OFF), the malfunction indicator light (A) in the combination meter illuminates.

**NOTE:**

If the malfunction indicator light does not illuminate, perform the diagnosis of malfunction indicator light circuit or the combination meter circuit. <Ref. to EN(H4SO 2.5)(diag)-46, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>



2) After starting the engine, the malfunction indicator light goes out. If it does not, either the engine or emission control system is malfunctioning.




- (1) No faulty
- (2) Trouble occurs
- (3) ON
- (4) OFF
- (5) Ignition switch ON
- (6) Engine start

3) Turn the ignition switch to OFF and connect the test mode connector.

(1) When the ignition switch is turned to ON (engine OFF), the malfunction indicator light illuminates.

(2) Malfunction indicator light blinks at a cycle of 0.5 Hz after starting the engine. (During diagnosis)

(3) Malfunction indicator light blinks at a cycle of 3 Hz after diagnosis if there is no trouble. Malfunction indicator light illuminates if faulty.



- (1) ON
- (2) OFF
- (3) Ignition switch ON
- (4) 1 second

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## C: MALFUNCTION INDICATOR LIGHT DOES NOT COME ON

### DIAGNOSIS:


The malfunction indicator light circuit is open or shorted.

### TROUBLE SYMPTOM:

When the ignition switch is turned to ON (engine OFF), malfunction indicator light does not come on.

### WIRING DIAGRAM:

- EC, EK and K4 model



EN-01985

- KA and KS model

### NOTE:

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.



# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

| Step | Check   | Yes   | No   |
|------|---|---|--|
| 1    | <b>CHECK OPTION CODE.</b>   | Go to step 2.   | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br>NOTE:<br>Fuel injection system for KA and KS model is the same as 2.0 L model.                         |
| 2    | <b>CHECK OUTPUT SIGNAL FROM ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 17 (+) — Chassis ground (-):</b>   | Go to step 5.   | Go to step 3.  |
| 3    | <b>CHECK POOR CONTACT.</b><br>Check for poor connection by shaking or pulling ECM connector and harness.  | Repair the poor contact in ECM connector.   | Go to step 4.  |
| 4    | <b>CHECK ECM CONNECTOR.</b><br>Check the connection of ECM connector.   | Replace the ECM. <Ref. to FU(H4SO 2.5)-36, Engine Control Module (ECM).>              | Repair the connection of ECM connector.  |
| 5    | <b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the combination meter. <Ref. to IDI-16, Combination Meter Assembly.><br>3) Disconnect the connector from ECM and combination meter.<br>4) Measure the resistance of harness between ECM and combination meter connector.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 17 — (i10) No. 16:</b> | Go to step 6.   | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following:<br>• Open circuit in harness between ECM and combination meter connector<br>• Poor contact in coupling connector               |
| 6    | <b>CHECK POOR CONTACT.</b><br>Check poor contact in combination meter connector.  | Repair the poor contact in combination meter connector.                               | Go to step 7.  |
| 7    | <b>CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between combination meter connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(i10) No. 3 (+) — Chassis ground (-):</b><br><b>(i10) No. 4 (+) — Chassis ground (-):</b>  | Replace the board of combination meter. <Ref. to IDI-16, Combination Meter Assembly.> | Check the following and repair if necessary.<br>NOTE:<br>• Blown out fuse (No. 5)<br>• Open or short circuit in harness between fuse (No. 5) and battery terminal<br>• Poor contact in ignition switch connector |

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## D: MALFUNCTION INDICATOR LIGHT DOES NOT GO OFF.

### DIAGNOSIS:


The malfunction indicator light circuit is shorted.

### TROUBLE SYMPTOM:

Although malfunction indicator light comes on when the engine runs, DTC is not shown on the Subaru Select Monitor display.

### WIRING DIAGRAM:

- EC, EK and K4 model



EN-01985

- KA and KS model

### NOTE:

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes  | No   |
|--|--|--|--|
| 1<br><b>CHECK OPTION CODE.</b>   | Is the option code EC, EK or K4?                 | Go to step 2.  | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br><br>NOTE:<br>Fuel injection system for KA and KS model is the same as 2.0 L model. |
| 2<br><b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Turn the ignition switch to ON. | Does the malfunction indicator light illuminate? | Repair the short circuit in harness between combination meter and ECM connector. | Replace the ECM. <Ref. to FU(H4SO 2.5)-36, Engine Control Module (ECM).>   |

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## E: MALFUNCTION INDICATOR LIGHT DOES NOT BLINK.

### DIAGNOSIS:


- The malfunction indicator light circuit is open or shorted.
- Test mode connector circuit is in open.

### TROUBLE SYMPTOM:

Malfunction indicator light does not blink during inspection mode.

### WIRING DIAGRAM:

- EC, EK and K4 model



- KA and KS model

### NOTE:

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes  | No   |
|---|--|--|--|
| 1<br><b>CHECK OPTION CODE.</b>  | Is the option code EC, EK or K4?                 | Go to step 2.  | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br>NOTE:<br>Fuel injection system for KA and KS model is the same as 2.0 L model. |
| 2<br><b>CHECK STATUS OF MALFUNCTION INDICATOR LIGHT.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the test mode connectors.<br>3) Turn the ignition switch to ON. (engine OFF)   | Does the malfunction indicator light illuminate? | Go to step 3.  | Repair the malfunction indicator light circuit. <Ref. to EN(H4SO 2.5)(diag)-46, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>                              |
| 3<br><b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Turn the ignition switch to ON.  | Does malfunction indicator light illuminate?     | Repair the short circuit in harness between combination meter and ECM connector. | Go to step 4.  |
| 4<br><b>CHECK HARNESS BETWEEN TEST MODE CONNECTOR AND CHASSIS GROUND.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance of harness between test mode connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B76) No. 1 — Chassis ground:</b>  | Is the resistance less than 1 $\Omega$ ?         | Go to step 5.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following:<br>• Open circuit in harness between test mode connector and chassis ground                            |
| 5<br><b>CHECK POOR CONTACT.</b><br>Check poor contact in ECM connector.   | Is there poor contact in ECM connector?          | Repair the poor contact in ECM connector.  | Go to step 6.  |
| 6<br><b>CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR.</b><br>1) Connect the test mode connector.<br>2) Measure the resistance of harness between ECM and chassis ground.<br><b>Connector &amp; terminal</b><br><b>Model with immobilizer</b><br><b>(B137) No. 15 — Chassis ground:</b><br><b>Model without immobilizer</b><br><b>(B137) No. 14 — Chassis ground:</b> | Is the resistance less than 1 $\Omega$ ?         | Go to step 7.  | Repair the open circuit in harness between ECM and test mode connector.  |
| 7<br><b>CHECK POOR CONTACT.</b><br>Check poor contact in ECM connector.   | Is there poor contact in ECM connector?          | Repair the poor contact in ECM connector.  | Replace the ECM. <Ref. to FU(H4SO 2.5)-36, Engine Control Module (ECM).>   |

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

## F: MALFUNCTION INDICATOR LIGHT REMAINS BLINKING.

### DIAGNOSIS:


Test mode connector circuit is shorted.

### TROUBLE SYMPTOM:

Malfunction indicator light blinks when test mode connector is not connected.

### WIRING DIAGRAM:

- EC, EK and K4 model



- KA and KS model

### NOTE:

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.

# Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

| Step   | Check                                       | Yes  | No   |
|--|---|--|--|
| <b>1 CHECK OPTION CODE.</b>  | Is the option code EC, EK or K4?            | Go to step 2.  | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br>NOTE:<br>Fuel injection system for KA and KS model is the same as 2.0 L model. |
| <b>2 CHECK TEST MODE CONNECTOR.</b><br>1) Disconnect the test mode connectors.<br>2) Turn the ignition switch to ON.   | Does the malfunction indicator light blink? | Go to step 3.  | System is in good order.<br>NOTE:<br>Malfunction indicator light blinks when test mode connector is connected.   |
| <b>3 CHECK HARNESS BETWEEN ECM CONNECTOR AND CHASSIS GROUNDING TERMINAL.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance of harness between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>Model with immobilizer</b><br><b>(B137) No. 15 — Chassis ground:</b><br><b>Model without immobilizer</b><br><b>(B137) No. 14 — Chassis ground:</b> | Is the resistance less than 5 Ω?            | Repair the short circuit in harness between ECM and test mode connector. | Replace the ECM. <Ref. to FU(H4SO 2.5)-36, Engine Control Module (ECM).>   |

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

## 16. Diagnostics for Engine Starting Failure

### A: PROCEDURE

|   |
|---|
| 1. Check for fuel amount.   |
| ↓   |
| 2. Inspection of starter motor circuit. <Ref. to EN(H4SO 2.5)(diag)-55, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>  |
| ↓   |
| 3. Inspection of ECM power supply and ground line. <Ref. to EN(H4SO 2.5)(diag)-58, CHECK POWER SUPPLY AND GROUND LINE OF ENGINE CONTROL MODULE (ECM), Diagnostics for Engine Starting Failure.> |
| ↓   |
| 4. Inspection of ignition control system. <Ref. to EN(H4SO 2.5)(diag)-61, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>  |
| ↓   |
| 5. Inspection of fuel pump circuit. <Ref. to EN(H4SO 2.5)(diag)-64, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>  |
| ↓   |
| 6. Inspection of fuel injector circuit. <Ref. to EN(H4SO 2.5)(diag)-67, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>  |




## B: STARTER MOTOR CIRCUIT

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4SO 2.5)(diag)-34, Inspection Mode.>.

### WIRING DIAGRAM:

- EC, EK and K4 model



**B72**

|   |   |   |
|---|---|---|
| 1 | 2 | 3 |
| 4 | 5 | 6 |

**B225**

|   |   |    |    |    |    |
|---|---|----|----|----|----|
| 1 | 2 | 9  | 13 | 17 | 21 |
| 3 | 4 | 10 | 14 | 18 | 22 |
| 5 | 6 | 11 | 12 | 15 | 16 |
| 7 | 8 | 19 | 20 | 23 | 24 |
|   |   | 25 | 29 | 33 | 37 |
|   |   | 26 | 30 | 34 | 38 |
|   |   | 27 | 28 | 31 | 32 |
|   |   | 35 | 36 | 39 | 40 |

**B: B135**

|    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  |
| 8  | 9  | 10 | 11 | 12 | 13 | 14 |
| 15 | 16 | 17 | 18 | 19 | 20 | 21 |
| 22 | 23 | 24 | 25 | 26 | 27 | 28 |
| 29 | 30 | 31 | 32 | 33 | 34 | 35 |

**D: B137**

|    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  |
| 8  | 9  | 10 | 11 | 12 | 13 | 14 |
| 15 | 16 | 17 | 18 | 19 | 20 | 21 |
| 22 | 23 | 24 | 25 | 26 | 27 | 28 |
| 29 | 30 | 31 | 32 | 33 | 34 | 35 |

## Diagnostics for Engine Starting Failure

### ENGINE (DIAGNOSTICS)

- KA and KS model

**NOTE:**

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.

| Step | Check   | Yes   | No  |   |
|------|---|---|---|---|
| 1    | <b>CHECK OPTION CODE.</b>   | Is the option code EC, EK or K4?  | Go to step 2.   | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br><b>NOTE:</b><br>Fuel injection system for KA and KS model is the same as 2.0 L model. |
| 2    | <b>CHECK BATTERY.</b><br>Check the battery voltage.   | Is the voltage more than 12 V?  | Go to step 3.   | Charge or replace the battery.  |
| 3    | <b>CHECK OPERATION OF STARTER MOTOR.</b>  | Does the starter motor operate?   | Go to step 4.   | Go to step 5.   |
| 4    | <b>CHECK DTC.</b>   | Is DTC displayed? <Ref. to EN(H4SO 2.5)(diag)-33, OPERATION, Read Diagnostic Trouble Code (DTC).> | Inspect the relevant DTC using List of Diagnostic Trouble Code (DTC). <Ref. to EN(H4SO 2.5)(diag)-70, List of Diagnostic Trouble Code (DTC).> | Repair the poor contact in ECM connector.   |
| 5    | <b>CHECK INPUT SIGNAL FOR STARTER MOTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from starter motor.<br>3) Turn the ignition switch to START.<br>4) Measure the power supply voltage between starter motor connector terminal and engine ground.<br><b>Connector &amp; terminal</b><br><b>(B14) No. 1 (+) — Engine ground (-):</b><br><b>NOTE:</b><br>Place the select lever in the "P" or "N" range. | Is the voltage more than 10 V?  | Go to step 6.   | Go to step 7.   |
| 6    | <b>CHECK GROUND CIRCUIT OF STARTER MOTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the ground cable terminal from starter motor.<br>3) Measure the resistance of ground cable between ground cable terminal and engine ground.   | Is the resistance less than 5 Ω?  | Check the starter motor. <Ref. to SC(H4SO 2.0)-6, Starter.>   | Repair the open circuit of ground cable.  |
| 7    | <b>CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.</b><br>1) Disconnect the connector from ignition switch.<br>2) Measure the power supply voltage between ignition switch connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B72) No. 3 (+) — Chassis ground (-):</b>  | Is the voltage more than 10 V?  | Go to step 8.   | Repair the open circuit in harness between ignition switch and battery, and check fuse SBF No. 7 and SBF No. 1.   |

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step  | Check                                    | Yes  | No  |
|---|--|--|---|
| <b>8 CHECK IGNITION SWITCH.</b><br>1) Disconnect the connector from ignition switch.<br>2) Measure the resistance between ignition switch terminals after turning the ignition switch to START position.<br><b>Terminals</b><br><b>No. 2 — No. 3:</b>   | Is the resistance less than 5 $\Omega$ ? | Go to step 9.  | Replace the ignition switch.  |
| <b>9 CHECK INPUT VOLTAGE OF STARTER RELAY.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from starter relay.<br>3) Connect the connector to ignition switch.<br>4) Measure the input voltage between starter relay connector and chassis ground after turning the ignition switch to START position.<br><b>Connector &amp; terminal</b><br><b>LHD model</b><br>(B225) No. 13 (+) — Chassis ground (-):<br>(B225) No. 15 (+) — Chassis ground (-):<br><b>RHD model</b><br>(B225) No. 14 (+) — Chassis ground (-):<br>(B225) No. 16 (+) — Chassis ground (-): | Is the voltage more than 10 V?           | Go to step 10.   | Repair the open circuit in harness between starter fan relay and ignition switch. |
| <b>10 CHECK STARTER RELAY.</b><br>1) Connect the battery to starter relay terminals No. 15 and No. 16.<br>2) Measure the resistance between starter relay terminals.<br><b>Terminals</b><br><b>No. 13 — No. 14:</b>   | Is the resistance less than 1 $\Omega$ ? | Go to step 11.   | Replace the starter relay.  |
| <b>11 CHECK INPUT VOLTAGE OF ECM.</b><br>1) Turn the ignition switch to OFF.<br>2) Connect the connector to starter relay.<br>3) Disconnect the connectors from ECM.<br>4) Measure the voltage between ECM and chassis ground.<br><b>Connector &amp; terminal</b><br>(B135) No. 32 (+) — Chassis ground (-):<br>(B137) No. 8 (+) — Chassis ground (-):  | Is the voltage more than 10 V?           | Replace the ECM. <Ref. to FU(H4SO 2.5)-36, Engine Control Module (ECM).> | Repair the open or ground short circuit in harness between ECM and starter relay. |

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)


## C: CHECK POWER SUPPLY AND GROUND LINE OF ENGINE CONTROL MODULE (ECM)

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4SO 2.5)(diag)-34, Inspection Mode.>.

### WIRING DIAGRAM:

- EC, EK and K4 model



EN-02456

- KA and KS model

### NOTE:

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step | Check  | Yes           | No  |
|------|--|---------------|---|
| 1    | <b>CHECK OPTION CODE.</b>  | Go to step 2. | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br><b>NOTE:</b><br>Fuel injection system for KA and KS model is the same as 2.0 L model. |
| 2    | <b>CHECK MAIN RELAY.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the main relay.<br>3) Connect the battery to main relay terminals No. 1 and No. 2.<br>4) Measure the resistance between main relay terminals.<br><b>Terminals</b><br><b>No. 3 — No. 5:</b><br><b>No. 4 — No. 6:</b>   | Go to step 3. | Replace the main relay.   |
| 3    | <b>CHECK GROUND CIRCUIT FOR ECM.</b><br>1) Disconnect the connector from ECM.<br>2) Measure the resistance of harness between ECM and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 6 — Chassis ground:</b><br><b>(B134) No. 7 — Chassis ground:</b><br><b>(B135) No. 1 — Chassis ground:</b><br><b>(B135) No. 4 — Chassis ground:</b><br><b>(B135) No. 12 — Chassis ground:</b><br><b>(B137) No. 1 — Chassis ground:</b><br><b>(B137) No. 2 — Chassis ground:</b><br><b>(B137) No. 3 — Chassis ground:</b><br><b>(B137) No. 7 — Chassis ground:</b> | Go to step 4. | Repair the open circuit in harness between ECM connector and engine grounding terminal.   |
| 4    | <b>CHECK INPUT VOLTAGE OF ECM.</b><br>Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B135) No. 19 (+) — Chassis ground (-):</b>   | Go to step 5. | Repair the open or ground short circuit of power supply circuit.  |
| 5    | <b>CHECK INPUT VOLTAGE OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>Model with immobilizer</b><br><b>(B137) No. 14 (+) — Chassis ground (-):</b><br><b>Model without immobilizer</b><br><b>(B137) No. 15 (+) — Chassis ground (-):</b>   | Go to step 6. | Repair the open or ground short circuit of power supply circuit.  |
| 6    | <b>CHECK INPUT VOLTAGE OF MAIN RELAY.</b><br>Measure the voltage between main relay connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>LHD model</b><br><b>(B47) No. 1 (+) — Chassis ground (-):</b><br><b>RHD model</b><br><b>(B47) No. 2 (+) — Chassis ground (-):</b>   | Go to step 7. | Repair the open circuit in harness between ECM connector and main relay connector.  |

## Diagnostics for Engine Starting Failure

### ENGINE (DIAGNOSTICS)

| Step   | Check                          | Yes  | No   |
|--|--------------------------------|--|--|
| <b>7</b><br><b>CHECK INPUT VOLTAGE OF ECM.</b><br>1) Connect the connectors to ECM and main relay.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>Model with immobilizer</b><br><i>(B137) No. 16 (+) — Chassis ground (-):</i><br><b>Model without immobilizer</b><br><i>(B137) No. 17 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Go to step <b>8</b> .  | Repair the open or ground short circuit in harness between ECM connector and main relay connector. |
| <b>8</b><br><b>CHECK INPUT VOLTAGE OF MAIN RELAY.</b><br>Measure the voltage between main relay connector and chassis ground.<br><b>Connector &amp; terminal</b><br><i>(B47) No. 5 (+) — Chassis ground (-):</i><br><i>(B47) No. 6 (+) — Chassis ground (-):</i>   | Is the voltage more than 10 V? | Go to step <b>9</b> .  | Repair the open or ground short circuit in harness of power supply circuit.                        |
| <b>9</b><br><b>CHECK INPUT VOLTAGE OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><i>(B135) No. 5 (+) — Chassis ground (-):</i><br><i>(B135) No. 6 (+) — Chassis ground (-):</i>  | Is the voltage more than 10 V? | Check ignition control system.<br><Ref. to EN(H4SO 2.5)(diag)-61, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.> | Repair the open or ground short circuit in harness between ECM connector and main relay connector. |


## D: IGNITION CONTROL SYSTEM

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4SO 2.5)(diag)-34, Inspection Mode.>.

### WIRING DIAGRAM:

- EC, EK and K4 model



EN-01989

- KA and KS model

### NOTE:

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.

## Diagnostics for Engine Starting Failure

### ENGINE (DIAGNOSTICS)

| Step  | Check                                    | Yes  | No   |
|---|--|--|--|
| <b>1</b><br><b>CHECK OPTION CODE.</b>   | Is the option code EC, EK or K4?         | Go to step 2.  | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br>NOTE:<br>Fuel injection system for KA and KS model is the same as 2.0 L model.   |
| <b>2</b><br><b>CHECK IGNITION SYSTEM FOR SPARKS.</b><br>1) Remove the plug cord cap from each spark plug.<br>2) Install a new spark plug on plug cord cap.<br><b>CAUTION:</b><br><b>Do not remove the spark plug from engine.</b><br>3) Contact the spark plug's thread portion on engine.<br>4) While opening the throttle valve fully, crank the engine to check that spark occurs at each cylinder.                        | Does spark occur at each cylinder?       | Check fuel pump system. <Ref. to EN(H4SO 2.5)(diag)-64, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.> | Go to step 3.  |
| <b>3</b><br><b>CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL &amp; IGNITOR ASSY.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ignition coil & ignitor ASSY.<br>3) Turn the ignition switch to ON.<br>4) Measure the power supply voltage between ignition coil & ignitor ASSY connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E12) No. 2 (+) — Engine ground (-):</b> | Is the voltage more than 10 V?           | Go to step 4.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ignition coil &amp; ignitor ASSY and main relay connector</li> <li>• Poor contact in coupling connector</li> <li>• Blown out fuse</li> </ul> |
| <b>4</b><br><b>CHECK HARNESS OF IGNITION COIL &amp; IGNITOR ASSY GROUND CIRCUIT.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance between ignition coil & ignitor ASSY connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E12) No. 3 — Engine ground:</b>  | Is the resistance less than 5 $\Omega$ ? | Go to step 5.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ignition coil &amp; ignitor ASSY connector and engine grounding terminal</li> </ul>  |
| <b>5</b><br><b>CHECK IGNITION COIL &amp; IGNITOR ASSY.</b><br>1) Remove the spark plug cords.<br>2) Measure the resistance between spark plug cord contact portions to check secondary coil.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b><br><b>No. 3 — No. 4:</b>  | Is the resistance 10 — 15 k $\Omega$ ?   | Go to step 6.  | Replace the ignition coil & ignitor ASSY. <Ref. to IG(H4SO 2.0)-8, Ignition Coil & Ignitor ASSY.>  |



# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step   | Check                                      | Yes                                       | No  |
|--|--|---|---|
| <p><b>6 CHECK INPUT SIGNAL FOR IGNITION COIL &amp; IGNITOR ASSY.</b></p> <p>1) Connect the connector to ignition coil &amp; ignitor ASSY.</p> <p>2) Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignition coil &amp; ignitor ASSY connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(E12) No. 1 (+) — Engine ground (-):</b><br/> <b>(E12) No. 4 (+) — Engine ground (-):</b></p>                       | Does the voltage vary more than 10 V?      | Go to step 7.                             | Replace the ignition coil & ignitor ASSY. <Ref. to IG(H4SO 2.0)-8, Ignition Coil & Ignitor ASSY.>   |
| <p><b>7 CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSY CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ECM.</p> <p>3) Disconnect the connector from ignition coil &amp; ignitor ASSY.</p> <p>4) Measure the resistance of harness between ECM and ignition coil &amp; ignitor ASSY connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B135) No. 18 — (E12) No. 1:</b><br/> <b>(B135) No. 17 — (E12) No. 4:</b></p> | Is the resistance less than 1 $\Omega$ ?   | Go to step 8.                             | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and ignition coil &amp; ignitor ASSY connector</li> <li>• Poor contact in coupling connector</li> </ul> |
| <p><b>8 CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSY CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM and engine ground.</p> <p><b>Connector &amp; terminal:</b><br/> <b>(B135) No. 18 — Engine ground:</b><br/> <b>(B135) No. 17 — Engine ground:</b></p>  | Is the resistance more than 1 M $\Omega$ ? | Go to step 9.                             | Repair the ground short circuit in harness between ECM and ignition coil & ignitor ASSY connector.  |
| <p><b>9 CHECK POOR CONTACT.</b></p> <p>Check poor contact in ECM connector.</p>  | Is there poor contact in ECM connector?    | Repair the poor contact in ECM connector. | Check fuel pump circuit. <Ref. to EN(H4SO 2.5)(diag)-64, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>   |

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)


## E: FUEL PUMP CIRCUIT

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4SO 2.5)(diag)-34, Inspection Mode.>.

### WIRING DIAGRAM:

- EC, EK and K4 model



EN-02457

- KA and KS model

### NOTE:

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step | Check  | Yes   | No  |
|------|--|---|---|
| 1    | <b>CHECK OPTION CODE.</b>  | Go to step 2.                               | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br><b>NOTE:</b><br>Fuel injection system for KA and KS model is the same as 2.0 L model. |
| 2    | <b>CHECK OPERATING SOUND OF FUEL PUMP.</b><br>Check the fuel pump is in operation for two seconds when turning the ignition switch to ON.<br><b>NOTE:</b><br>Fuel pump operation can also be executed using Subaru Select Monitor.<br>Refer to "Compulsory Valve Operation Check Mode" for procedures. <Ref. to EN(H4SO 2.5)(diag)-42, Compulsory Valve Operation Check Mode.> | Does the fuel pump produce operating sound? | Check the fuel injector circuit.<br><Ref. to EN(H4SO 2.5)(diag)-67, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>  |
| 3    | <b>CHECK GROUND CIRCUIT OF FUEL PUMP.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the fuel pump access hole lid.<br>3) Disconnect the connector from fuel pump.<br>4) Measure the resistance of harness connector between fuel pump and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(R58) No. 6 — Chassis ground:</b>                                 | Is the resistance less than 5 $\Omega$ ?    | Go to step 4.   |
| 4    | <b>CHECK POWER SUPPLY TO FUEL PUMP.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage of power supply circuit between fuel pump connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(R58) No. 5 (+) — Chassis ground (-):</b>   | Is the voltage more than 10 V?              | Replace the fuel pump. <Ref. to FU(H4SO 2.5)-49, Fuel Pump.>  |
| 5    | <b>CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance of harness connector between fuel pump and fuel pump relay.<br><b>Connector &amp; terminal</b><br><b>(R58) No. 5 — (B362) No. 1:</b>   | Is the resistance less than 1 $\Omega$ ?    | Go to step 6.   |
| 6    | <b>CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.</b><br>Measure the resistance of harness between fuel pump and fuel pump relay connector.<br><b>Connector &amp; terminal</b><br><b>(R58) No. 5 — Chassis ground:</b>   | Is the resistance more than 1 M $\Omega$ ?  | Go to step 7.   |

# Diagnostics for Engine Starting Failure

## ENGINE (DIAGNOSTICS)

| Step  | Check                                     | Yes                                       | No  |
|---|---|---|---|
| <b>7 CHECK FUEL PUMP RELAY.</b><br>1) Disconnect the connectors from fuel pump relay and main relay.<br>2) Remove the fuel pump relay and main relay with bracket.<br>3) Connect the battery to fuel pump relay connector terminals No. 3 and No. 4.<br>4) Measure the resistance between connector terminals of fuel pump relay.<br><i>Terminals</i><br><i>No. 2 — No. 1:</i>        | Is the resistance less than 10 $\Omega$ ? | Go to step 8.                             | Replace the fuel pump relay. <Ref. to FU(H4SO 2.5)-49, Fuel Pump.>  |
| <b>8 CHECK HARNESS BETWEEN ECM AND FUEL PUMP RELAY CONNECTOR.</b><br>1) Disconnect the connector from ECM.<br>2) Measure the resistance of harness between ECM and fuel pump relay connector.<br><i>Connector &amp; terminal</i><br><i>Model with immobilizer</i><br><i>(B135) No. 27 — (B362) No. 4:</i><br><i>Model without immobilizer</i><br><i>(B135) No. 26 — (B362) No. 4:</i> | Is the resistance less than 1 $\Omega$ ?  | Go to step 9.                             | Repair the open circuit in harness between ECM and fuel pump relay connector.   |
| <b>9 CHECK POOR CONTACT.</b><br>Check poor contact in ECM connector.  | Is there poor contact in ECM connector?   | Repair the poor contact in ECM connector. | Check the fuel injector circuit. <Ref. to EN(H4SO 2.5)(diag)-67, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.> |


## F: FUEL INJECTOR CIRCUIT

### CAUTION:

- Check or repair only faulty parts.
- After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4SO 2.5)(diag)-41, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4SO 2.5)(diag)-34, Inspection Mode.>.

### WIRING DIAGRAM:

- EC, EK and K4 model



EN-01991

- KA and KS model

### NOTE:

Fuel injection system for KA and KS model is the same as 2.0 L model. Refer to EN(H4SO 2.0) section.

## Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step   | Check                                      | Yes  | No  |
|--|--|--|---|
| <b>1</b><br><b>CHECK OPTION CODE.</b>  | Is the option code EC, EK or K4?           | Go to step 2.  | Refer to EN(H4SO 2.0) section. <Ref. to EN(H4SO 2.0)(diag)-66, List of Diagnostic Trouble Code (DTC).><br>NOTE:<br>Fuel injection system for KA and KS model is the same as 2.0 L model.  |
| <b>2</b><br><b>CHECK OPERATION OF EACH FUEL INJECTOR.</b><br>While cranking the engine, check each fuel injector emits operating sound. Use a sound scope or apply a screwdriver to the injector for this check.   | Does the fuel pump emit operating sound?   | Check the fuel pressure. <Ref. to ME(H4SO 2.0)-27, INSPECTION, Fuel Pressure.> | Go to step 3.   |
| <b>3</b><br><b>CHECK POWER SUPPLY TO EACH FUEL INJECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from fuel injector.<br>3) Turn the ignition switch to ON.<br>4) Measure the power supply voltage between fuel injector terminal and engine ground.<br><b>Connector &amp; terminal</b><br><b>#1 (E5) No. 2 (+) — Engine ground (-):</b><br><b>#2 (E16) No. 2 (+) — Engine ground (-):</b><br><b>#3 (E6) No. 2 (+) — Engine ground (-):</b><br><b>#4 (E17) No. 2 (+) — Engine ground (-):</b> | Is the voltage more than 10 V?             | Go to step 4.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in fuel injector connector</li> </ul> |
| <b>4</b><br><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b><br>1) Disconnect the connector from ECM.<br>2) Measure the resistance of harness between ECM and fuel injector connector.<br><b>Connector &amp; terminal</b><br><b>#1 (B136) No. 6 — (E5) No. 1:</b><br><b>#2 (B136) No. 5 — (E16) No. 1:</b><br><b>#3 (B136) No. 4 — (E6) No. 1:</b><br><b>#4 (B136) No. 3 — (E17) No. 1:</b>   | Is the resistance less than 1 $\Omega$ ?   | Go to step 5.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and fuel injector connector</li> <li>• Poor contact in coupling connector</li> </ul>   |
| <b>5</b><br><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b><br>Measure the resistance of harness between ECM and fuel injector connector.<br><b>Connector &amp; terminal</b><br><b>#1 (B136) No. 6 — Chassis ground:</b><br><b>#2 (B136) No. 5 — Chassis ground:</b><br><b>#3 (B136) No. 4 — Chassis ground:</b><br><b>#4 (B136) No. 3 — Chassis ground:</b>   | Is the resistance more than 1 M $\Omega$ ? | Go to step 6.  | Repair the ground short circuit in harness between ECM and fuel injector connector.   |

# Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step  | Check                                   | Yes                                       | No  |
|---|---|---|---|
| <b>6</b><br><b>CHECK EACH FUEL INJECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance between each fuel injector terminals.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b> | Is the resistance 5 — 20 Ω?             | Go to step 7.                             | Replace the faulty fuel injector.   |
| <b>7</b><br><b>CHECK POOR CONTACT.</b><br>Check poor contact in ECM connector.  | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Inspection using "General Diagnostic Table" <Ref. to EN(H4SO 2.5)(diag)-261, INSPECTION, General Diagnostic Table.> |

## List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

### 17. List of Diagnostic Trouble Code (DTC)

#### A: LIST

##### 1. EC, EK AND K4 MODEL

| DTC   | Item  | NOTE  |
|-------|---|---|
| P0030 | HO2S Heater Control Circuit (Bank 1 Sensor 1)                     | <Ref. to EN(H4SO 2.5)(diag)-80, DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                      |
| P0031 | HO2S Heater Control Circuit Low (Bank 1 Sensor 1)                 | <Ref. to EN(H4SO 2.5)(diag)-82, DTC P0031 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                  |
| P0032 | HO2S Heater Control Circuit High (Bank 1 Sensor 1)                | <Ref. to EN(H4SO 2.5)(diag)-85, DTC P0032 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P0037 | HO2S Heater Control Circuit Low (Bank 1 Sensor 2)                 | <Ref. to EN(H4SO 2.5)(diag)-87, DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                  |
| P0038 | HO2S Heater Control Circuit High (Bank 1 Sensor 2)                | <Ref. to EN(H4SO 2.5)(diag)-90, DTC P0038 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P0102 | Mass or Volume Air Flow Circuit Low Input                         | <Ref. to EN(H4SO 2.5)(diag)-92, DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                          |
| P0103 | Mass or Volume Air Flow Circuit High Input                        | <Ref. to EN(H4SO 2.5)(diag)-95, DTC P0103 MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                         |
| P0107 | Manifold Absolute Pressure/Barometric Pressure Circuit Low Input  | <Ref. to EN(H4SO 2.5)(diag)-97, DTC P0107 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0108 | Manifold Absolute Pressure/Barometric Pressure Circuit High Input | <Ref. to EN(H4SO 2.5)(diag)-100, DTC P0108 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0112 | Intake Air Temperature Circuit Low Input                          | <Ref. to EN(H4SO 2.5)(diag)-103, DTC P0112 INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                          |
| P0113 | Intake Air Temperature Circuit High Input                         | <Ref. to EN(H4SO 2.5)(diag)-105, DTC P0113 INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                         |
| P0117 | Engine Coolant Temperature Circuit Low Input                      | <Ref. to EN(H4SO 2.5)(diag)-108, DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                      |
| P0118 | Engine Coolant Temperature Circuit High Input                     | <Ref. to EN(H4SO 2.5)(diag)-110, DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                     |
| P0122 | Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input       | <Ref. to EN(H4SO 2.5)(diag)-113, DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>       |
| P0123 | Throttle/Pedal Position Sensor/Switch "A" Circuit High Input      | <Ref. to EN(H4SO 2.5)(diag)-116, DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>      |
| P0125 | Insufficient Coolant Temperature for Closed Loop Fuel Control     | <Ref. to EN(H4SO 2.5)(diag)-119, DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>     |
| P0131 | O2 Sensor Circuit Low Voltage (Bank 1 Sensor 1)                   | <Ref. to EN(H4SO 2.5)(diag)-121, DTC P0131 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                   |



# List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC   | Item  | NOTE  |
|-------|---|---|
| P0132 | O2 Sensor Circuit High Voltage (Bank 1 Sensor 1)                    | <Ref. to EN(H4SO 2.5)(diag)-123, DTC P0132 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                    |
| P0133 | O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)                   | <Ref. to EN(H4SO 2.5)(diag)-125, DTC P0133 O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                   |
| P0134 | O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)            | <Ref. to EN(H4SO 2.5)(diag)-127, DTC P0134 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>            |
| P0137 | O2 Sensor Circuit Low Voltage (Bank 1 Sensor 2)                     | <Ref. to EN(H4SO 2.5)(diag)-129, DTC P0137 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                     |
| P0138 | O2 Sensor Circuit High Voltage (Bank 1 Sensor 2)                    | <Ref. to EN(H4SO 2.5)(diag)-132, DTC P0138 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                    |
| P0139 | O2 Sensor Circuit Slow Response (Bank 1 Sensor 2)                   | <Ref. to EN(H4SO 2.5)(diag)-135, DTC P0139 O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                   |
| P0171 | System Too Lean (Bank 1)  | <Ref. to EN(H4SO 2.5)(diag)-136, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0172 | System Too Rich (Bank 1)  | <Ref. to EN(H4SO 2.5)(diag)-137, DTC P0172 SYSTEM TOO RICH (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0222 | Throttle/Pedal Position Sensor/Switch "B" Circuit Low Input         | <Ref. to EN(H4SO 2.5)(diag)-140, DTC P0222 THROTTLE/PEDAL POSITION SENSOR/SWITCH "B" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P0223 | Throttle/Pedal Position Sensor/Switch "B" Circuit High Input        | <Ref. to EN(H4SO 2.5)(diag)-143, DTC P0223 THROTTLE/PEDAL POSITION SENSOR/SWITCH "B" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>        |
| P0301 | Cylinder 1 misfire detected   | <Ref. to EN(H4SO 2.5)(diag)-146, DTC P0301 CYLINDER 1 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0302 | Cylinder 2 misfire detected   | <Ref. to EN(H4SO 2.5)(diag)-146, DTC P0302 CYLINDER 2 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0303 | Cylinder 3 misfire detected   | <Ref. to EN(H4SO 2.5)(diag)-146, DTC P0303 CYLINDER 3 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0304 | Cylinder 4 misfire detected   | <Ref. to EN(H4SO 2.5)(diag)-147, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0327 | Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)          | <Ref. to EN(H4SO 2.5)(diag)-151, DTC P0327 KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>          |
| P0328 | Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)         | <Ref. to EN(H4SO 2.5)(diag)-153, DTC P0328 KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P0335 | Crankshaft Position Sensor "A" Circuit                              | <Ref. to EN(H4SO 2.5)(diag)-155, DTC P0335 CRANKSHAFT POSITION SENSOR "A" CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                              |
| P0340 | Camshaft Position Sensor "A" Circuit (Bank 1 or Single Sensor)      | <Ref. to EN(H4SO 2.5)(diag)-158, DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>      |
| P0400 | Exhaust Gas Recirculation Flow                                      | <Ref. to EN(H4SO 2.5)(diag)-161, DTC P0400 EXHAUST GAS RECIRCULATION FLOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                      |
| P0420 | Catalyst System Efficiency Below Threshold (Bank 1)                 | <Ref. to EN(H4SO 2.5)(diag)-164, DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P0458 | Evaporative Emission Control System Purge Control Valve Circuit Low | <Ref. to EN(H4SO 2.5)(diag)-166, DTC P0458 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

## List of Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| DTC   | Item   | NOTE   |
|-------|--|--|
| P0459 | Evaporative Emission Control System Purge Control Valve Circuit High | <Ref. to EN(H4SO 2.5)(diag)-169, DTC P0459 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0462 | Fuel Level Sensor Circuit Low Input                                  | <Ref. to EN(H4SO 2.5)(diag)-172, DTC P0462 FUEL LEVEL SENSOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                  |
| P0463 | Fuel Level Sensor Circuit High Input                                 | <Ref. to EN(H4SO 2.5)(diag)-173, DTC P0463 FUEL LEVEL SENSOR CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                 |
| P0500 | Vehicle Speed Sensor   | <Ref. to EN(H4SO 2.5)(diag)-174, DTC P0500 VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0512 | Starter Request Circuit  | <Ref. to EN(H4SO 2.5)(diag)-175, DTC P0512 STARTER REQUEST CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0513 | Incorrect Immobilizer Key  | <Ref. to IM(diag)-17, DTC P0513 INCORRECT IMMOBILIZER KEY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0519 | Idle Control System Malfunction (Fail-Safe)                          | <Ref. to EN(H4SO 2.5)(diag)-178, DTC P0519 IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                          |
| P0558 | Generator Circuit Low Input  | <Ref. to EN(H4SO 2.5)(diag)-178, DTC P0558 GENERATOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0559 | Generator Circuit High Input   | <Ref. to EN(H4SO 2.5)(diag)-179, DTC P0559 GENERATOR CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0600 | Serial Communication Link  | <Ref. to EN(H4SO 2.5)(diag)-180, DTC P0600 SERIAL COMMUNICATION LINK, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0604 | Internal Control Module Read Access Memory (RAM) Error               | <Ref. to EN(H4SO 2.5)(diag)-181, DTC P0604 INTERNAL CONTROL MODULE READ ACCESS MEMORY (RAM) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>               |
| P0605 | Internal Control Module Read Only Memory (ROM) Error                 | <Ref. to EN(H4SO 2.5)(diag)-182, DTC P0605 INTERNAL CONTROL MODULE READ ONLY MEMORY (ROM) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P0607 | Control Module Performance   | <Ref. to EN(H4SO 2.5)(diag)-183, DTC P0607 CONTROL MODULE PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0638 | Throttle Actuator Control Range/Performance (Bank 1)                 | <Ref. to EN(H4SO 2.5)(diag)-184, DTC P0638 THROTTLE ACTUATOR CONTROL RANGE/PERFORMANCE (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P0691 | Cooling Fan 1 Control Circuit Low                                    | <Ref. to EN(H4SO 2.5)(diag)-185, DTC P0691 COOLING FAN 1 CONTROL CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                    |
| P0692 | Cooling Fan 1 Control Circuit High                                   | <Ref. to EN(H4SO 2.5)(diag)-186, DTC P0692 COOLING FAN 1 CONTROL CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                   |
| P0700 | Transmission Control System (MIL Request)                            | <Ref. to EN(H4SO 2.5)(diag)-186, DTC P0700 TRANSMISSION CONTROL SYSTEM (MIL REQUEST), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                            |
| P0851 | Neutral Switch Input Circuit Low                                     | <Ref. to EN(H4SO 2.5)(diag)-187, DTC P0851 NEUTRAL SWITCH INPUT CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                     |
| P0852 | Neutral Switch Input Circuit High                                    | <Ref. to EN(H4SO 2.5)(diag)-189, DTC P0852 NEUTRAL SWITCH INPUT CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                    |
| P1086 | Tumble Generated Valve Position Sensor 2 Circuit Low                 | <Ref. to EN(H4SO 2.5)(diag)-192, DTC P1086 TUMBLE GENERATED VALVE POSITION SENSOR 2 CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P1087 | Tumble Generated Valve Position Sensor 2 Circuit High                | <Ref. to EN(H4SO 2.5)(diag)-195, DTC P1087 TUMBLE GENERATED VALVE POSITION SENSOR 2 CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                |
| P1088 | Tumble Generated Valve Position Sensor 1 Circuit Low                 | <Ref. to EN(H4SO 2.5)(diag)-197, DTC P1088 TUMBLE GENERATED VALVE POSITION SENSOR 1 CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |

# List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC   | Item  | NOTE  |
|-------|---|---|
| P1089 | Tumble Generated Valve Position Sensor 1 Circuit High         | <Ref. to EN(H4SO 2.5)(diag)-200, DTC P1089 TUMBLE GENERATED VALVE POSITION SENSOR 1 CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P1090 | Tumble Generated Valve System 1 (Valve Open)                  | <Ref. to EN(H4SO 2.5)(diag)-202, DTC P1090 TUMBLE GENERATED VALVE SYSTEM 1 (VALVE OPEN), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                  |
| P1091 | Tumble Generated Valve System 1 (Valve Close)                 | <Ref. to EN(H4SO 2.5)(diag)-203, DTC P1091 TUMBLE GENERATED VALVE SYSTEM 1 (VALVE CLOSE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P1092 | Tumble Generated Valve System 2 (Valve Open)                  | <Ref. to EN(H4SO 2.5)(diag)-204, DTC P1092 TUMBLE GENERATED VALVE SYSTEM 2 (VALVE OPEN), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                  |
| P1093 | Tumble Generated Valve System 2 (Valve Close)                 | <Ref. to EN(H4SO 2.5)(diag)-205, DTC P1093 TUMBLE GENERATED VALVE SYSTEM 2 (VALVE CLOSE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P1094 | Tumble Generated Valve Signal 1 Circuit Malfunction (Open)    | <Ref. to EN(H4SO 2.5)(diag)-206, DTC P1094 TUMBLE GENERATED VALVE SIGNAL 1 CIRCUIT MALFUNCTION (OPEN), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>    |
| P1095 | Tumble Generated Valve Signal 1 Circuit Malfunction (Short)   | <Ref. to EN(H4SO 2.5)(diag)-208, DTC P1095 TUMBLE GENERATED VALVE SIGNAL 1 CIRCUIT MALFUNCTION (SHORT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P1096 | Tumble Generated Valve Signal 2 Circuit Malfunction (Open)    | <Ref. to EN(H4SO 2.5)(diag)-210, DTC P1096 TUMBLE GENERATED VALVE SIGNAL 2 CIRCUIT MALFUNCTION (OPEN), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>    |
| P1097 | Tumble Generated Valve Signal 2 Circuit Malfunction (Short)   | <Ref. to EN(H4SO 2.5)(diag)-212, DTC P1097 TUMBLE GENERATED VALVE SIGNAL 2 CIRCUIT MALFUNCTION (SHORT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P1110 | Atmospheric Pressure Sensor Circuit Malfunction (Low Input)   | <Ref. to EN(H4SO 2.5)(diag)-214, DTC P1110 ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P1111 | Atmospheric Pressure Sensor Circuit Malfunction (High Input)  | <Ref. to EN(H4SO 2.5)(diag)-215, DTC P1111 ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1152 | O2 Sensor Circuit Range/Performance (Low) (Bank1 Sensor1)     | <Ref. to EN(H4SO 2.5)(diag)-216, DTC P1152 O2 SENSOR CIRCUIT RANGE/PERFORMANCE (LOW) (BANK1 SENSOR1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>     |
| P1153 | O2 Sensor Circuit Range/Performance (High) (Bank1 Sensor1)    | <Ref. to EN(H4SO 2.5)(diag)-218, DTC P1153 O2 SENSOR CIRCUIT RANGE/PERFORMANCE (HIGH) (BANK1 SENSOR1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>    |
| P1160 | Return Spring Failure   | <Ref. to EN(H4SO 2.5)(diag)-221, DTC P1160 RETURN SPRING FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P1492 | EGR Solenoid Valve Signal #1 Circuit Malfunction (Low Input)  | <Ref. to EN(H4SO 2.5)(diag)-221, DTC P1492 EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1493 | EGR Solenoid Valve Signal #1 Circuit Malfunction (High Input) | <Ref. to EN(H4SO 2.5)(diag)-221, DTC P1493 EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1494 | EGR Solenoid Valve Signal #2 Circuit Malfunction (Low Input)  | <Ref. to EN(H4SO 2.5)(diag)-221, DTC P1494 EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1495 | EGR Solenoid Valve Signal #2 Circuit Malfunction (High Input) | <Ref. to EN(H4SO 2.5)(diag)-221, DTC P1495 EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1496 | EGR Solenoid Valve Signal #3 Circuit Malfunction (Low Input)  | <Ref. to EN(H4SO 2.5)(diag)-221, DTC P1496 EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |

## List of Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| DTC   | Item  | NOTE  |
|-------|---|---|
| P1497 | EGR Solenoid Valve Signal #3 Circuit Malfunction (High Input)     | <Ref. to EN(H4SO 2.5)(diag)-221, DTC P1497 EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>       |
| P1498 | EGR Solenoid Valve Signal #4 Circuit Malfunction (Low Input)      | <Ref. to EN(H4SO 2.5)(diag)-222, DTC P1498 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>        |
| P1499 | EGR Solenoid Valve Signal #4 Circuit Malfunction (High Input)     | <Ref. to EN(H4SO 2.5)(diag)-224, DTC P1499 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>       |
| P1518 | Starter Switch Circuit Low Input                                  | <Ref. to EN(H4SO 2.5)(diag)-226, DTC P1518 STARTER SWITCH CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                    |
| P1560 | Back-Up Voltage Circuit Malfunction                               | <Ref. to EN(H4SO 2.5)(diag)-229, DTC P1560 BACK-UP VOLTAGE CIRCUIT MALFUNCTION, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                 |
| P1570 | Antenna   | <Ref. to IM(diag)-18, DTC P1570 ANTENNA, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1571 | Reference Code Incompatibility                                    | <Ref. to IM(diag)-21, DTC P1571 REFERENCE CODE INCOMPATIBILITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P1572 | IMM Circuit Failure (Except Antenna Circuit)                      | <Ref. to IM(diag)-22, DTC P1572 IMM CIRCUIT FAILURE (EXCEPT ANTENNA CIRCUIT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                   |
| P1574 | Key Communication Failure   | <Ref. to IM(diag)-25, DTC P1574 KEY COMMUNICATION FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1576 | EGI Control Module EEPROM   | <Ref. to IM(diag)-25, DTC P1576 EGI CONTROL MODULE EEPROM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1577 | IMM Control Module EEPROM   | <Ref. to IM(diag)-25, DTC P1577 IMM CONTROL MODULE EEPROM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1578 | Meter Failure   | <Ref. to IM(diag)-26, DTC P1578 METER FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P2101 | Throttle Actuator Control Motor Circuit Range/Performance         | <Ref. to EN(H4SO 2.5)(diag)-231, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>           |
| P2102 | Throttle Actuator Control Motor Circuit Low                       | <Ref. to EN(H4SO 2.5)(diag)-237, DTC P2102 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                         |
| P2103 | Throttle Actuator Control Motor Circuit High                      | <Ref. to EN(H4SO 2.5)(diag)-240, DTC P2103 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                        |
| P2109 | Throttle/Pedal Position Sensor A Minimum Stop Performance         | <Ref. to EN(H4SO 2.5)(diag)-241, DTC P2109 THROTTLE ANGLE CLOSED POSITION ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                |
| P2122 | Throttle/Pedal Position Sensor/Switch "D" Circuit Low Input       | <Ref. to EN(H4SO 2.5)(diag)-242, DTC P2122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P2123 | Throttle/Pedal Position Sensor/Switch "D" Circuit High Input      | <Ref. to EN(H4SO 2.5)(diag)-245, DTC P2123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>        |
| P2127 | Throttle/Pedal Position Sensor/Switch "E" Circuit Low Input       | <Ref. to EN(H4SO 2.5)(diag)-247, DTC P2127 THROTTLE/PEDAL POSITION SENSOR/SWITCH "E" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P2128 | Throttle/Pedal Position Sensor/Switch "E" Circuit High Input      | <Ref. to EN(H4SO 2.5)(diag)-250, DTC P2128 THROTTLE/PEDAL POSITION SENSOR/SWITCH "E" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>        |
| P2135 | Throttle/Pedal Position Sensor/Switch "A"/"B" Voltage Rationality | <Ref. to EN(H4SO 2.5)(diag)-252, DTC P2135 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" / "B" VOLTAGE RATIONALITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

# List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC   | Item  | NOTE  |
|-------|---|---|
| P2138 | Throttle/Pedal Position Sensor/Switch "D"/"E" Voltage Rationality | <Ref. to EN(H4SO 2.5)(diag)-257, DTC P2138 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" / "E" VOLTAGE RATIONALITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

## 2. KA AND KS MODEL

| DTC   | Item  | NOTE   |
|-------|---|--|
| P0030 | HO2S Heater Control Circuit (Bank 1 Sensor 1)                     | <Ref. to EN(H4SO 2.0)(diag)-71, DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                     |
| P0031 | HO2S Heater Control Circuit Low (Bank 1 Sensor 1)                 | <Ref. to EN(H4SO 2.0)(diag)-73, DTC P0031 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P0032 | HO2S Heater Control Circuit High (Bank 1 Sensor 1)                | <Ref. to EN(H4SO 2.0)(diag)-76, DTC P0032 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                |
| P0037 | HO2S Heater Control Circuit Low (Bank 1 Sensor 2)                 | <Ref. to EN(H4SO 2.0)(diag)-78, DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |
| P0038 | HO2S Heater Control Circuit High (Bank 1 Sensor 2)                | <Ref. to EN(H4SO 2.0)(diag)-81, DTC P0038 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                |
| P0107 | Manifold Absolute Pressure/Barometric Pressure Circuit Low Input  | <Ref. to EN(H4SO 2.0)(diag)-83, DTC P0107 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0108 | Manifold Absolute Pressure/Barometric Pressure Circuit High Input | <Ref. to EN(H4SO 2.0)(diag)-86, DTC P0108 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0112 | Intake Air Temperature Circuit Low Input                          | <Ref. to EN(H4SO 2.0)(diag)-89, DTC P0112 INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                          |
| P0113 | Intake Air Temperature Circuit High Input                         | <Ref. to EN(H4SO 2.0)(diag)-91, DTC P0113 INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                         |
| P0117 | Engine Coolant Temperature Circuit Low Input                      | <Ref. to EN(H4SO 2.0)(diag)-94, DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                      |
| P0118 | Engine Coolant Temperature Circuit High Input                     | <Ref. to EN(H4SO 2.0)(diag)-96, DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                     |
| P0122 | Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input       | <Ref. to EN(H4SO 2.0)(diag)-99, DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>       |
| P0123 | Throttle/Pedal Position Sensor/Switch "A" Circuit High Input      | <Ref. to EN(H4SO 2.0)(diag)-102, DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>     |
| P0125 | Insufficient Coolant Temperature for Closed Loop Fuel Control     | <Ref. to EN(H4SO 2.0)(diag)-105, DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>    |
| P0130 | O2 Sensor Circuit (Bank 1 Sensor 1)                               | <Ref. to EN(H4SO 2.0)(diag)-107, DTC P0130 O2 SENSOR CIRCUIT (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                              |
| P0131 | O2 Sensor Circuit Low Voltage (Bank 1 Sensor 1)                   | <Ref. to EN(H4SO 2.0)(diag)-110, DTC P0131 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                  |
| P0132 | O2 Sensor Circuit High Voltage (Bank 1 Sensor 1)                  | <Ref. to EN(H4SO 2.0)(diag)-112, DTC P0132 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                 |

## List of Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| DTC   | Item   | NOTE   |
|-------|--|--|
| P0133 | O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)                    | <Ref. to EN(H4SO 2.0)(diag)-114, DTC P0133 O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                    |
| P0134 | O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)             | <Ref. to EN(H4SO 2.0)(diag)-116, DTC P0134 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>             |
| P0137 | O2 Sensor Circuit Low Voltage (Bank 1 Sensor 2)                      | <Ref. to EN(H4SO 2.0)(diag)-118, DTC P0137 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                      |
| P0138 | O2 Sensor Circuit High Voltage (Bank 1 Sensor 2)                     | <Ref. to EN(H4SO 2.0)(diag)-121, DTC P0138 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                     |
| P0139 | O2 Sensor Circuit Slow Response (Bank 1 Sensor 2)                    | <Ref. to EN(H4SO 2.0)(diag)-124, DTC P0139 O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                    |
| P0171 | System Too Lean (Bank 1)   | <Ref. to EN(H4SO 2.0)(diag)-126, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0172 | System Too Rich (Bank 1)   | <Ref. to EN(H4SO 2.0)(diag)-126, DTC P0172 SYSTEM TOO RICH (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0222 | Throttle/Pedal Position Sensor/Switch "B" Circuit Low Input          | <Ref. to EN(H4SO 2.0)(diag)-128, DTC P0222 THROTTLE/PEDAL POSITION SENSOR/SWITCH "B" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>          |
| P0223 | Throttle/Pedal Position Sensor/Switch "B" Circuit High Input         | <Ref. to EN(H4SO 2.0)(diag)-131, DTC P0223 THROTTLE/PEDAL POSITION SENSOR/SWITCH "B" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P0301 | Cylinder 1 Misfire Detected  | <Ref. to EN(H4SO 2.0)(diag)-134, DTC P0301 CYLINDER 1 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0302 | Cylinder 2 Misfire Detected  | <Ref. to EN(H4SO 2.0)(diag)-134, DTC P0302 CYLINDER 2 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0303 | Cylinder 3 Misfire Detected  | <Ref. to EN(H4SO 2.0)(diag)-134, DTC P0303 CYLINDER 3 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0304 | Cylinder 4 Misfire Detected  | <Ref. to EN(H4SO 2.0)(diag)-135, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0327 | Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)           | <Ref. to EN(H4SO 2.0)(diag)-142, DTC P0327 KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>           |
| P0328 | Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)          | <Ref. to EN(H4SO 2.0)(diag)-144, DTC P0328 KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>          |
| P0335 | Crankshaft Position Sensor "A" Circuit                               | <Ref. to EN(H4SO 2.0)(diag)-146, DTC P0335 CRANKSHAFT POSITION SENSOR "A" CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                               |
| P0340 | Camshaft Position Sensor "A" Circuit (Bank 1 or Single Sensor)       | <Ref. to EN(H4SO 2.0)(diag)-148, DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>       |
| P0400 | Exhaust Gas Recirculation Flow                                       | <Ref. to EN(H4SO 2.0)(diag)-150, DTC P0400 EXHAUST GAS RECIRCULATION FLOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                       |
| P0420 | Catalyst System Efficiency Below Threshold (Bank 1)                  | <Ref. to EN(H4SO 2.0)(diag)-153, DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                  |
| P0458 | Evaporative Emission Control System Purge Control Valve Circuit Low  | <Ref. to EN(H4SO 2.0)(diag)-155, DTC P0458 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P0459 | Evaporative Emission Control System Purge Control Valve Circuit High | <Ref. to EN(H4SO 2.0)(diag)-157, DTC P0459 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

# List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC   | Item   | NOTE   |
|-------|--|--|
| P0462 | Fuel Level Sensor Circuit Low Input                          | <Ref. to EN(H4SO 2.0)(diag)-159, DTC P0462 FUEL LEVEL SENSOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                          |
| P0463 | Fuel Level Sensor Circuit High Input                         | <Ref. to EN(H4SO 2.0)(diag)-159, DTC P0463 FUEL LEVEL SENSOR CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                         |
| P0500 | Vehicle Speed Sensor   | <Ref. to EN(H4SO 2.0)(diag)-159, DTC P0500 VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0512 | Starter Request Circuit                                      | <Ref. to EN(H4SO 2.0)(diag)-160, DTC P0512 STARTER REQUEST CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                      |
| P0513 | Incorrect Immobilizer Key                                    | <Ref. to IM(diag)-17, DTC P0513 INCORRECT IMMOBILIZER KEY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P0519 | Idle Control System Malfunction (Fail-Safe)                  | <Ref. to EN(H4SO 2.0)(diag)-163, DTC P0519 IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                  |
| P0558 | Generator Circuit Low Input                                  | <Ref. to EN(H4SO 2.0)(diag)-163, DTC P0558 GENERATOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                  |
| P0559 | Generator Circuit High Input                                 | <Ref. to EN(H4SO 2.0)(diag)-164, DTC P0559 GENERATOR CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                       |
| P0600 | Serial Communication Link                                    | <Ref. to EN(H4SO 2.0)(diag)-165, DTC P0600 SERIAL COMMUNICATION LINK, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                    |
| P0604 | Internal Control Module Read Access Memory (RAM) Error       | <Ref. to EN(H4SO 2.0)(diag)-166, DTC P0604 INTERNAL CONTROL MODULE READ ACCESS MEMORY (RAM) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>       |
| P0605 | Internal Control Module Read Only Memory (ROM) Error         | <Ref. to EN(H4SO 2.0)(diag)-167, DTC P0605 INTERNAL CONTROL MODULE READ ONLY MEMORY (ROM) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P0607 | Control Module Performance                                   | <Ref. to EN(H4SO 2.0)(diag)-168, DTC P0607 CONTROL MODULE PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                   |
| P0638 | Throttle Actuator Control Range/Performance (Bank 1)         | <Ref. to EN(H4SO 2.0)(diag)-169, DTC P0638 THROTTLE ACTUATOR CONTROL RANGE/PERFORMANCE (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P0691 | Cooling Fan 1 Control Circuit Low                            | <Ref. to EN(H4SO 2.0)(diag)-170, DTC P0691 COOLING FAN 1 CONTROL CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                            |
| P0692 | Cooling Fan 1 Control Circuit High                           | <Ref. to EN(H4SO 2.0)(diag)-170, DTC P0692 COOLING FAN 1 CONTROL CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                           |
| P0700 | Transmission Control System (MIL Request)                    | <Ref. to EN(H4SO 2.0)(diag)-170, DTC P0700 TRANSMISSION CONTROL SYSTEM (MIL REQUEST), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                    |
| P0851 | Neutral Switch Input Circuit Low                             | <Ref. to EN(H4SO 2.0)(diag)-171, DTC P0851 NEUTRAL SWITCH INPUT CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                             |
| P0852 | Neutral Switch Input Circuit High                            | <Ref. to EN(H4SO 2.0)(diag)-173, DTC P0852 NEUTRAL SWITCH INPUT CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                            |
| P1134 | A/F Sensor Micro-Computer Problem                            | <Ref. to EN(H4SO 2.0)(diag)-176, DTC P1134 A/F SENSOR MICRO-COMPUTER PROBLEM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                            |
| P1137 | O2 Sensor Circuit (Lamda=1) (Bank1 Sensor1)                  | <Ref. to EN(H4SO 2.0)(diag)-178, DTC P1137 O2 SENSOR CIRCUIT (BANK1 SENSOR1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                            |
| P1160 | Return Spring Failure  | <Ref. to EN(H4SO 2.0)(diag)-181, DTC P1160 RETURN SPRING FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1492 | EGR Solenoid Valve Signal #1 Circuit Malfunction (Low Input) | <Ref. to EN(H4SO 2.0)(diag)-181, DTC P1492 EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

## List of Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| DTC   | Item  | NOTE  |
|-------|---|---|
| P1493 | EGR Solenoid Valve Signal #1 Circuit Malfunction (High Input) | <Ref. to EN(H4SO 2.0)(diag)-181, DTC P1493 EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1494 | EGR Solenoid Valve Signal #2 Circuit Malfunction (Low Input)  | <Ref. to EN(H4SO 2.0)(diag)-181, DTC P1494 EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1495 | EGR Solenoid Valve Signal #2 Circuit Malfunction (High Input) | <Ref. to EN(H4SO 2.0)(diag)-181, DTC P1495 EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1496 | EGR Solenoid Valve Signal #3 Circuit Malfunction (Low Input)  | <Ref. to EN(H4SO 2.0)(diag)-181, DTC P1496 EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1497 | EGR Solenoid Valve Signal #3 Circuit Malfunction (High Input) | <Ref. to EN(H4SO 2.0)(diag)-181, DTC P1497 EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1498 | EGR Solenoid Valve Signal #4 Circuit Malfunction (Low Input)  | <Ref. to EN(H4SO 2.0)(diag)-182, DTC P1498 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1499 | EGR Solenoid Valve Signal #4 Circuit Malfunction (High Input) | <Ref. to EN(H4SO 2.0)(diag)-184, DTC P1499 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1518 | Starter Switch Circuit Low Input                              | <Ref. to EN(H4SO 2.0)(diag)-186, DTC P1518 STARTER SWITCH CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                              |
| P1521 | Brake Switch Circuit Range/Performance Problem (High Input)   | <Ref. to EN(H4SO 2.0)(diag)-189, DTC P1521 BRAKE SWITCH CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P1560 | Back-Up Voltage Circuit Malfunction                           | <Ref. to EN(H4SO 2.0)(diag)-191, DTC P1560 BACK-UP VOLTAGE CIRCUIT MALFUNCTION, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                           |
| P1570 | Antenna   | <Ref. to IM(diag)-18, DTC P1570 ANTENNA, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1571 | Reference Code Incompatibility                                | <Ref. to IM(diag)-21, DTC P1571 REFERENCE CODE INCOMPATIBILITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>   |
| P1572 | IMM Circuit Failure (Except antenna circuit)                  | <Ref. to IM(diag)-22, DTC P1572 IMM CIRCUIT FAILURE (EXCEPT ANTENNA CIRCUIT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                             |
| P1574 | Key Communication Failure                                     | <Ref. to IM(diag)-25, DTC P1574 KEY COMMUNICATION FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1576 | EGI Control Module EEPROM                                     | <Ref. to IM(diag)-25, DTC P1576 EGI CONTROL MODULE EEPROM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1577 | IMM Control Module EEPROM                                     | <Ref. to IM(diag)-25, DTC P1577 IMM CONTROL MODULE EEPROM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P1578 | Meter Failure   | <Ref. to IM(diag)-26, DTC P1578 METER FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |
| P2100 | Throttle Control Motor Circuit Open                           | <Ref. to EN(H4SO 2.0)(diag)-192, DTC P2100 THROTTLE CONTROL MOTOR CIRCUIT OPEN, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                           |
| P2101 | Throttle Actuator Control Motor Circuit Range/Performance     | <Ref. to EN(H4SO 2.0)(diag)-193, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>     |
| P2102 | Throttle Actuator Control Motor Circuit Low                   | <Ref. to EN(H4SO 2.0)(diag)-200, DTC P2102 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                   |
| P2103 | Throttle Actuator Control Motor Circuit High                  | <Ref. to EN(H4SO 2.0)(diag)-203, DTC P2103 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                  |



# List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC   | Item  | NOTE  |
|-------|---|---|
| P2109 | Throttle/Pedal Position Sensor A Minimum Stop Performance         | <Ref. to EN(H4SO 2.0)(diag)-205, DTC P2109 THROTTLE ANGLE CLOSED POSITION ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                |
| P2111 | Throttle Actuator Control System - Stuck Open                     | <Ref. to EN(H4SO 2.0)(diag)-205, DTC P2111 THROTTLE ACTUATOR CONTROL SYSTEM - STUCK OPEN, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                       |
| P2122 | Throttle/Pedal Position Sensor/Switch "D" Circuit Low Input       | <Ref. to EN(H4SO 2.0)(diag)-206, DTC P2122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P2123 | Throttle/Pedal Position Sensor/Switch "D" Circuit High Input      | <Ref. to EN(H4SO 2.0)(diag)-209, DTC P2123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>        |
| P2127 | Throttle/Pedal Position Sensor/Switch "E" Circuit Low Input       | <Ref. to EN(H4SO 2.0)(diag)-211, DTC P2127 THROTTLE/PEDAL POSITION SENSOR/SWITCH "E" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>         |
| P2128 | Throttle/Pedal Position Sensor/Switch "E" Circuit High Input      | <Ref. to EN(H4SO 2.0)(diag)-214, DTC P2128 THROTTLE/PEDAL POSITION SENSOR/SWITCH "E" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>        |
| P2135 | Throttle/Pedal Position Sensor/Switch "A"/"B" Voltage Rationality | <Ref. to EN(H4SO 2.0)(diag)-216, DTC P2135 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" / "B" VOLTAGE RATIONALITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P2138 | Throttle/Pedal Position Sensor/Switch "D"/"E" Voltage Rationality | <Ref. to EN(H4SO 2.0)(diag)-220, DTC P2138 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" / "E" VOLTAGE RATIONALITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |